


Phone Book

Overview	4-2
Saving to Phone Book	4-3
Phone Book Entry Items.....	4-3
Create New Entry	4-3
Other Ways to Add New Entries	4-5
Setting Groups	4-6
Searching/Using Phone Book.....	4-6
Making Calls from Phone Book.....	4-6
Using Phone Book	4-7
Managing Phone Book	4-9
Editing Phone Book Entries	4-9
Deleting Phone Book Entries.....	4-9
Copying/Deleting Phone Book Data	4-9
Phone Book Memory Status.....	4-9
S! Addressbook Back-up.....	4-10
Manual Synchronization	4-11
Auto Synchronization.....	4-11
Viewing Sync Log	4-11
Account Details	4-12
Editing Account Details.....	4-12
Account Details Functions.....	4-12
Voice Dial.....	4-13
Adding Entries to Voice Dial.....	4-13
Searching Entries by Voice Dial.....	4-13


Overview

Save frequently used phone numbers and mail addresses to Phone Book.


Supplement phone numbers and mail addresses with birthday, street address, an image or notes.



Set tones/image for each entry.



Sort entries into Groups.



Note

● Back-up Important Information

Keep a separate copy of Phone Book entry information. When battery is exhausted or removed for extended periods, entries may be lost. Handset damage may also affect data recovery. SoftBank is not liable for damages from lost/altered entries.

Tip

● Backing up to microSD Card (P.10-19)

Saving to Phone Book

Phone Book Entry Items

Save up to 1000 entries in handset Phone Book; 50 entries to USIM Card Phone Book.

- Available entry items are as follows.

Phone Book Entry Items		Handset	USIM Card
Basic Item	Name (Reading)	○	○
	Group	19	10
	Phone number	4	2
	Mail address	3	1
	Address	○	—
	Location information	○	—
	Birthday	○	—
	Memo	○	—
	Image	100	—
	Memory number	000 - 999	—
Incoming Settings	Ringtone	○	—
	Vibrator		
	Notification Light		
	Screen		
	Msg Ringtone		
	Msg Vibrator		
	Msg Notif. Light		
Answer message			

○: Can be saved —: Cannot be saved


- Phone Book entries in USIM Card can also be used in another SoftBank handset.

Create New Entry

Save new entries to handset or USIM Card Phone Book.

- When saving to USIM Card Phone Book, set *Save Settings* to *USIM* or *Ask Every Time* beforehand (P.18-12).

- Press and hold
- Enter Last name →
Enter First name
 - For handset Phone Book, to switch Basic item and Incoming Settings tabs.



Handset Phone Book

- Select an item (See below)

Item	Operation/Description
Last name	Save last name. For USIM Card, enter both first name and last name together >Enter last name
First name	Save first name >Enter first name
Reading (Last/First)	Automatically entered when last/first name is entered. For USIM Card, both readings are entered together. >To change reading, edit

Item	Operation/Description
Group	Categorize/search entries by group > Select a group ● Change group names or set ringtones for individual groups (☞P.4-6).
Phone number	> Enter phone number (→ For handset, select an icon)
Mail address	> Enter mail address (→ For handset, select an icon) ● Save only phone number if mail address is "phone number@softbank.ne.jp".
Address	Save zip code, country/region, prefecture, city, number/street and additional information > Select an item → Enter each information → Home or Office → For entering other information, [Return]
Location information	Identify handset location and save information. Also, save location record selected from location logs > Select an item · By position loc. → YES → Check information → [Set] (To show information while positioning: When [Use] appears at lower right of display, press [OK]. To retry positioning: [Retry]) · From loc. history → Select a location record to save
Birthday	> Enter birthday
Memo	> Enter memo

Item	Operation/Description
Image	Save a still image to appear for incoming calls > Select an item · Select image → Select a folder → Select a file · Shoot image → Frame subject → ● [Record]/[]/[]/[] → ● [Save]/[]/[]/[] ● Saved still image appears for an incoming call only when Phone Book Image (☞P.18-7) is ON . If there is an image saved for Screen , the image preferentially appears.
Memory number	> Enter memory number
Ring tone	> Ring Tones → Select a type → Select a folder → Select a ringtone
Vibrator	> Select vibrator → Select a pattern
Notification Light	> Select illumination → Select a pattern
Screen*	> SEL picture → Select a screen type → Select a folder → Select an image ● Saved still image appears for an incoming call whether Phone Book Image is ON or OFF . Phone Book Image setting applies only when still image is saved for Image .
Msg Ringtone	> Ring Tones → Select a type → Select a folder → Select a ringtone
Msg Vibrator	> Select vibrator → Select a pattern
Msg Notif. Light	> Select illumination → Select a pattern
Answer message	> Select answer message → Select a message



* To cancel: Select **RLS picture**

4 [Finish]

Other Ways to Add New Entries

Save currently displayed phone numbers, mail addresses, still images or location information to Phone Book.

Example: Saving Numbers from Incoming Call Logs

1  → Highlight a record →  [Menu] → **Add to Phone Book**

2 **New Entry**

New → Enter details (→ Step 3 on P.4-3)

Add to Existing Entry


Add → Select entry → Enter other details

(→ Step 3 on P.4-3)

- When saving to USIM Card, **Overwrite** appears instead of **Add**.

3 When complete,  [Finish] (→ **YES**)


Note




- Press  [Menu] from a function. If **Add to Phone Book** appears, the information is savable to Phone Book. From a message window, select **Add Address** to save entries; from still image list/still image, select **Set display → Phone Book** to save entries.
- When saving new entries in Secret Mode or Secret Data Only, entries are saved to handset regardless of Save Settings.

Setting Groups

Sort entries by Group. Custom set ringtones/vibrators/notifications per group.

Main Menu ► Phone ► Group

-  appears for USIM Card Group.

- 1 Highlight a group →  [Edit] → Select an item → Set item
 - Enter group name for " Group name."
 - For other item operations:  P.4-3

- 2 When complete,  [Finish]

■ Check Settings

- > Select a group entry, or  [Menu] → *Check setting*
- Settings cannot be checked in USIM Card Group Phone Book.

■ Reset Group Setting

- > Highlight a group →  [Menu] → *Reset group* → YES



Note





- Custom settings unavailable for USIM Card Groups.
- Individually set ringtones are prioritized over those set for groups.

Searching/Using Phone Book

Making Calls from Phone Book

<Default> A-KA-SA-TA-NA

- 1 
- 2 Search Phone Book (See below)
 - To change search method:  → Select a search method (See below)

Search Method	Operation/Description
A-KA-SA-TA-NA	Search entries by katakana syllabary. Names saved in Roman characters are saved under the 英 tab. > Highlight a reading page ● Alternatively, enter partial reading
Reading	> Enter partial reading → 
Group	> Select a group
Memory Number*	Enter memory (entry) number to search for an entry > Enter a memory number
Name	> Enter partial name → 
Phone Number	> Enter partial phone number → 
Mail Address	> Enter partial mail address → 
2-touch Dial*	Show entries with memory (entry) numbers 000 - 009

* Handset Phone Book only

- 3 Select an entry
- 4 


5 Voice Calls

Highlight a phone number → 










Video Calls

Highlight a phone number →  [V. Call]

Note



- To scroll through entries, enter nothing and press  (not available in **Group** or **2-touch Dial**).
- If no matches are found in **Reading** or **Memory Number** method, entries closest to condition appear.
- Once a method is selected, same method retains.









Additional Search/Dialing Methods


Open Tab Assigned to Key from Standby	Press and hold  –  Open search window assigned to key.
Enter Partial Number from Standby or during Call	Enter partial number → 
By Memory Number	 →  → Enter a memory number
By Single-digit Memory Number (2-touch Dial)	Enter last digit ( – ) of memory number 000-009 → Voice Call:  /Video Call:  [V. Call]

Using Phone Book

Use Phone Book Entries

>  → Highlight an entry →  [Menu] → Select an item
(See below)

Item	Operation/Description
New	Add a new entry ( From Step 2 on P.4-3)
Sort¹	Change display order > Select an order
Send Ir data²	( P.11-3)
IC transmission²	( P.11-5)
Send to Bluetooth²	( P.11-9)
Copy to microSD²	Copy an entry to microSD Card > YES ● To view copied data:  P.10-18
S! Addressbook BkUp	( P.4-10)
Delete phone book	> Select an item → Follow steps for selected option ( P.4-9)
Character size	Switch character size to large/standard
Set secret mode/Release secret²	Set/cancel Secret Mode for selected entry ● Entries saved as secret data appear only when Secret Mode or Secret Data Only is active ( P.12-10).

¹ Available only when search method ( P.4-6) is set to **Name, Phone Number** or **Mail Address**

² Not available in USIM Card Phone Book

■ Use Entry Details

>  → Select an entry →  [Menu] → Select an item (See below)

Item	Operation/Description
Notify caller ID	Show/hide caller ID (☞P.2-3)
Prefix numbers	Make a call using a prefix number (☞P.2-3)
Int'l dial assist	Set International dial assist (☞P.2-10)
Restrictions*	Activate restrictions on specified entry (☞P.12-12)
Edit Phone Book	Edit entry (☞From Step 3 on P.4-3)
Delete phone book	> Phone number or Delete this → YES ● Item names vary by selected item: Mail address/Address/Location info/Birthday/Memo/Image
Add shortcut icon	Create a shortcut (☞P.1-23)
Compose S! Mail	Create a message to mail address of selected entry (☞From Step 4 on P.14-4)
Compose SMS	Create an SMS message to phone number of selected entry (☞From Step 4 on P.14-7) ● Message can be sent to SoftBank handsets only.
Send Ir data*	(☞P.11-3)
IC transmission*	(☞P.11-5)
Send to Bluetooth*	(☞P.11-9)

Item	Operation/Description
Copy to microSD*	Copy an entry to microSD Card > YES ● To display copied data: ☞P.10-18
S! Addressbook BkUp	(☞P.4-10)
Copy names	Copy a name
Copy phone numbers	Copy an item ● Item names vary by selected item. Copy mail add./Copy address/Copy location info/Copy birthday/Copy memo
Character size	Switch character size to large/standard
Set secret mode/ Release secret*	Set/cancel Secret Mode for selected entry ● Entries saved as secret data appear only when Secret Mode or Secret Data Only is active (☞P.12-10).
Copy to USIM/ Copy from USIM	Copy an entry to USIM Card > YES



* Not available in USIM Card Phone Book

Note



- Insert entry details to a message (☞P.3-6).



Managing Phone Book

Editing Phone Book Entries

- 1  → Select an entry →  [Edit]
- 2 Edit (↳ From Step 3 on P.4-3) → **YES**

Deleting Phone Book Entries

- 1  → Highlight an entry →  [Menu] → **Delete phone book**
- 2 Select an item (See below)

Item	Operation/Description
Delete this	> YES
Delete select	> Check entries to delete →  [Finish] → YES •  [Menu] → Select all in tab* , Select all , Release all in tab* or Release all to check/uncheck all entries at a time
Delete all in tab*	> YES
Delete all	Delete all entries (handset/USIM Card Phone Book) including Secret Mode entries > Enter Phone Password → YES → YES


* Available in **A-KA-SA-TA-NA**, **Reading**, **Group** and **Memory Number** search methods (↳ P.4-6)

Copying/Deleting Phone Book Data

Main Menu ► Phone ► Memory Manager

- 1 Enter Phone Password
- 2 Select an item (See below)

Item	Operation/Description
Copy	Copy data between handset/USIM Card Phone Book > Copy to USIM or Copy from USIM
Delete	Delete data in handset/USIM Card Phone Book > Phone or USIM

- 3 **Phone Book** → Select an entry*
* To clear, repeat operation.
- 4  [Finish] → **YES**

Phone Book Memory Status

Main Menu ► Phone ► Memory Status

View handset/USIM Card Phone Book memory status.

S! Addressbook Back-up

Back up Phone Book entries to S! Addressbook (network server); synchronize handset Phone Book with S! Addressbook; restore Phone Book after accidental loss/alteration.

- Separate subscription is required for this service.

Notes

- Fully charge battery beforehand (🔋 appears).
- Transmission fees apply to synchronization, backup and restoration.
- **Restore** cancels these Phone Book settings: Ringtone, Vibrator, Notification Light, Picture, Answer message.
- Subscription to the service activates Auto Sync Settings during network information retrieval to back up edited Phone Book entries. Note that initiating network information retrieval activates Auto Sync Settings even when Auto Sync Settings are **OFF**. When contract is terminated, check if Auto Sync Settings are **OFF** (☞P.4-11).
- **S! Addressbook is deleted upon contract termination.**
- **Addresses saved in Address field on handset Phone Book are saved to building name field in S! Addressbook.**
- **When number of characters saved in S! Addressbook exceeds maximum number of characters savable on handset Phone Book, excess characters do not appear on handset Phone Book.**

Synchronization/Back-up/Restoration

- Be careful of back-up/restoration timing or selecting a synchronization direction.
- When no handset Phone Book entries exist, executing regular update or selecting **Sync from Client** or **Backup** deletes S! Addressbook.
- When no S! Addressbook entries exist, executing regular update or selecting **Sync from Server** or **Restore** deletes all handset Phone Book entries.

Capacity Disparities

- When the number of savable items varies between handset Phone Book and S! Addressbook, synchronization reflects lower limit.

Transfer to New Handsets

- S! Addressbook Back-up-compatible 3G Handsets: Data remains.
- Other 3G Handsets: Service subscription and data remains, but data is not accessible via handset (accessible via PCs).
- V3/V4/V5/V6/V8 Series: Service subscription is terminated and data is deleted.

Manual Synchronization

Regular Update

Update S! Addressbook and handset Phone Book after adding/editing entries.

Main Menu ► Phone ► S! Addressbook BkUp

1 Start Sync

Selecting Sync Type

Main Menu ► Phone ► S! Addressbook BkUp ► Details
► Backup/Restore

1 Select an item (See below)

Item	Operation/Description
Sync from Client	Send data changed in handset Phone Book to S! Addressbook
Backup	Delete all S! Addressbook entries and save handset Phone Book to S! Addressbook
Sync from Server	Send data changed in S! Addressbook to handset Phone Book
Restore	Delete all handset Phone Book entries and save S! Addressbook to handset Phone Book

2 YES

Auto Synchronization

Main Menu ► Phone ► S! Addressbook BkUp ► Details
► Auto Sync Settings

1 ON

- To cancel, select **OFF**

2 Select an item (See below)

Item	Operation/Description
Every month	Synchronize monthly at specified time of the date > Enter a date → Set start time
Every week	Synchronize weekly at specified time of the day > Select a day → Enter start time
After Editing PB	Synchronize ten minutes after editing

3 Select a Sync Type → YES

■ View Auto Sync Settings

> In Step 1, **Confirm Settings**

Viewing Sync Log

Main Menu ► Phone ► S! Addressbook BkUp ► Details
► Sync Log

1 Select a log

■ Delete Sync Log

> In Step 1, (highlight a log →) [Menu] → **Delete this** or **Delete all**
(→ For **Delete all**, enter Phone Password) → YES

Account Details

Save phone number, mail address, street address, etc. in Account Details.

Editing Account Details

- 1 →
- 2 [Edit]
- 3 Enter Phone Password → Edit → [Finish]
 - Your subscribing phone number cannot be edited or deleted.

Account Details Functions

In Account Details, press [Menu] for following operations.

Item	Operation/Description
Edit*	Edit Account Details (☞ From Step 3 above)
Character size	Switch character size to large/standard
Display all data*	View all saved items such as phone numbers and mail addresses
Copy names	Copy a name
Copy phone numbers	Copy an item <ul style="list-style-type: none"> ● Item names vary by selected item. <i>Copy mail add./Copy address/Copy birthday/Copy notepad</i>

Item	Operation/Description
Send Ir data	Send details via Infrared (☞ P.11-3) <ul style="list-style-type: none"> ● Alternatively, while Account Details is open, press [Ir].
IC transmission	Send details via IC transmission (☞ P.11-5) <ul style="list-style-type: none"> ● Alternatively, while Account Details is open, press [ICtrans].
Copy to microSD	Copy details to microSD Card <ul style="list-style-type: none"> > YES <ul style="list-style-type: none"> ● To display copied data: ☞ P.10-18 ● Account Details is saved as a Phone Book entry.
Erase phone number*	> Select an item → YES <ul style="list-style-type: none"> ● Delete items saved in Account Details ● Item names vary by selected item. <i>Erase mail add./Erase address/Erase birthday/Erase memorandums/Delete image</i>
Reset*	Reset Account Details (handset number remains) <ul style="list-style-type: none"> > YES

* Enter Phone Password if required.

Note

- Insert Account Details information to a message (☞ P.3-6).

Voice Dial

Make a call by saying a voice dial name.

Note




- Keep microphone about 10 cm away from your mouth, and pronounce a Voice Dial name clearly. If microphone is too distant, your voice may not be recognized.
- Avoid making sounds unrelated to Voice Dial names (clearing your throat, clicking your tongue, heavy breathing, etc.).
- Say Voice Dial names in quiet places.
- Avoid pressing or brushing keys, or covering microphone with fingers when pronouncing a Voice Dial name.

Adding Entries to Voice Dial

Main Menu ► Phone ► Settings ► Voice Dial

- 1 **<New>** → Select a Phone Book entry
Entries with ★ are already saved in Voice Dial list.
 - 2 Enter a Voice Dial name
 - Only katakana entry is available for Voice Dial names.
- Edit Voice Dial Names**
 > In Step 1, highlight a Voice Dial name → [Edit] → Edit name → **YES**
- Delete Voice Dial Entries**
 > In Step 1, (highlight a Voice Dial name →) [Menu] → **Delete this** or **Delete all** → **YES**

Searching Entries by Voice Dial

- 1 Press and hold  → Say a Voice Dial name
Say the name within four seconds after voice recognition tone sounds. Once Voice Dial is recognized, result appears.
 - 2 [Detail] →  to show phone number
 - 3 **Voice Calls**
Highlight phone number → 
- Video Calls**
 Highlight phone number → [V. Call]

Tip

- Settings** ● Activate Voice Dial Automatically ● Activate Voice Dial via Earphone or Bluetooth® Device (P.18-12)

