

Date & Time	14-2
Clock View/Settings	14-2
Display & Illumination	14-3
Language.....	14-3
Image & Text.....	14-3
Display & Key Illumination	14-3
External Display.....	14-4
Standby Display.....	14-4
Key Illumination	14-4

Ringtones & Sounds	14-5
Handset Response.....	14-5
System Sound.....	14-5
Additional Sound Settings	14-5
Connectivity	14-6
Network	14-6
IP Service.....	14-7
Location Information.....	14-7
Reset.....	14-8
Restoring Default Settings.....	14-8

14

Handset Customization



🔧 Date & Time Settings

Clock View/Settings

[Start Here](#) ➤ Settings ➤ In Phone menu, *Date & Time* ➤

Setting the date and time	<i>Set Date/Time</i> ➤ Enter the year ➤ Enter the month ➤ Enter the day ➤ Enter the time ➤
Correcting Clock manually	<i>Time Correction</i> ➤ <i>Manual</i> ➤ <i>Yes</i> ➤
Disabling auto Clock correction	<i>Time Correction</i> ➤ <i>Auto Corr. Setting</i> ➤ <i>Off</i> ➤
Setting auto Clock correction timing	<i>Time Correction</i> ➤ <i>Auto Corr. Setting</i> ➤ <i>On</i> ➤ Select item ➤ (☐/☑) ➤
Activating Daylight Saving	<i>Daylight Saving</i> ➤ <i>On</i> ➤
Changing Time Zone	<i>Set Time Zone</i> ➤ Select area ➤
Adding custom time zone	<i>Set Time Zone</i> ➤ Enter city name ➤ + or - ➤ Enter time difference ➤
Changing time format to 12 hour	<i>Time Format</i> ➤ <i>12 Hour</i> ➤
Changing date format	<i>Date Format</i> ➤ Select option ➤
Starting the Calendar week on Monday	<i>Calendar Format</i> ➤ <i>Monday-Sunday</i> ➤



Display & Illumination Settings 1

Language

[Start Here](#) [] → **Settings** [] → [] → Phone menu

Switching interface between Japanese and English

Language or 言語選択 [] → [] → **English** or 日本語 [] → []

Image & Text

[Start Here](#) [] → **Settings** [] → [] → In Phone menu, **Display** [] → []

Showing preloaded images for incoming calls, etc.

System Graphics [] → [] → **Select item** [] → [] → **Preset Animation (or Pattern 1 to Pattern 3)** [] → []

Showing Data Folder images for incoming calls, etc.

System Graphics [] → [] → **Select item** [] → [] → **Select folder** [] → [] → **Select image** [] → [] → **Specify display area** [] → []
 • Some images may be usable without specifying display area.

Showing Customized Screen for incoming calls, etc.

System Graphics [] → [] → **Select item** [] → [] → **Customized Screen** [] → [] → []
 • Not available for **Power On** or **Power Off**.

Changing font of numbers entered in Standby

Dial Number [] → [] → **Select pattern** [] → []

Showing a message each time handset is turned on

Greeting Message [] → [] → **Edit Message** [] → [] → **Enter message** [] → [] → [] → **Switch On/Off** [] → [] → **On** [] → []

- When using Double Number in Dual Mode, press [] in System Graphics menu to switch modes.

Display & Key Illumination

[Start Here](#) [] → **Settings** [] → [] → In Phone menu, **Display** [] → []

Disabling display transition effects

Display Effects [] → [] → **Off** [] → []

Changing Display/Keypad Backlight illumination time

Backlight [] → [] → **Time Out** [] → [] → **Select time** [] → []

Changing Display Brightness

Backlight [] → [] → **Brightness** [] → [] → **Adjust level** [] → []

Changing inactivity time after which Display turns off

Display Saving [] → [] → **Select period** [] → []



⌘ Display & Illumination Settings 2

External Display

[Start Here](#) **Settings** **In Phone menu, Display** **External Display**

Changing inactivity time after which External Display turns off

Duration **Select time**

Hiding new received messages

Messages **Not Display**

Hiding caller info

Caller Display **Off**

Changing Clock view

Display Date&Time **Select type**

Changing Clock font

Clock Type **Select pattern**

Standby Display

[Start Here](#) **Settings** **In Phone menu, Display** **Standby Display**

Changing Clock/Calendar

Clock/Calendar **Select type**

Showing Network service provider name in Standby

Show Operator Name **On**

Key Illumination

[Start Here](#) **Settings** **Phone menu**

Disabling Keypad light illumination

Set Key Light **Off**



🔧 Ringtone & Sound Settings

Handset Response

[Start Here](#) → **Settings** → **In Phone menu, Sounds & Alerts**

Changing ringtone volume	Volume → Select item → Adjust level
Selecting illumination option for incoming transmissions	Event Light → Select item → On, Link to Sound or Off
Enabling/disabling illumination for missed incoming transmissions	Status Light → Select item → On or Off
Answering calls with other keys	Any Key Answer → On • Use [0] - [9], [*], [#], ##, [M], [V], [A] or [C] in addition to [D].

- When using Double Number in Dual Mode, press [v] in Volume menu or Event Light menu to switch modes.

System Sound

[Start Here](#) → **Settings** → **In Phone menu, Sounds & Alerts**

Enabling Keypad Tones	System Sounds → Keypad Tones → Select tone
Changing S! Circle Talk tone	System Sounds → S! Circle Talk → Select tone
Changing other System Sounds	System Sounds → Select item → Tone → Select folder → Select tone/file • For files with limited usage period, choose Yes and press [D].
Disabling System Sounds	System Sounds → Select item → Tone → Off • Not available for S! Circle Talk .
Changing System Sound duration	System Sounds → Select item → Duration → Select/enter time • Not available for Keypad Tones or S! Circle Talk .
Changing System Sound volume	Volume → General Volume → Adjust level

Additional Sound Settings

[Start Here](#) → **Settings** → **Phone menu**





































































































Disabling Speaker when using Headphones	Ringer Output → Earphone
Activating Speaker surround	Sounds & Alerts → Surround → On



Connectivity Settings 1

Network

Start Here  **Settings**  **Network** 

Selecting a Network manually	<i>Select Network</i>   <i>Manual</i>   <i>Select Network</i>  
Adding preferred Networks	<i>Select Network</i>   <i>Set Preferred</i>   <i>Select location</i>   <i>Insert</i>   <i>Select Network</i>  
Adding preferred Networks to the end	<i>Select Network</i>   <i>Set Preferred</i>    <i>Add to End</i>     <i>Select Network</i>  
Deleting preferred Networks	<i>Select Network</i>   <i>Set Preferred</i>   <i>Select Network</i>   <i>Delete</i>  
Adding Networks	<i>Select Network</i>   <i>Add New Network</i>   <i>Add</i>   <i>Enter country code</i>   <i>Enter Network code</i>   <i>Enter name</i>     <i>Select NW Type</i>   <i>Select type</i>   <ul style="list-style-type: none"> • After selecting Add New Network and pressing , Network list appears if Network has already been added. To add more, press  again and proceed.
Editing Networks	<i>Select Network</i>   <i>Add New Network</i>   <i>Select Network</i>   <i>Change</i>   <i>Edit in the same manner as adding Networks</i>  
Deleting Networks	<i>Select Network</i>   <i>Add New Network</i>   <i>Select Network</i>   <i>Delete</i>  
Switching Network services manually	<i>Select Service</i>   <i>Manual</i>   <i>Select service</i>  
Retrieving Network Information	<i>Retrieve NW Info</i>   <i>Yes</i>  
Checking Network status	<i>Network Info</i>  
Editing access point names for communication with external devices	<i>External Device</i>   <i>Select name</i>   <i>Edit</i>  
Clearing access point names for communication with external devices	<i>External Device</i>    <i>Reset</i>   <i>Enter Handset Code</i>   <i>Yes</i>  



⌘ Connectivity Settings 2

IP Service

[Start Here](#) → **Settings** → **In Phone menu, Locks**

Disabling IP Service

IP Service Setting → **Off** → **Enter Handset Code**

- When **Off**, S! Friend's Status, S! Circle Talk, Decoration Call, S! Appli Notification Setting and Mobile Widget Notification Setting are disabled.

Location Information

[Start Here](#) → **Settings** → **Network** → **Location Info**

Adding/editing Location Information destination URLs

URL Setting → **<Empty> (or select URL)** → **Edit** → **Enter URL**

- Default URL is not editable.

Specifying Location Information destination URL

URL Setting → **Select URL**

Viewing Location Information destination URL

URL Setting → **Select URL** → **Display**

Deleting Location Information destination URLs

URL Setting → **Select URL** → **Delete** → **Yes**

Hiding Location Information

Datum On/Off → **Off** → **Enter Handset Code**

Changing Location Information confirmation option

















Location Property → **Select option** → **Enter Handset Code**



Reset Settings

Restoring Default Settings

[Start Here](#)   **Settings**   **In Phone menu, Master Reset**  

Restoring default handset settings	<p>Reset Settings   Enter Handset Code   Yes   Yes  </p> <ul style="list-style-type: none"> • Some default settings may not be restored.
Clearing all Phone Book entries, Data Folder files, etc.	<p>Reset All   Enter Handset Code   Yes   Yes  </p> <ul style="list-style-type: none"> • Delete IC Card data beforehand. (Procedures to delete IC Card data vary by Lifestyle-Appli; contact Osaifu-Keitai® service providers for details.) • Files and records deleted by Reset All cannot be restored. Reset All deletes all downloaded S! Applications and Lifestyle-Applications. • Handset Code returns to the default setting.

- A confirmation may appear before entering Handset Code; end the current function to proceed.
- When Double Number is active, regardless of usage mode setting, Reset Settings restores all default settings (Double Number is canceled), and Reset All clears all user files.

