

Internet Services	5-2
Service Basics	5-2
Yahoo! Keitai	5-3
Using Yahoo! Keitai.....	5-3
PC Site Browser	5-4
Using PC Site Browser	5-4
Browsing	5-5
Basic Operations	5-5

Bookmarks & Saved Pages	5-7
Using Bookmarks & Saved Pages....	5-7
RSS Feeds	5-8
Updating Blogs & News.....	5-8
Additional Functions	5-9
Troubleshooting	5-16

5

Yahoo! Keitai & PC Site Browser



Service Basics

Access the Mobile Internet via Yahoo! Keitai, or view PC Internet sites via PC Site Browser.

- Service requires a separate contract; retrieve Network Information to use these services.
- For more about Yahoo! Keitai, see SoftBank Mobile Website (P.14-22).

Transmission/Information Fees

Some page content may automatically activate Internet connection incurring transmission fees. Information fees may also apply.

Security

Electronic certificates are saved on handset to support SSL (encryption protocol for Internet transmissions of important/sensitive information).

Secure Pages

- A confirmation appears before entering and exiting secure pages.
- When a security notice appears, subscribers must decide for themselves whether or not to open the page. Opening secure pages constitutes agreement to the terms of usage. SoftBank, VeriSign Japan, Cybertrust, Entrust Japan, GlobalSign, RSA Security and SECOM Trust Systems cannot be held liable for any damages associated with the use of SSL.

Advanced



- Clearing cache (temporarily saved information) ● Clearing authentication information (And more on P.5-9)
- Disabling manufacture number auto send for authentication ● Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.) (And more on P.5-15)



Using Yahoo! Keitai

Using Yahoo! Keitai Main Menu

Browse Yahoo! Keitai sites from Yahoo! Keitai Main Menu.

Internet pages may not open depending on connection/Server status, etc.

1 → Connection starts



Cursor

Internet Page

- Yahoo! Keitai Main Menu appears.
- To disconnect, press .

2 Highlight menu item →

- Corresponding page opens.
- Repeat 2 to open additional links.

3 → Yes → → Page closes

Advanced

-  Switching browsers
-  Using previously entered URLs
-  Deleting History records
-  Opening History properties
-  Sorting History records
-  Sending History records via mail (P.5-9)
-  Customizing streaming settings
-  Streaming from Media Player (P.5-12)

Returning to Previous Pages

[Internet Page]  → Previous page opens

- Follow these steps to return to the initial page:

[Internet Page]  → Forward → 

Returning to Yahoo! Keitai Main Menu

[Internet Page]  → Yahoo! Keitai → 

User Authentication

Enter user ID or password →  → 

Playing Media Streams (Streaming)

[Internet Page] Select file → 

- Downloaded content cannot be saved.
- Packet transmission fees apply even while stream is paused.

Using History

1 → Yahoo! Keitai → → History →



2 Select record → → Connection starts

- Corresponding page opens.

3 → Yes → → Page closes

Entering URLs Directly

1 → Yahoo! Keitai → → Enter URL →



2 Enter URL → → Connection starts

- Corresponding page opens.

3 → Yes → → Page closes



Using PC Site Browser

Browse PC sites from Yahoo! JAPAN (preset home page).

- Internet pages may not open depending on connection/Server status, etc.
- Browsing PC sites may incur higher charges depending on subscribed price plan.

1 → **Yahoo! Keitai** → → **PC Site Browser** →



2 **Homepage** → → **Connection starts**



Internet Page

- Yahoo! JAPAN Home opens.
- If a message appears, follow onscreen prompts.
- To disconnect, press .

3 **Highlight menu item** →

- Corresponding page opens.
- Repeat to open additional links.

4 → **Yes** → → **Page closes**

Returning to Previous Pages

[Internet Page] → Previous page opens

- Follow these steps to return to the initial page:

[Internet Page] → **Forward** →

Returning to Yahoo! JAPAN Home

[Internet Page] → **Homepage** →

User Authentication

Enter user ID or password → →

Using History

In , **History** → → Select record →

Entering URLs Directly

In , **Enter URL** → → Enter URL →

Hiding Softkeys

[Internet Page] → **Convenient Functions** → → **Softkey Area** → → **Off** →

Browsing in Wideview

[Internet Page]

- Use Multi Selector according to page orientation.

Advanced

- Switching browsers
- Using previously entered URLs
- Deleting History records
- Opening History properties
- Sorting History records
- Sending History records via mail (P.5-9)
- Hiding navigation map for continuous scroll
- Changing scroll unit
- Hiding PC Site Browser messages (P.5-11)




Basic Operations

Page Browsing

Scrolling Pages


If page content continues beyond view, use to scroll pages.

Long Press to scroll continuously.



Switching Frames

On framed pages, Long Press to select other frames.



Frames

- In pointer navigation, point to a frame and press to select it.
- Otherwise, use to select one.

Viewing Single Frame

Select frame **Convenient Functions** **Frame In**

- To return, press .

Tabbed Browsing


Open another page in a new tab and switch between tabs.

Opening a New Tab

1 On a page, select menu item

Tab Menu

2 Open in New Tab



Switching Tabs

1 (Long) **Select tab**

- In pointer navigation, point to a tab and press to open it.

Closing Tabs

(Long) **Select tab** **Tab Menu** **Close Tab or Close All Other Tabs**

Advanced

- Using Web Search
- Searching current page
- Looking up copied words in dictionaries
- Saving files to Data Folder
- Jumping to page top/bottom
- Changing Font Size
- Enlarging specific areas
- Disabling automatic image display/sound playback
- Changing scroll unit (And more on P.5-10 - 5-11)



Selecting Text


Activate pointer navigation to enable text selection (Drag Mode). Select text to copy or look up words in dictionaries.

- Text may not be selectable or linked page may open depending on the site or page.
- Follow these steps to use a dictionary:

1 On a page, point to first character (Long)

- Drag Mode is activated.

2 Highlight text range



3

- Text range remains unchanged even when pointer is moved.

4 Select dictionary

- Dictionary opens with text inserted.

5 Search Select word, etc.

Starting Over

- After , point to first character 
-  From 

Additional Page Operations

Enter text or select/execute items.



Text Entry

1 On a page, select text entry field

2 Enter text

- Internet page returns.

Using Entered Text (Input Memory)

- [Internet page] Select text entry field 
-        
- Input Memory   Select text 

Pull-down Menu Item Selection

1 On a page, select menu list field

2 Select item

When Multiple Selection is Supported

- Select items as needed and press .

Page Item Indicators

Selection Items

Buttons or boxes appear.

1 On a page, select button or box



- / changes to /

Execution Items

Execute the assigned command.

1 On a page, select command



Using Bookmarks & Saved Pages

Bookmarks

Bookmark sites for quick access.

Saving Bookmarks

- 1 On a page, ➔ **Bookmarks**
➔ ➔ **Save** ➔
- Save appears only for savable pages.
- 2 Enter/edit title ➔
- 3 Save ➔

Opening Bookmarks

- 1 ➔ **Yahoo! Keitai** ➔ ➔ **Bookmarks** ➔



- 2 Select title ➔
- Corresponding page opens.

Switching Bookmark Type

After 1, ➔ **Change List** ➔ ➔

Select type ➔

Opening Bookmarks Online

[Internet Page] ➔ **Bookmarks** ➔
 ➔ **Open List** ➔ ➔ Select title
➔

Saved Pages

Save page content; handset opens saved pages without connecting to the Internet.

Saving Pages

- 1 On a page, ➔ **Saved Pages** ➔ ➔ **Save** ➔
- Save appears only for savable pages.

- 2 Enter/edit title ➔

Opening Saved Pages

- 1 ➔ **Yahoo! Keitai** ➔ ➔ **Saved Pages** ➔



- 2 Select page ➔
- Corresponding page opens.

Opening Saved Pages Online

[Internet Page] ➔ **Saved Pages** ➔
 ➔ **Open List** ➔ ➔ Select page
➔

Advanced

- Deleting titles Editing titles Changing title order Sorting titles into folders Deleting pages Editing page titles Changing page order (And more on P.5-12 - 5-13)




Updating Blogs & News

Register RSS-compatible sites; view content updates without opening source sites. Transmission fees apply.

Subscribing to RSS Feeds

 appears for RSS-compatible sites.

 RSS Indicator
Available for PC Site Browser.

- 1 On a compatible page,  → Register In RSS Feed → 
- 2 Select feed →  (/) → Complete selection → 
- 3 Save → 
 - Choose **Yes** to update immediately or **No** and press .

Via RSS Icons

Use RSS icons to subscribe to RSS feeds from sites that are not RSS-compatible. Available for PC Site Browser.

- 1 On a page, select icon → 
- 2 Yes →  → Save → 

Checking Updates


Follow these steps to update all feeds:

- 1  → Yahoo! Keitai → 
- 2 PC Site Browser →  → RSS Feed → 



RSS Feed List

- 3 Reload All →  → 
- 4 Yes or No → 
- 5 Select feed → 



Title List

- 6 Select title → 
 - Information appears.

Updating Single RSS Feeds

[RSS Feed List] Select feed →  → Reload →  →  → Yes or No → 

Accessing Source Sites

[Title List] Select title →  → Select linked title →  → Yes →  →  → Yes or No → 

Advanced

-  Disabling feed updates
-  Sorting feeds into folders
-  Deleting feeds
-  Sorting feeds
-  Opening feed properties
-  Exchanging feeds with other devices
-  Sending feeds via mail (P.5-14)



Connecting & Browsing

■ General

Switching browsers	On a page, Convenient Functions Change to PC Browser or Change to Y! Keitai This Page or Linked Page Yes or No
Using previously entered URLs	Start Here Yahoo! Keitai See below
	Yahoo! Keitai Enter URL URL Entry Log Select URL
	PC Site Browser PC Site Browser Enter URL URL Entry Log Select URL

■ History

Deleting History records	Start Here Yahoo! Keitai History Change to PC Browser or Change to Y! Keitai See below
	One Record Select record Delete Yes
	All Records Delete All Enter Handset Code Yes
Opening History properties	Yahoo! Keitai History Select record Details
Sorting History records	Yahoo! Keitai History Sort By Domain or By Date

Sending History records via mail

- Yahoo! Keitai** **History** **Select record** **Send URL** **S! Mail or SMS** **Complete message**
- S! Mail Composition window opens automatically depending on character count.

■ Memory Operation

For PC Site Browser, perform the following sequence instead of **Browser Settings** .

PC Site Browser **PC Site Browser Settings**

Clearing cache (temporarily saved information)	Yahoo! Keitai Browser Settings Memory Operation Delete Cache Yes
Clearing cookies	Yahoo! Keitai Browser Settings Memory Operation Delete Cookies Yes
Clearing authentication information	Yahoo! Keitai Browser Settings Memory Operation Delete Auth Info Yes



Page Operations

■ Yahoo! Keitai & PC Site Browser

Using Web Search	On a page, → <i>Convenient Functions</i> → → <i>Web Search</i> → → Enter search text →
Searching current page	On a page, → <i>Convenient Functions</i> → → <i>Search</i> → → Enter search text → • Press to jump to next search result, if any.
Looking up copied words in dictionaries	On a page, → <i>Convenient Functions</i> → → <i>Copy & Search Dict.</i> → → Select first character → → Highlight text range → → Select dictionary → → <i>Search</i> → → Select word, etc. →
Saving files to Data Folder	On a page, → <i>Save Items</i> → → See below
	Files on Page Select file → → <i>Save</i> → → Enter name → → <i>Save here</i> → • Some files are saved automatically. • Confirm signal is strong, battery is adequately charged and that there is enough free memory beforehand.
	Background Images <i>Save Background Image</i> → → <i>Save</i> → → Enter name → → <i>Save here</i> →
Using linked info	Dialing Numbers On a page, highlight number → → <i>Call or Video Call</i> →
	Sending Messages On a page, highlight number or mail address → → <i>Create Message</i> → → <i>S! Mail or SMS</i> → → Complete message →

Copying text	On a page, → <i>Copy Text</i> → → Select first character → → Highlight text range →
Sending URLs via mail	On a page, → <i>Convenient Functions</i> → → <i>Send URL</i> → → <i>S! Mail or SMS</i> → → Complete message → • S! Mail Composition window opens automatically depending on character count.
Jumping to page top/bottom	On a page, → <i>Convenient Functions</i> → → <i>Jump In Page</i> → → <i>Page Top or Page Bottom</i> →
Opening function shortcuts	On a page, → <i>Help</i> →
Opening page properties	On a page, → <i>Convenient Functions</i> → → <i>Details</i> → → Select item →
Changing encoding to read garbled text	On a page, → <i>Settings</i> → → <i>Char-code</i> → → Select option →
Handling Flash® files	On a page, → <i>Convenient Functions</i> → → <i>Flash® Menu</i> → → See below Pausing/Playing <i>Pause, Resume or Replay</i> → Selecting Image Quality <i>Quality</i> → → Select option →
Updating page content	On a page, → <i>Reload</i> → • To update content in Saved Pages, open a page and follow the steps above.
■ Yahoo! Keitai	
Changing Font Size	On a page, (Long) to enlarge or (Long) to reduce



■ PC Site Browser

Switching view	On a page, [M] → <i>PC Screen or Small Screen</i> → [M] <ul style="list-style-type: none"> In Small Screen view, PC sites are redesigned to fit Display.
Zooming on pages (Zoom Factor)	On a page, [+3] (Long) to enlarge or [-1] (Long) to reduce
Jumping to specific locations	On a page, [5] (Long) → Quick Movement map appears → Select target location → [M]
Enlarging specific areas	On a page, point to area → [7] (Long) <ul style="list-style-type: none"> Pointed area is enlarged while [7] is pressed.

Internet Page Settings

■ Yahoo! Keitai & PC Site Browser

For PC Site Browser, perform the following sequence instead of *Browser Settings* → **[M]**.

PC Site Browser → **[M]** → *PC Site Browser Settings* → **[M]**

Disabling automatic image display/sound playback	[Start Here] → <i>Yahoo! Keitai</i> → [M] → <i>Browser Settings</i> → [M] → <i>Downloads</i> → [M] → See below
	Image Display <i>Images</i> → [M] → <i>Do not Show</i> → [M]
	Sound Playback <i>Sounds</i> → [M] → <i>Do not Play</i> → [M]
Changing Font Size	[M] → <i>Yahoo! Keitai</i> → [M] → <i>Browser Settings</i> → [M] → <i>Font Size</i> → [M] → Select size → [M]

Using pointer navigation	[Start Here] → <i>Yahoo! Keitai</i> → [M] → <i>Browser Settings</i> → [M] → <i>Cursor Settings</i> → [M] → See below
	Activating <i>Cursor Mode Settings</i> → [M] → <i>Normal Mode</i> → [M]
	Changing Pointer Speed <i>Speed Settings</i> → [M] → Select speed → [M]
Using Memory Card as primary download storage	[M] → <i>Yahoo! Keitai</i> → [M] → <i>Browser Settings</i> → [M] → <i>Download to</i> → [M] → <i>Prefer Card</i> → [M] <ul style="list-style-type: none"> Some files may be saved to handset regardless of this setting.

■ Yahoo! Keitai

Changing scroll unit	[M] → <i>Yahoo! Keitai</i> → [M] → <i>Browser Settings</i> → [M] → <i>Scroll Unit</i> → [M] → Select unit → [M]
----------------------	--

■ PC Site Browser

Hiding navigation map for continuous scroll	[M] → <i>Yahoo! Keitai</i> → [M] → <i>PC Site Browser</i> → [M] → <i>PC Site Browser Settings</i> → [M] → <i>Scroll Settings</i> → [M] → <i>Page Navigation</i> → [M] → <i>Off</i> → [M]
Changing scroll unit	[M] → <i>Yahoo! Keitai</i> → [M] → <i>PC Site Browser</i> → [M] → <i>PC Site Browser Settings</i> → [M] → <i>Scroll Settings</i> → [M] → <i>Scroll Unit</i> → [M] → Select unit → [M]
Hiding PC Site Browser messages	[M] → <i>Yahoo! Keitai</i> → [M] → <i>PC Site Browser</i> → [M] → <i>PC Site Browser Settings</i> → [M] → <i>Warning Message</i> → [M] → <i>PC Site Browser or Yahoo! Keitai</i> → [M] → <i>Off</i> → [M]



Streaming

Customizing streaming settings	<p>Start Here While streaming, Settings </p> <p> See below</p> <p>Changing Playback Size</p> <p>Display Size Select size </p> <ul style="list-style-type: none"> • Playback size may not change depending on file/stream. <p>Setting Backlight Status</p> <p>Backlight Select option </p> <ul style="list-style-type: none"> • Selecting Normal Settings applies Display Backlight settings. <p>Adjusting Sound Effects</p> <p>Sound Effects Select effect </p>
	<p>Start Here Streaming See below</p> <p>Resuming from Stopped Point</p> <p>Last Played </p> <p>Using Bookmarks</p> <p>Bookmarks Select title </p> <p>Using History</p> <p>History Select record </p>

Streaming from Media Player

Bookmarks

Deleting titles	<p>Start Here Yahoo! Keitai Bookmarks See below</p> <p>One Title</p> <p>Select title Delete Yes </p> <p>All Titles</p> <p> Delete All Enter Handset Code Yes </p>
	<p> Yahoo! Keitai Bookmarks Select title Edit Title: Enter title </p>
Editing titles	<p> Yahoo! Keitai Bookmarks Select title Edit URL: Edit </p>
Editing bookmarked URLs	<p> Yahoo! Keitai Bookmarks Select title Edit URL: Edit </p>
Sending bookmarked URLs via mail	<p> Yahoo! Keitai Bookmarks Select title Send As Message S! Mail or SMS Complete message </p> <ul style="list-style-type: none"> • S! Mail Composition window opens automatically depending on character count.
Changing title order	<p> Yahoo! Keitai Bookmarks Select title Change Order Select target location </p>
Opening title properties	<p> Yahoo! Keitai Bookmarks Select title Details </p>



Sorting titles into folders	<input type="button" value="Start Here"/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <input type="button" value=""/> Bookmarks → <input type="button" value=""/> → See below
	Creating Folders <input type="button" value=""/> → <i>Create Folder</i> → <input type="button" value=""/> → Enter name → <input type="button" value=""/>
	Moving to Folders Select title → <input type="button" value=""/> → <i>Move</i> → <input type="button" value=""/> → Select folder → <input type="button" value=""/> → <i>Move</i> → <input type="button" value=""/>
	Moving from Folders Select folder → <input type="button" value=""/> → Select title → <input type="button" value=""/> → <i>Move</i> → <input type="button" value=""/> → <i>Move</i> → <input type="button" value=""/>
	Renaming Folders Select folder → <input type="button" value=""/> → <i>Rename</i> → <input type="button" value=""/> → Enter name → <input type="button" value=""/>
	Deleting All Titles within a Folder Select folder → <input type="button" value=""/> → <input type="button" value=""/> → <i>Delete All</i> → <input type="button" value=""/> → Enter Handset Code → <input type="button" value=""/> → <i>Yes</i> → <input type="button" value=""/>
	Deleting Folders Select folder → <input type="button" value=""/> → <i>Delete</i> → <input type="button" value=""/> → Enter Handset Code → <input type="button" value=""/> → <i>Yes</i> → <input type="button" value=""/>

Saved Pages

Deleting pages	<input type="button" value="Start Here"/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <input type="button" value=""/> → <i>Saved Pages</i> → <input type="button" value=""/> → See below
	One Page Select page → <input type="button" value=""/> → <i>Delete</i> → <input type="button" value=""/> → <i>Yes</i> → <input type="button" value=""/>
Editing page titles	All Pages <input type="button" value=""/> → <i>Delete All</i> → <input type="button" value=""/> → Enter Handset Code → <input type="button" value=""/> → <i>Yes</i> → <input type="button" value=""/>
	<input type="button" value=""/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <i>Saved Pages</i> → <input type="button" value=""/> → Select page → <input type="button" value=""/> → <i>Rename</i> → <input type="button" value=""/> → Enter title → <input type="button" value=""/>
Changing page order	<input type="button" value=""/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <i>Saved Pages</i> → <input type="button" value=""/> → Select page → <input type="button" value=""/> → <i>Change Order</i> → <input type="button" value=""/> → Select target location → <input type="button" value=""/>
Opening page properties	<input type="button" value=""/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <i>Saved Pages</i> → <input type="button" value=""/> → Select page → <input type="button" value=""/> → <i>Details</i> → <input type="button" value=""/>
Switching page list view	<input type="button" value=""/> → <i>Yahoo! Keitai</i> → <input type="button" value=""/> → <i>Saved Pages</i> → <input type="button" value=""/> → Select page → <input type="button" value=""/> → <i>List View or Preview View</i> → <input type="button" value=""/>



RSS Feeds

Disabling feed updates	<ul style="list-style-type: none"> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → Select feed → ☰ → Manage RSS Feed → ● → Restrict Update → ●
Sorting feeds into folders	<p><small>Start Here</small> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below</p> <p>Creating Folders</p> <ul style="list-style-type: none"> ☰ → Manage RSS Feed → ● → Create Folder → ● → Enter name → ● <p>Moving to Folders</p> <ul style="list-style-type: none"> Select feed → ☰ → Manage RSS Feed → ● → Move → ● → Select folder → ● → Move → ● <p>Renaming Folders</p> <ul style="list-style-type: none"> Select folder → ☰ → Manage RSS Feed → ● → Rename → ● → Enter name → ● <p>Deleting Folders</p> <ul style="list-style-type: none"> Select folder → ☰ → Delete → ● → Enter Handset Code → ● → Yes → ●
	<p><small>Start Here</small> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below</p> <p>One Entry</p> <ul style="list-style-type: none"> Select feed → ☰ → Delete → ● → Yes → ● <p>All Entries</p> <ul style="list-style-type: none"> ☰ → Manage RSS Feed → ● → Delete All → ● → Enter Handset Code → ● → Yes → ● <ul style="list-style-type: none"> ● Alternatively, perform <i>Delete RSS Feed List</i> in Memory Operation (PC Site Browser Settings) to delete all feeds.
	<p><small>Start Here</small> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below</p>
	<p><small>Start Here</small> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below</p>
Deleting feeds	<p><small>Start Here</small> ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → See below</p> <p>One Entry</p> <ul style="list-style-type: none"> Select feed → ☰ → Delete → ● → Yes → ● <p>All Entries</p> <ul style="list-style-type: none"> ☰ → Manage RSS Feed → ● → Delete All → ● → Enter Handset Code → ● → Yes → ● <ul style="list-style-type: none"> ● Alternatively, perform <i>Delete RSS Feed List</i> in Memory Operation (PC Site Browser Settings) to delete all feeds.

Sorting feeds

- → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → ☰ → Manage RSS Feed → ● → Sort → ● → Select option → ●

Opening feed properties

- → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → Select feed → ☰ → Manage RSS Feed → ● → Details → ●

Exchanging feeds with other devices

Start Here ● → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → ☰ → Manage RSS Feed → ● → See below

Exporting All Feeds

- Export All → ● → Select storage media → ●

Importing (Adding Feeds)

- Import → ● → Select file → ● → As New Items → ● → Yes or No → ● → Yes or No → ●

Importing (Overwriting Existing Feeds)

- Import → ● → Select file → ● → Delete All → ● → Enter Handset Code → ● → Yes → ● → Yes or No → ● → Yes or No → ●

Sending feeds via mail

- → Yahoo! Keitai → ● → PC Site Browser → ● → RSS Feed → ● → Select feed → ☰ → Manage RSS Feed → ● → As Message → ● → Complete message → ☺



Security Settings

For PC Site Browser, perform the following sequence instead of **Browser Settings** ➔ [] .

PC Site Browser ➔ [] ➔ **PC Site Browser Settings** ➔ []

Disabling manufacture number auto send for authentication	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Manufacture Number ➔ [] ➔ Off ➔ []
Disabling referer information delivery to the Server	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Send ➔ [] ➔ Referer ➔ [] ➔ Not Send ➔ []
Enabling/disabling cookies	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Cookies ➔ [] ➔ Select option ➔ []
Selecting script execution option	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Script Settings ➔ [] ➔ Select option ➔ []
Hiding confirmations before entering/exiting secure pages	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Secure Prompt ➔ [] ➔ Do not Show ➔ []
Opening electronic certificates saved on handset	[] ➔ Yahoo! Keitai ➔ [] ➔ Browser Settings ➔ [] ➔ Security Settings ➔ [] ➔ Root Certificates ➔ [] ➔ Select certificate ➔ []

Changing validity of entered user ID/password

[] ➔ **Yahoo! Keitai** ➔ [] ➔ **Browser Settings** ➔ [] ➔ **Security Settings** ➔ [] ➔ **Keep Auth Info** ➔ [] ➔ **Select option** ➔ []

- **Per Browsing** retains entered user ID/password during browsing sessions. **On** retains such authentication information even after turning handset off.
- Authentication information may not be retained depending on the site.

Enabling/disabling Ajax (for asynchronous communication)

[] ➔ **Yahoo! Keitai** ➔ [] ➔ **Browser Settings** ➔ [] ➔ **Security Settings** ➔ [] ➔ **Restrict Ajax** ➔ [] ➔ **Select option** ➔ []

Resetting

For PC Site Browser, perform the following sequence instead of **Browser Settings** ➔ [] .

PC Site Browser ➔ [] ➔ **PC Site Browser Settings** ➔ []

Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.)

[] ➔ **Yahoo! Keitai** ➔ [] ➔ **Browser Settings** ➔ [] ➔ **Initialized Browser** ➔ [] ➔ **Enter Handset Code** ➔ [] ➔ **Yes** ➔ []

Restoring default handset settings

[] ➔ **Yahoo! Keitai** ➔ [] ➔ **Browser Settings** ➔ [] ➔ **Reset Settings** ➔ [] ➔ **Enter Handset Code** ➔ [] ➔ **Yes** ➔ []



Connecting & Browsing

? What is the bar at Display bottom?

- This is a data progress bar; the number beside it indicates transmitted (green) or received (red) data.

Page Operations

? Internet page does not open completely

- Portions of page content may not appear in tabbed browsing; close other tabs.

? Text overlaps

- The site may be designed for browsing on PCs; try *Tiny* font size.
- Text may overlap when Zoom Factor is used; adjust scale.

? Cannot access other functions while browsing the Internet

- When switching between Yahoo! Keitai and PC Site Browser (☐ appears), additional function activation is disabled; close either browser and retry.

