

S! Appli

Before Using S! Appli	15-2
Downloading S! Appli.....	15-2
Using S! Appli	15-3
Activating S! Appli.....	15-3
Terminate/Suspend & Resume.....	15-3
Managing Applications	15-4

Before Using S! Appli

S! Appli are Java™-based applications designed to run on SoftBank handsets. Download games and other real-time applications for use on handset.

- Separate subscription required to use downloaded applications (not required for pre-installed S! Appli).
- For usage on pre-installed applications, see Help menu for each S! Appli.

Note

- For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Network S! Appli

Network S! Appli requires Network connection.

- Transmission fees apply.

License Information

> [Main Menu](#) ▶ [S! Appli](#) ▶ [Information](#)

Downloading S! Appli

Download up to 100 S! Appli files to handset/Memory Card.

[Main Menu](#) ▶ [S! Appli](#) ▶ [S! Appli List](#)

1 *Download S! Appli*

Handset connects to the Network, and download site appears.

2 Select an S! Appli

Properties appear.

3 Follow onscreen instructions

4 Select a save location

Downloaded S! Appli is saved to Data Folder automatically.

- Download may take some time.

5 [YES] to activate

Downloaded S! Appli starts.


- To exit:  [NO]


Using S! Appli

Activating S! Appli


Main Menu ► S! Appli ► S! Appli List

1 Select an S! Appli

S! Appli starts and  appears.


- See application Help menu for usage information.
- Confirmation appears when selecting Network S! Appli.
- For a Memory Card S! Appli, press  to select **Memory Card** tab before Step 1.

Note

- Alternatively, **Main Menu ► Data Folder ► S! Appli ►** Select an S! Appli.
- Incoming transmissions pause S! Appli.
- View Blind ( P.1-26) is temporarily canceled while an S! Appli is active. To reactivate View Blind, terminate or pause S! Appli.



Tip

Settings

- Change Volume ● Backlight On/Off ● Deactivate Vibration
- Suspend S! Appli after Set Period of Inactivity ● Update S! Appli Information on Memory Card from Another Handset ( P.16-24)

Terminate/Suspend & Resume

Terminating/Pausing S! Appli

- 1 While running an S! Appli, 
- 2 **Terminate** or **Suspend**
 appears for a suspended application.

Resuming/Terminating Paused S! Appli

Main Menu ► S! Appli ► S! Appli List

1 **Resume** or **Terminate**

Resumed application starts from paused point.

Managing Applications

Moving S! Appli between Handset and Memory Card

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli → [Menu] → **Move**
 - Some S! Appli may not be moved to Memory Card.

Deleting S! Appli

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli → [Menu] → **Delete** → 
 - Some pre-installed S! Appli may not be deleted.

Viewing S! Appli Properties

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli → [Menu] → **Property**

Set Security Level while Running S! Appli

- Security Level cannot be set for some S! Appli.

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli → [Menu] → **Permission**
- 2 Select an item (See below)

Item	Operation/Description
Network Access	Connect to the Network
Auto Invocation	Activate S! Appli
Multimedia Recording	Activate Camera
Data Reading Access	Read data in Data Folder
Data Rewriting Access	Write/delete data in Data Folder
Location Access	Retrieve Location information

- 3 **Always Allowed, Ask First Time***, **Ask Every Time** or **Not Allowed**

* Confirmation appears the first time application is activated.