Tools



Osaifu-Keitai®	
About Osaifu-Keitai®	11-2
Using Osaifu-Keitai®	11-3
Activating IC Card Lock	11-3
S! GPS Navi	11-5
About S! GPS Navi	11-5
Activating a Navi Appli	11-5
Checking Current Location	11-5
Using Location Navi (Japanese)	
Life History Viewer	
Life History Viewer Window	
Viewing Data in Chronological Order	
Schedule	
Schedule Window	
Saving Events to Schedule	
Checking Saved Events	
Deleting Events	
To Do List	
Saving Tasks	
Checking Saved Tasks	
Deleting Tasks	
Text Memo	
Saving Text Memos	
Deleting Text Memos	
Deleting Text Wellios	11-14

Voice Memo	11-15
Recording Your Voice	11-15
Calculator	11-16
Alarm	11-17
Setting Alarm	11-17
Canceling Alarm	11-18
Bar Code Reader	11-19
Scanning Bar Codes	11-19
Checking Scanned Data	11-19
Text Reader	11-21
Scanning Text	11-22
Checking Scanned Text	11-22
Advanced Features	11-24
Osaifu-Keitai [®]	11-24
S! GPS Navi	11-24
Life History Viewer	11-24
Schedule	11-25
To Do List	11-25
Text Memo	11-26
Alarm	11-26
Bar Code Reader & Text Reader	11-27

11



About Osaifu-Keitai®

"Osaifu-Keitai®" is a range of IC Card-based services used by Osaifu-Keitai® compatible handsets. Make purchases using e-money or e-ticketing. Hold handset up to a reader/ writer to pay for your purchase.

Osaifu-Keitai® Terms

Osaifu- Keitai [®]	Cellular phone equipped with "FeliCa" contactless IC card technology for reading and writing data by holding phone up to a reader/writer.
IC Card	An IC chip embedded in Osaifu- Keitai®-compatible handsets.
Lifestyle- Appli	S! Applications to use Osaifu- Keitai [®] . Some applications are preinstalled.

Tip

- Data saved in IC Card varies by service content and usage history.
 - Procedures to delete IC Card data vary by Lifestyle-Appli.
- Contact Osaifu-Keitai® service providers for details.
- Softbank is not liable for damage from accidental loss or alteration of IC Card data or settings.
- IC Card data can be misused if your Osaifu-Keitai[®] compatible handset is lost or stolen. Softbank is not liable for any resulting damages.

Getting Started

Downloading Lifestyle-Appli

Download Lifestyle-Appli via Internet website.

· Lifestyle-Appli is saved to Data Folder.

Registrations/Settings

Activate Lifestyle-Appli to complete registration or customize settings.

 Make deposit into account, check payment records or balance, etc.

Note

 Keep a copy of service passwords, customer service contact, etc. in a separate place.

Downloading Lifestyle-Appli

- ⇒ Tools ⇔ ⇔
 Osaifu-Keitai ⇔ ⇔
 Lifestyle-Appli ⇔ ⇔
 Download LifeApp ⇔ ⇒ YES
 ⇒ ●
- - To Activate Lifestyle-Appli Right
 Away
 - ► To Activate Lifestyle-Appli Later NO ⇔ ●

Note

- Check the battery level before downloading Lifestyle-Appli. If the battery level is low, download may fail.
- If you replace USIM Card due to damage or loss, downloaded Lifestyle-Appli are no longer available.

Activating Lifestyle-Appli



Lifestyle-Appli List

2 Select a Lifestyle-Appli ⇒ ●

Note

 Keep a copy of service passwords, customer service contact, etc. in a separate place.

Tip

- Lifestyle-Appli is paused when a call arrives.
 When the call ends, a prompt with *Pause*,
 Resume, and *End* appears. Select *Resume* to resume the Lifestyle-Appli.
- To end Lifestyle-Appli: While running, ¬ ⇒ End ⇒ ●

Using Osaifu-Keitai®

Reader/Writer Transactions

- There is no need to activate a Lifestyle-Appli during transaction.
- Make sure battery is adequately charged.
- Transactions are possible even when handset power is off or during calls or Internet transmissions.
- 1 Hold logo up to a reader/writer ⇒ Check scan result on reader/writer display



Hold handset parallel to the reader/writer. Try moving handset around if recognition is slow.

Note

 Softbank is not liable for damages from accidental loss or alteration of IC Card data or settings.

Tip

 Data may be unreadable if a metal object, etc. is between logo and reader/writer.

Activating IC Card Lock

Use this function to restrict access to and prevent unauthorized use of Osaifu-Keitai®.

- 11 ⇔ Tools ⇔ ⇔
 Osaifu-Keitai ⇔ ⇒ IC Card
 Lock Set. ⇔ ●
- **2** Enter Security Code ⇒ ●



IC Card Lock Setting Window

Setting Operation of IC Card Lock after Power Off

[IC Card Lock Setting] window ⇔
IC Lock (Power-off) ⇔ ⊕ ⇔
Maintain or IC Card Lock ON ⇔

●

Tip

- Alternatively, to set IC Card Lock: In Standby, press and hold 3

Remote Lock

Call from a specified phone to activate Call Remote Lock.

Saving Numbers to Activate Call Remote Lock

- **2** Enter Security Code ⇒
- **3** ON ⇒



Call Remote Lock Setting Window

- 4 <Not Recorded> ▶
 - To Enter and Save Numbers

 ⇒ Enter phone numbers ⇒ ●
 - ► To save numbers from Phone Book.
 - Redial or Received calls

 (□) ⇒ Look-up Address ⇒ ⇒

- ⇒ Select a number 🖈 🗨
- ► To save a Payphone number

 Payphone → ●
- **5 ≥**

Tip

 To cancel Call Remote Lock: At Step 3, select OFF ⇒ ●

Activating Call Remote Lock

- 1 Using one of the specified phones, call handset
 Send Caller ID.
- 2 Hang up after handset receives the call
- Within three minutes, repeat

 1 2 twice

After the third Missed Call, IC Card Lock is set; a message announces IC Card Lock activation.

Note

 If series is interrupted by another call, Missed Call count is reset. Start over from the beginning.

More Features

Advanced

Osaifu-Keitai®

- Check Lifestyle-Appli Properties
- Check Memory Status
- Delete a Lifestyle-Appli
- Edit Call Remote Lock Numbers
- Delete Call Remote Lock Numbers

(P. 11-24)

Customize

Osaifu-Keitai®

- Set Illumination for IC Card
- Delete all Lifestyle-Appli
- Set Whether to Enable Opening from Reader/Writer

(P. 14-28)

Tools

About S! GPS Navi

Use this GPS feature to find your location and routes to destinations.

Note

- Positioning accuracy may be affected by GPS satellite/radio station signal strength.
- SoftBank accepts no liability for damages resulting from provided location information.
 S! GPS Navi applications may require
- subscription.

 Transmission fees apply, even when
- Transmission fees apply, even wher positioning fails.
- May incur high transmission fees.

Activating a Navi Appli



S! GPS Navi Window

Navi Appli ⇒ ● ⇒ Select an application ⇒ ●

Tip

To activate Navi appli from positioning for current location:
 [S! GPS Navi] window ⇒ Position Location ⇒ ● ⇒ Navi Appli ⇒ ● ⇒ Select an application ⇒ ●

Checking Current Location

Confirm your location by map.

1 [S! GPS Navi] window ⇒ Current Location ⇒ ●

A confirmation appears. Select **Send** to allow location to be sent.

To disable confirmation, select **No.**

To disable confirmation, select **No Confirmation**.

2 Send ⇒ ●

Note

 This function is unavailable when Send Location Info is set to Not Send; change setting to Confirm or Send.

Tip

Alternatively, to check current location:
 [S! GPS Navi] window ⇒ Position Location
 ⇒ ● ⇒ Read Map ⇒ ●

Using Location Navi (Japanese)

Search for someone's location. Also determine approximate location of lost handset.

- Separate subscription required.
- 1 [S! GPS Navi] window ⇔ NAVI Settings ⇔ ● ⇔ Location Navi ⇔ ● ⇔ Service Settings ⇔ ●

Follow onscreen instructions.



Advanced

S! GPS Navi

- Add Current Location to Phone Book
- Check Location Logs
- Use Location Logs
- Delete Location Log Records

(P. 11-24)



S! GPS Navi


- Set Default Navi Appli
- Begin Positioning Before/After Activating Map
- Save Map URL
- Edit URL Name
- Delete Map URL
- Set Map URL
- Set Location Information Send Method


(P. 14-28)

Life History Viewer

View activities in chronological order.

Life History Viewer Window





Date and time Still image, image, movie: Shooting, Updating or Saving date and time Schedule: Start date and time Mail message (send/receive) history: Received/Sent date and time Title Still image, image, movie: Title Schedule: Schedule name Mail message (send/receive) history: Sender for received mail

qiT

 Still images and images in JPEG format can be browsed.

Receiver for sent mail

Life History Viewer

Viewing Data in Chronological Order

MEN

→ Tools

→

■ Life History Viewer ⇒ •



Life History Viewer Window

To reduce/enlarge scale of time axis, press or 📆.

Select a data item ⇒ •



Life History Viewer Closeup Window

3 ₪

The function corresponding to the data type is activated and the data is opened. More Features

Advanced

Life History Viewer

- Hide Some Items in Life History Viewer
- Update Life History Viewer

(P. 11-24)


Schedule

Save future events to Schedule. Set alarm to be activated at a specified time with message and animation appearing to remind you of the event. Saved events can be checked from Schedule window.

Schedule Window



Schedule Window



Saving Events to Schedule



Event Edit Window

- 4 Ø ⇒ ⇒ Enter start/end date and time ⇒ ●

Schedule

Folders are unavailable when *Clock Alarm Tone*, *Voice Announce* or *OFF* is selected.

- 8 📾 ⇒ ⇒ Enter place ⇒ •

Entered content appears when alarm sounds or vibrates.

Alarm Notification

When the set time arrives, alarm sounds and animation appears (on Display) for approximately five minutes.

When handset is closed, press $\overline{\mathbb{I}}_{\text{uuen}}$ to stop alarm. When handset is open, press any key to stop alarm. Press any key again to end notification message.

Tip

- If the set alarm time arrives during a call, alarm tone sounds through earpiece.
- If a call arrives while alarm is sounding, alarm stops.

Adding Holidays

- 1 [Schedule] window ⇒ 🖾 ⇒

 Holiday ⇒ ●
- 2 ∅ ⇒ Enter year, month and date ⇒ •

- **5 ≥**

Setting Secret Entries

Set private events as secret entries.

- Activate Secret Mode or Secret Data Only Mode beforehand. (P. 4-7)
- Events set as secret entries are viewable only in Secret Mode or Secret Data Only Mode. (P. 4-7)
- 1 [Event Edit] window ⇒ Enter items ⇒ ☑

Tip

Checking Saved Events



Schedule Window

Press 🖅 to toggle between weekly and monthly view.




Event List

Tools

Schedule

Select an event ⇒ ●



Event Details

Deleting Events

To Delete One Event

- In [Event List], select an event or [Event Details] ⇒ 🕞
- Delete ⇒ ⇒ Delete This ⇒ **⇒ YES ⇒ (•**)

To Delete Multiple Events

- In [Schedule] window, select date, [Event List] or [Event Details] ⇒ (F)
- Delete ⇒ Delete selected \Rightarrow \bigcirc

- 3 Select an event ⇒ Repeat this step to specify other events.

To Delete All Events Prior to a **Specified Date**

- 1 In [Schedule] window, select date, [Event List] or [Event Details] ⇒ (F)
- Delete ⇒ ⇒ Delete Past ⇒ ⇒ Select an item ⇒ • YES ⇒ \odot

More Features

Advanced

Schedule

- Sort Events by Icon
- Check Number of Saved Events
- Edit an Event
- Copy an Event
- Delete All Events
- Reset Holidavs
- Search Information by Keyword

(P. 11-25)

Customize

Alarm

- Set Priority at Alarm Notification Time
- Change Alarm Tone

(P. 14-2)

Save tasks to To Do List Set Alarm to remind vou of deadlines.

Saving Tasks

- MENU ⇒ Tools ⇒ → To Do List ⇒
- √ New ⇒
 - To Edit a Saved Task ⇒ Select a task ⇒ 🕞 ⇒ Edit ⇒ •



Task Edit Window

- Task appears when alarm time arrives.
- - To Enter Date Manually Enter Date ⇒ ● => Enter due date and time 🖈 🖲
 - To Enter Due Date from Calendar Choose Date ⇒ • Select a date on Calendar \Rightarrow • Enter date/time \Rightarrow \bigcirc

- To Cancel a Due Date No Date 🖈 🖲
- 5 P ⇒ ⇒ Select a priority level \Rightarrow \bigcirc
- 7 🔼 ⇒ 💿 ⇒ Select an alarm notification option ⇒ • (⇒ Enter time)
- 8 🕟 ⇒ 💿 ⇒ Select an alarm tone type ⇒ ● (⇒ Select a folder ⇒ ● ⇒ Select an alarm tone ⇒ •) ⇒

Folders are unavailable when Clock Alarm Tone. Voice Announce or OFF is selected

Alarm Notification

When the set time arrives, alarm sounds and animation appears (on Display) for approximately five minutes.

When handset is closed, press Julan to stop alarm. When handset is open, press any key to stop alarm. Press any key again to end notification message.

qiT

- If the set alarm time arrives during a call, alarm tone sounds through earpiece.
- If a call arrives while alarm is sounding, alarm stops.

Checking Saved Tasks

1 MEND ⇒ Tools ⇒ ● ⇒ To Do List ⇒



Task List

Select a task ⇒ •



Task Details

Tip

• Overdue tasks are indicated by red status icons (e.g. Plan).

Deleting Tasks

To Delete One Task

- In [Task List], select a task or [Task Details] ⇒ 📵
- Delete ⇒ ⇒ Delete This ⇒ ⇒ YES ⇒ ●

To Delete Multiple Tasks

- 1 [Task List] ⇒ 🕞
- Delete ⇒ ⇒ Delete selected ⇒ ●
- 3 Select a task ⇒ ●
 Repeat this step to specify other tasks.

To Delete All Completed Tasks

- 1 [Task List] ⇒ 🕞

More Features

Advanced

To Do List

- Sort Tasks by Category
- Change Order of Tasks
- Set Task Status
- Delete All Tasks

(P. 11-25)

Customize

Alarm

- Set Priority at Alarm Notification Time
- Change Alarm Tone

(P. 14-2)

Saving Text Memos



Text Memo List

- 2 <Not Recorded> ⇒ 🖾 ⇒ Enter content ⇒
 - To Edit a Saved Text Memo

 ⇒ Select a text memo ⇒ ☞ ⇒ Edit content ⇒ ●

Deleting Text Memos

To Delete One Text Memo

- 1 [Text Memo List] ⇒ Select a text memo ⇒ ♠
- Delete ⇒ ⇒ Delete This ⇒ ⇒ YES ⇒ ●

To Delete Multiple Text Memos

- 1 [Text Memo List] ⇒ 🕞
- Delete ⇒ ⇒ Delete selected ⇒ ●
- 3 Select a text memo

 Repeat this step to specify other text memos.



Advanced

Text Memo

- Save a Text Memo to Schedule
- Sort Text Memos by Category
- Check Text Memo Information
- Delete All Text Memos

(P. 11-26)



Voice Memo

Record voice for up to 20 seconds. Handset makes single recording and overwrites each time.

• See P. 3-6 and P. 3-20 for playing and deleting a recorded voice memo.

Recording Your Voice

- \Rightarrow \bigcirc
- **2 YES** ⇒ **●** ⇒ Record your voice Speak into microphone after short beep sounds through earpiece. When remaining recording time reaches five seconds, a short beep sounds. When recording is finished, two short beeps sound. To stop recording, press .

Tip

- · Recording stops automatically when a call arrives, alarm goes off or another function is activated.
- See P. 3-5 for details on recording the other party's voice.

Calculator

- 2 Enter numbers with Keypad ⇒ Enter +, -, × or ÷ with Multi Selector
 - To Calculate Negative Numbers

 ⇒ ⓒ ⇒ Enter numbers with keypad ⇒
 Enter +, -, × or ÷ with Multi Selector
- Result appears.

Operations Enter Number 0 - 9 **(** + (Add) 0 (Subtract) ◎ × (Multiply) **Q** ÷ (Divide) • = (Equal) **Decimal Point** Cancel Calculation CLEAR (AC) CLEAR (C) Clear Number

Tip

• If the calculation result exceeds 10 digits, .E appears.

Setting Alarm





Alarm List

2 Select an alarm ⇒ 🖾



Alarm Setting Window

- The state of the Title appear in Alarm message.
- $\square \Rightarrow \bigcirc \Rightarrow$ Enter time $\Rightarrow \bigcirc \bigcirc$

- 5 🗟 ⇒ 🏵 ⇒ 1 Time, Daily (📵) or Select Day (W) ⇒ • (⇔ Put checkmarks to days of the week ⇒ **∞**/)
- Select an alarm tone type ⇒ • (⇒ Select a folder ⇒ • ⇒ Select an alarm tone ⇒ ●) Folders are unavailable when Clock Alarm Tone. Voice Announce or OFF is selected
- 7 😭 ⇒ 🏵 🖈 🛇 to adjust volume 🖈 \odot
- 8 ₩ ⇒
 - To Set Snooze ON ⇒ ● ⇒ Enter number of activation times > Enter time interval
 - To Cancel Snooze **OFF** ⇒ • Enter ringing duration
- 9 🙀 ⇒ ON or OFF ⇒ 🖈

■ To View Alarm Entries

Select an entry \Rightarrow 💿



Alarm Details

Alarm Operations

When the set time arrives, alarm activates and animation appears (on Display). When Auto Power is set to ON (Alarm Setting window). handset automatically turns on for alarm. Press Julen to stop alarm tone with handset closed. Press any key to stop alarm tone with handset open.

When Snooze is set to OFF, press any key again to cancel alarm and return to previous window. When Snooze is set to ON, alarm tone repeats at the set interval. Press to cancel Snooze.

Note

- When *Keypad sound* is set to *ON*, two short beeps sound if you:
- Press a key, after canceling alarm (Snooze not set).
- Press 🖚 while snooze is still set.
- Set the auto power-on function to OFF in Alarm Setting window and turn off handset, when you are near high-precision electronic devices or devices using weak signals, on an aircraft or in a hospital where handset use is prohibited.
- If a call arrives while alarm is sounding, alarm stops.
- If the alarm activation time comes during a call, alarm sounds from Earpiece. Snooze does not work even if it is set to ON.

More Features



Alarm

- Cancel All Alarms
- Edit Alarm Settings

(P. 11-26)



Alarm

- Set Priority at Alarm Notification Time
- Change Alarm Tone

(P. 14-2)

응 11

Canceling Alarm

1 [Alarm List] ⇒ Select an alarm 🗢



Each time you press 🔀, alarm toggles between ON and OFF.

Tip

 Alarm settings are retained even if alarm is canceled.

Bar Code Reader

JAN codes and QR codes can be scanned by Bar Code Reader using handset camera.

About JAN & QR Codes

JAN Code

A bar code made of vertical lines (bars) with different widths and spaces in between, representing numbers. Handset can scan 8-digit (JAN8) and 13-digit (JAN13) bar codes.

OR Code

A two-dimensional code representing alphanumerics, kanji, kana or pictographs. Some QR codes are made up of several data areas that are scanned as individual OR codes and then automatically combined as one QR code.

Scanning Bar Codes

- Position handset camera at a distance of 10 cm. from the bar code
- MENV ⇒ Tools ⇒ Bar Code Reader ⇒ •

Prame the bar code in the scan viewfinder



Bar Code Scanning Window

Scanning starts automatically.

r.¬. Land I indicate the corners of the scan viewfinder.

Press to toggle zoom. ■ To Cancel Scanning

- \Rightarrow \bigcirc \Rightarrow \bigcirc \bigcirc \bigcirc \bigcirc
- To Scan a OR Code Made of Several Data Areas (OR Codes)

⇒ OK ⇒ • (twice) ⇒ Scan a OR code Repeat this step to scan other OR codes. All component QR codes must be scanned in order to access or save scanned data on handset

■ To Turn On Light

□ 1₂₊₋

Press | again to turn off.

- Check scanned data
 - To Discard Scanned Data CLEAR > YES >
- **OK** ⇒ **(**

qiT

- A JAN code/QR code must be accurately focused and be enlarged to fill the scan viewfinder
- · Scanning may take a while.
- · Some bar codes may not be scanned depending on the size, version or print quality, or due to scratches, stains, damage or the reflection of light.

Checking Scanned Data

[Bar Code Scanning] window \Rightarrow □ ⇒ Reading Data List ⇒ ●



Scanned Bar Code Data List



Bar Code Reader

2 Select an entry ⇒ ●



Scanned Bar Code Data Details

Tip

 Characters that are not supported by Bar Code Reader are replaced with spaces (blanks).





Using Scanned Data

- Make a Call
- Compose a Message
- Access the Internet
- Save to Phone Book
- Save to Friorie Book
 Save a Bookmark
- Copy Text
- Edit Title of Scanned Data
- Delete Scanned Data


(P. 11-27)


ools

Text Reader

Use Text Reader to scan printed text.

Scan Modes		
Card read	Scan name, phone number, e-mail address, postal code, address and memo printed on business cards, and save all scanned data collectively as a Phone Book entry.	
Compose message	Scan address, subject or message text, and open Composition (S! Mail) window with the address, subject or message text entered.	
URL	Scan URL, and access the page or save the URL to Bookmark.	
Mail address	Scan e-mail address, and compose an S! Mail to the address.	
Phone number	Scan phone number, and make a call to the number.	
Free memo	Scan Japanese or English text, and save the text to Text Memo.	





Text Reader

Scanning Text

Position handset camera at a distance of 10 cm. from the text

<Example> Scanning in Card Read mode

- \Rightarrow \odot
- 2 New ⇒ ⇒ Card Read ⇒ ●



Text Scanning Window

⊙ ⇒ Select a category icon ⇒ Frame text in the scan viewfinder Press 🛇 to toggle zoom in and zoom out.

The text is scanned. The scanned text appears.

■ To Rescan the Same Text CLEAR > YES >

■ When Scanned Text Overflows Scanned Text Field

⇒ 🛇 to scroll the field

■ To Scan Following Text

⇒ ● Frame text in the scan viewfinder (include several scanned characters of the preceding text) \Rightarrow ①

■ To Scan Another Item

⇒ • Select a category icon ⇒ Frame text in the scan viewfinder \Rightarrow 💿

■ To Turn On Light

□ 1 2+-

Press Again to turn off.



Tip

- · Text must be accurately focused and be enlarged to fill the scan viewfinder.
- When *Processing* ··· appears, do not move handset.
- · Handwritten text is not recognized.
- Text may not be recognized correctly when: Faxed or copied text is scanned.
- Decorated characters are scanned.
- Spaces between characters are uneven.
- Text is indistinguishable from the background.
- Ambient lighting is inappropriate.

Checking Scanned Text

MN ⇒ Tools ⇒ ● Text Reader ⇒ • Reading Data List ⇒ •



Scanned Text List

Select an entry ⇒ ●



Scanned Text Details







Scanning Text

- Correct Scanned Text
- Edit Scanned Text
- Set Printing Status of Text
- Set Guidance ON/OFF
- Set Vertical/Lateral Scan

(P. 11-27)

Using Scanned Data

- Make a Call
- Compose a MessageAccess the Internet
- Access the internet
- Save to Phone Book
- Save a Bookmark
- Search Phone Book
- Save a Text Memo
- Copy Text
- Delete Scanned Data

(P. 11-27)



Start Here

[Lifestyle-Appli List]P. 11-3 [Call Remote Lock Setting] window... P. 11-4

Check Lifestyle-Appli Properties

【Lifestyle-Appli List】

→ Select a Lifestyle-Appli

→ Properties

→ ●

Check Memory Status

[Lifestyle-Appli List] \Rightarrow \bigcirc Memory Info \Rightarrow \bigcirc

Delete a Lifestyle-Appli

[Lifestyle-Appli List] ⇒ Select a Lifestyle-Appli ⇒ 📵 ⇒ **Delete** ⇒ ● ⇒ **YES** ⇒ ●

Edit Call Remote Lock Numbers

[Call Remote Lock Setting] window ⇒ Select phone number ⇒ ● ⇒ Change phone number ⇒ ● ⇒ YES ⇒ ● ⇒ ⑤

Delete Call Remote Lock Numbers

[Call Remote Lock Setting] window ⇒ Select phone number ⇒ ® ⇒ Delete this or Delete All ⇒ ● ⇒ YES ⇒ ●

S! GPS Navi

Start Here

[S! GPS Navi] window......P. 11-5

Add Current Location to Phone Book

[S! GPS Navi] window \Rightarrow Position Location \Rightarrow $\textcircled{o} \Rightarrow$ Add to Phonebook \Rightarrow $\textcircled{o} \Rightarrow$ Phone \Rightarrow $\textcircled{o} \Rightarrow$ Select add method \Rightarrow $\textcircled{o} \Rightarrow$ Search Phone Book \Rightarrow Select Phone Book \Rightarrow $\textcircled{o} \Rightarrow$ (twice)) \Rightarrow Edit items \Rightarrow $\textcircled{o} \Rightarrow$ (\Rightarrow YES or NO \Rightarrow o) (\Rightarrow Enter entry number \Rightarrow o)

Check Location Logs

Use Location Logs

[S! GPS Navi] window \$\ightharpoonup Location Logs \$\ightharpoonup \ightharpoonup \ightharpoonu

Delete Location Log Records

- To Select Delete This
 ⇒ Delete This ⇒ ⊙ ⇒ YES ⇒ ⊙
- To Delete selected
 ⇒ Delete selected ⇒ ⇒ Select logs ⇒
 ⇒ □ ⇒ YES ⇒ ●
- To Delete All
 ⇒ Delete All
 ⇒ © ⇒ Enter Security Code
 ⇒ ⊙ ⇒ YES ⇒ ⊙

Life History Viewer

Start Here

Hide Some Items in Life History Viewer

Update Life History Viewer

[Life History Viewer] window / [Life History Viewer Closeup] window ⇒ 🕞 🖘 Reload 🖈 🖲

Schedule

Start Here

[Schedule] window	P. 11-9
[Event Edit] window	P. 11-9
[Event List]	P. 11-10
[Event Details]	P. 11-11

Sort Events by Icon

[Schedule] window. [Event List] or [Event Select an icon 🖈 📵

Check Number of Saved Events

[Schedule] window ⇒ 🕞 ⇒ No. of Schedules 🖈 🖲

Edit an Event

[Event List] / [Event Details] (⇒ Select an event) 🖈 🖾 🖈 Edit each item 🖈 🖾

Copy an Event

[Event List] / [Event Details] ⇒ 🕞 ⇒ Copy ⇒ • Enter start/end date and time ⇒ ● ⇒ Edit each item ⇒ 🖾 Repetition setting of an event is canceled when it is copied.

Delete All Events

[Schedule] window. [Event List] or [Event Details]

→ Pelete → Delete All ⇒ ● ⇒ Enter Security Code ⇒ ● ⇒ Select an item ⇒ ● YES ⇒ ●

Reset Holidays

[Schedule] window ⇒ 🕞 ⇒ Reset Holiday ⇒ • YES ⇒ •

Search Information by Keyword

[Event Details] ⇒ /🕞 ⇒ Ouick Search ⇒

- To Enter a Keyword ⇒ Enter Keyword ⇒ ● => Enter keyword ⇒ () ⇒ Y? or Browser ⇒ () ⇒ Select an item from search results \Rightarrow •
- To Enter a Keyword with Ouote Keyword Ouote Keyword \Rightarrow Ouote Subject. **Details** or **Place** ⇒ • Move cursor to head of keyword to search \Rightarrow \bigcirc \Rightarrow Move cursor to last character of keyword to search ⇒ () ⇒ Y' or Browser ⇒ () ⇒ Select item from results ⇒ •
- To Select a Keyword from Previous Searches ⇒ History ⇒ • Select keyword ⇒ • ⇒ Y! or Browser ⇒ Select item from results

To Do List

Start Here

[Task List]P. 11-12 [Task Details]P. 11-12

Sort Tasks by Category

[Task List] ⇒ 🕞 ⇒ Category Display ⇒ Select a category ⇒ ●

Change Order of Tasks

[Task List] \Rightarrow \bigcirc \bigcirc Sort/Filter \Rightarrow \bigcirc \Rightarrow Select a criterion \Rightarrow \bigcirc

Set Task Status

[Task List] / [Task Details] (

Select a task)

Change Status

Select a status

Select a status

Select a

- The set status is indicated by the status icon in Task List and in Task Details.
- When *Completion* is set as status, enter the completion date.

Delete All Tasks

[Task List] \Rightarrow \bigcirc \bigcirc Delete \Rightarrow \bigcirc \Rightarrow Delete All \Rightarrow \bigcirc \Rightarrow Enter Security Code \Rightarrow \bigcirc \Rightarrow YES \Rightarrow \bigcirc

Text Memo

Start Here

[Text Memo List] P. 11-14

Save a Text Memo to Schedule

[Text Memo List] ⇒ Select a text memo ⇒ □ ⇒ Edit Schedule ⇒ ● ⇒ Enter each item ⇒ ▷

Entered text appears in the Details field when Event Edit window is opened.

Sort Text Memos by Category

[Text Memo List]

Select a text memo

G

Category

Select a category

Select a category

Select a category

Check Text Memo Information

【Text Memo List】 ⇒ Select a text memo ⇒ (□) ⇒ Text Memo Info ⇒ (●)

Delete All Text Memos

[Text Memo List] \Rightarrow \bigcirc \bigcirc Delete \Rightarrow \bigcirc \Rightarrow Delete All \Rightarrow \bigcirc \Rightarrow Enter Security Code \Rightarrow \bigcirc \Rightarrow YES \Rightarrow \bigcirc

Alarm

Start Here

Cancel All Alarms

[Alarm List] / [Alarm Details] ⇒ ♠

Release All ⇒ ● ⇒ YES ⇒ ●

Edit Alarm Settings

[Alarm List] / [Alarm Details] (⇒ Select an alarm) ⇒ □ ⇒ Edit each item ⇒ □



Bar Code Reader & Text Reader

Start Here

[Scanned Bar Code Data List]	Ρ.	11-19
[Scanned Bar Code Data Details]	P.	11-20
[Text Scanning] window	P.	11-22
[Scanned Text List]	P.	11-22
[Scanned Text Details]	P.	11-22

Scanning Text

Correct Scanned Text

[Text Scanning] window ⇒ Scan text ⇒ ⊕ to move cursor to the character you want to correct ⇒ Press the number key corresponding to the correct character on the suggestion list

Press * to toggle upper case and lower case.

Edit Scanned Text

[Text Scanning] window ⇒ Scan text ⇒

☐ ⇒ Edit ⇒ ● ⇒ Edit text using keypad

To cancel editing and return to scanned text, press ♠, select *Select Recog. Data* and then press ♠.

Set Printing Status of Text

[Text Scanning] window ⇔ 📵 ⇔ NEGA/POSI Mode ⇔ 🏵 ⇔ Auto setting, Positive Fix or Negative Fix ⇔ ⑥

Set to Positive Fix when dark-colored text is

printed on a light-colored background.
Set to **Negative Fix** when light-colored text is printed on a dark-colored background.

Set Guidance ON/OFF

[Text Scanning] window ⇒ 🗐 ⇒

Guidance OFF or Guidance ON ⇒ •

Set Vertical/Lateral Scan

[Text Scanning] window ⇒ 🗗 ⇒ Vertical Writing or Lateral Writing ⇒ 🌘

Using Scanned Data

Make a Call

[Scanned Bar Code Data Details] / [Scanned Text Details] ⇒ Select a phone number ⇒ ⓐ ⇒ Dialing ⇒ ⑥ ⇒ Voice Phone or Video Call ⇒ ⑥ ⇒ Dial ⇒ ⑥ ⇒ Talk ⇒ □ to end call

Compose a Message

[Scanned Bar Code Data Details] / [Scanned Text Details]

⇒ Select an e-mail address

⊕ ⇔ Create S! Mail

⊕ ⊕ Compose and send S! Mail

Access the Internet

[Scanned Bar Code Data Details] / [Scanned Text Details]

Select a URL

□ □ □

Internet □ □ □ YES □ □

Save to Phone Book

[Scanned Bar Code Data Details] / [Scanned Text Details]

⇒ Select an item

• □ ⇒

Add to Phone Book
• ●

- To Select Phone
- ightharpoonupPhone ightharpoonupightharpoonup Select store method ightharpoonupightharpoonup Select an entry ightharpoonupightharpoonupightharpoonup (twice)) ightharpoonup Edit each item ightharpoonupightharpoonupightharpoonup (ightharpoonup) (ightharpoonupEnter entry number ightharpoonupightharpoonup)
- To Select USIM

Advanced Features

Save a Bookmark

[Scanned Bar Code Data Details] / [Scanned Text Details] \Rightarrow Select a URL \Rightarrow \bigcirc \Rightarrow Add Bookmark \Rightarrow \bigcirc (twice) \Rightarrow Select a folder \Rightarrow \bigcirc

Search Phone Book

[Scanned Text Details] \Rightarrow Select an item \Rightarrow \bigcirc \Rightarrow Search Phone Book \Rightarrow \bigcirc \Rightarrow Search Phone Book

Save a Text Memo

Copy Text

Edit Title of Scanned Data

[Scanned Bar Code Data List] \Rightarrow Select an entry \Rightarrow $\textcircled{\tiny{1}} \Rightarrow$ Edit Title \Rightarrow $\textcircled{\tiny{2}} \Rightarrow$ Edit title \Rightarrow $\textcircled{\tiny{3}}$

Delete Scanned Data

[Scanned Bar Code Data List] / [Scanned Text List] ⇒ Select an entry ⇒ √

| □

- To Select Delete This
 - ⇒ Delete This ⇒ YES ⇒ •
- To Select Delete All
 - ⇒ *Delete All* ⇒ **⊙** ⇒ Enter Security Code
- \Rightarrow \bigcirc \Rightarrow YES \Rightarrow \bigcirc