

Text Entry

Text Entry	3-2
Entering Text	3-3
Entering Characters	3-3
Pictographs & Symbols	3-4
Templates.....	3-5
Additional Features.....	3-5
Conversion Methods (Japanese)	3-6
Predictive Conversion	3-6
Converting Hiragana to Katakana/Alphanumerics.....	3-7
Conversion	3-8
Editing Text	3-9
Deleting & Replacing	3-9
Copy/Cut/Paste.....	3-9
User's Dictionary	3-10
Saving User's Dictionary Entries	3-10
Download Dictionary	3-10
Activating Downloaded Dictionaries.....	3-10

Text Entry

Enter alphanumerics, hiragana, kanji, katakana, symbols and pictographs.

- Three types of character input methods are available: Mode 1 (5-touch), Mode 2 (2-touch), Mode 3 (NIKO-touch)

In this guide, examples are described in Mode 1 (5-touch).

Mode 2 (2-touch)/Mode 3 (NIKO-touch)


Press two numeric keys to enter a character.

- List of Key Assignments (☞P.19-15 to 17)

Help

Help describes text entry operations.

> In text entry window, **[Menu]** → **Help** → Select an item




① Character Input Methods	Operations
2 : Mode 2 (2-touch) ☞: Mode 3 (NIKO-touch) <ul style="list-style-type: none"> No icon appears for Mode 1 (5-touch). 	Press and hold ☞[Mode]
② Input Modes*	Operations
abc : Alphanumerics 123 : Numbers 漢: Kanji (hiragana) ｶ: Katakana	☞[Mode]
③ Double-byte/Single-byte*	Operations
1/1: Double-byte 1/2: Single-byte	☞[Menu] → 2bytes character (1byte character)
④ Remaining/Maximum Bytes in Message	

* Operations in Mode 3 (NIKO-touch): ☞P.19-17

Entering Text


Entering Characters


Example: Enter 鈴木


- 1 In alphanumeric mode,  twice to switch to kanji (hiragana) mode

す:  three times


ず: * →  three times → 


き:  twice


* When the next character is on the same key, press  first to move cursor.















- 2  to enter Predictive Candidates List

- To change word before converting, press .
- There are four types of word suggestion lists: **Predictive Candidates**, **Conversion Candidates**, **Context Forecast** and **abc/123/Kana Candidates** (ㄱ P.3-6)



- 3  to select 鈴木

Other Input Functions


Enter katakana/ alphanumerics	Press  [Mode] several times to select an input mode → Enter characters
Enter small kana (つ, っ, etc.)	Enter a character →  to convert to small character ● Alternatively, press a key repeatedly to enter an assigned small kana.
Enter upper case characters	Enter a character →  ● Alternatively, press a key repeatedly to enter an assigned upper case character.
Add * or °	Enter a character to add ° or ° →  for ° or  twice for ° ● In single-byte katakana mode, ° and ° are entered as a single-byte character.
Insert line break	Press  [Line FD] to insert line breaks in text
Insert space at end of text	
Insert space within text	Press  repeatedly until single-byte space appears*, or  [Menu] → Pictograms/symbols → Space to enter a space (Double-byte (single-byte) space is entered in 2 bytes (1 byte) input mode.)
Toggle characters in reverse order	 [Rev] Example: From c, press to toggle as follows: c → b → a → 2...
Move cursor to beginning/ end of sentence	 [Menu] → Jump → To beginning or To end
Undo	 [Undo]

* Space cannot be entered within text in number mode by following the steps above. Use symbol list.

Pictographs & Symbols

- Pictographs do not appear in messages sent to incompatible SoftBank handsets or e-mail.

1 Pictographs

In kanji (hiragana)/katakana/alphanumeric mode,  SoftBank pictograph list appears.


Symbols

Press and hold  Single-byte symbol list appears.



2 to select a pictograph or symbol

- Symbol List:  P.19-18










Note

- Alternatively, follow the steps to access pictograph or symbol:
 [Menu] → *Pictograms/symbols*
- List Log may appear first.

Entering Cross-carrier Pictographs

Press  or  to toggle lists (Universal pictograph list, Log, Full pictograph list and My Pictograms).

Functions Available in Pictograph/Symbol List

Enter same pictograph or symbol again	 [Cont.]
Toggle pictograph/symbol list	 [Pict./Symbol]
Jump to previous/next page	
Toggle full screen/standard screen	
Toggle double/single-byte symbol and log [symbol list only]	 [1byte/2bytes/Log] ●  to toggle in reverse
Toggle pictograph lists [pictograph list only]	 [Univrsl. ¹ /Full/My Pict. ² /NxtMyPic ² /Log] ●  to toggle in reverse
Close list	


¹ In S! Mail Subject/Text/Signature field or Subject field for Auto-sort Setting only

² In S! Mail Text field only


Templates

Insert templates (greetings, URLs, emoticons) or edit preinstalled templates.

Inserting Templates

- 1 In text entry window, press and hold 
 - Not available in number mode.
- 2 Select a category → Select a template

Note

- Alternatively, in a text entry window,  [Menu] → *Input assistance* → *Templates* to enter a template

Editing Templates

Main Menu ► Tools ► Templates/Users Dic. ► Templates

- 1 Select a category
- 2 Highlight a template →  [Edit] → Edit template


Reset Edited Templates





- > After Step 1, (highlight a template →)  [Menu] → *Reset this* or *Reset all* (→ For *Reset all*, enter Phone Password) → *YES*

Manage Template Folders

- > In Step 1, highlight a category →  [Menu] → *Edit folder name* → Edit folder name
- To reset folder name,  [Menu] → *Reset name* → *YES*

Additional Features

- 1 In text entry window,  [Menu] → *Input assistance*
- 2 Select an item (See below)


Item	Operation/Description
Kuten Code	Enter a character code ( P.19-19) > Enter a character code (4 digits)
Input date/time	Select a style to enter date/time > Select a display style → Enter date/time
Quote phone book	Quote Phone Book entry detail > Select an entry → Check item(s) to quote →  [Finish]
Quote acct detls	Quote Account Details > Enter Phone Password → Check item(s) to quote →  [Finish]
Bar code reader	Activate Bar Code Reader to insert scanned result ( P.12-11)

Conversion Methods (Japanese)

Predictive Conversion

The following suggestion lists appear while entering text or after a word is fixed.









While Entering Text	Predictive Candidates	Lists likely conversions (Predictive Candidates) and matching conversions (Conversion Candidates) Predictive Candidates わ → 私, わたし, etc. Conversion Candidates わ → 和, 輪, etc.
	Conversion Candidates	Suggests matching conversions Example: わ → 和, 輪, etc.
	abc/123/Kana Candidates	Lists alphanumerics/katakana assigned to key (☞P.3-7)
After a Word is Fixed	Context Forecast	Suggests words likely to follow Example: 私 is fixed → です, の, は, etc.



- Predictions change with each letter entered.
- Press  [Pred.]/[Conv.] to toggle Predictive Candidates List and Conversion Candidates List.



Note

- 931P learns entered characters and suggests them for future conversions (☞P.3-8).

Example: Enter 私の鼻


- 1 In kanji (hiragana) mode,  わ is entered and Predictive Candidates List appears.
- 2  to move to Predictive Candidates List →  to select 私
私 is entered and Context Forecast List appears.
- 3  to move to Context Forecast List →  to select の
の is entered and Context Forecast List appears.
- 4  →  はな is entered and Predictive Candidates List appears.
- 5  [Conv.]
Conversion Candidates List appears.





- 6  to move to Conversion Candidates List →  to select
鼻



If the Word is Not Listed

Press  to return to hiragana, and segment hiragana to convert separately.

Example: Segment はるか into はる and か, then convert to 春香

- ① Move cursor to る, then convert はる to 春 → 
- ② Convert か to 香 → 





Using Previously Entered Words

Enter the first one or two hiragana to access previously entered words in the list.

Converting Hiragana to Katakana/Alphanumerics







Enter katakana and alphanumerics in kanji (hiragana) mode. Date and time can be entered quickly.

Example 1: Enter OK

Step	1	2	3	4
Key	 (3 times)	 (twice)	 [a1Kana]	
Display	ふ	ふに	abc/123/Kana Candidates	OK

- Press  after highlighting OK.


Example 2: Enter 10:30 or 10/30

Step	1	2	3
Key	   	 [a1Kana]	
Display	あわさわ	abc/123/Kana Candidates	10:30 or 10/30

- Press  after highlighting 10:30 or 10/30.

Conversion

Viewing Learned Words

- 1 In text entry window,  [Menu] → *Text entry setting* → *Learned words*
- 2 Select a row → Select a log

Delete Learned Words


- > In Step 2, (highlight a log →  [Menu] → *Delete this* or *Delete all* (→ For *Delete all*, enter Phone Password) → *YES*

Tip

- Settings**
- Set Learning Feature Off for Secret Mode/Secret Data Only
 - Delete All Learned Words (☞P.18-10)

Activating/Canceling Prediction List

<Default> ON

- 1 In text entry window,  [Menu] → *Text entry setting*
- 2 Select an item (See below)


Item	Operation/Description
Predict	Activate/cancel Predictive Candidates and Context Forecast lists.
Candidate display	Activate/cancel Context Forecast list.
2/NIKO-touch guide	Activate/cancel Conversion Candidates guidance for 2/NIKO-touch input method.

- 3 *ON* or *OFF*

Fixing Entered Characters Automatically

<Default> OFF

Fix character in Mode 1 (5-touch) automatically after specified time elapses.

- 1 In text entry window,  [Menu] → *Text entry setting*
- 2 *Character set time* → Select a speed

Editing Text

Deleting & Replacing

1 Delete Characters within Lines

Place cursor before a character →  

A character after cursor is deleted.

- Press and hold  to delete all characters after cursor.

Delete Characters from the End of Text

Place cursor at the end of text →  

A character before cursor is deleted.

- Press and hold  to delete all characters before cursor.

2 Enter another character

Copy/Cut/Paste

Copy/cut text (up to 5000 double-byte/10000 single-byte) and paste to another place.

1 In text entry window,  [Menu] → *Copy* or *Cut*

2 Select Text to Copy/Cut

Place cursor before (or after) text to select →

[Start] → Place cursor after (or before) text →

[End]

Select All


 [All] → [End]

3 Place cursor at target location →  [Menu] → *Paste*

User's Dictionary

Save frequently used words/phrases (up to 100 entries).
Saved words/phrases appear among word suggestions.


Saving User's Dictionary Entries

- 1 In text entry window, [Menu] → *Text entry setting* → *User's Dictionary*
- 2 <New>
- 3 Enter a word → Enter reading

■ Edit User's Dictionary Entries

> After Step 1, highlight a word → [Edit] → Edit word → Edit reading

■ Delete User's Dictionary Entries

> After Step 1, [Menu] → *Delete* → *Delete this* or *Delete all*
(→ For *Delete all*, enter Phone Password) → *YES*

Note

- Alternatively, **Main Menu** ► **Tools** ► **Templates/Users Dic.**
► **User's Dictionary**




Download Dictionary

Download dictionaries from P-egg, a download site for 931P users (see below). Activate downloaded dictionaries to add character conversions to conversion suggestions (Japanese).

- P-egg (as of May 2009)
Yahoo! Keitai top page → メニューリスト → 辞書・ツール → ケータイメーカー → P-egg

Activating Downloaded Dictionaries

Main Menu ► **Tools** ► **Templates/Users Dic.**
► **Download Dictionary**

- 1 Select a dictionary
 - ★ appears next to active dictionary.
 - To cancel: follow the same step
- **Change Title**
> In Step 1, highlight a dictionary → [Menu] → *Edit title* → Edit
- **View Details**
> In Step 1, highlight a dictionary → [Menu] → *Dictionary info*
- **Delete Dictionaries**
> In Step 1, (highlight a dictionary) → [Menu] → *Delete this* or *Delete all* (→ For *Delete all*, enter Phone Password) → *YES*