

Mobile Widget	10-2
Customizing Standby Display (Japanese).....	10-2
S! Quick News	10-5
Receiving Content Updates (Japanese)	10-5
S! Information Channel	10-6
S! Information Channel & Weather Indicator (Japanese).....	10-6
e-Books	10-7
Reading e-Books (Japanese)	10-7

S! Friend's Status	10-8
Using S! Friend's Status	10-8
S! Circle Talk	10-11
Using S! Circle Talk	10-11
Near Chat	10-13
Using Near Chat (Japanese).....	10-13
Blog Tool	10-14
Blogging	10-14
Additional Functions	10-16
Troubleshooting	10-23

10

Entertainment & Communication




Customizing Standby Display (Japanese)

Paste various widgets (applications) to Standby to access/activate information/ functions immediately from Standby.



Obtaining Widgets

- 1 → **Entertainment** → → **Mobile Widget** →



Mobile Widget Menu

- 2 **Widget Contents** →



Widget List

- 3 **Download** →

- Follow onscreen instructions.

Installing Widgets






- Some widgets may need to be installed manually; follow these steps:
[Widget List] Select widget → → → **Install** → → **Yes** →
- Activating Single Widgets**
[Widget List] Select widget → → →

Advanced








- Opening properties
- Opening widget notification history
- Canceling automatic updates
- Receiving updates automatically while abroad
- Disabling widget notifications
- Disabling cookies
- Deleting cookies (P.10-16)








Saving Widgets to Standby

- 1 
 - Pointer () appears.
- 2 Use  to select  (OPEN)
 - ➔ 









- Press  to toggle selection.
 - Alternatively, use  to point to  (OPEN) and press .
- 3 Select widget ➔ 
 - Corresponding icon appears in Standby.
 - 4 Use  to specify target location ➔ 






Removing Widgets from Standby

- 1  ➔ Use  to select widget ➔ 
 - ➔ Operation ➔  ➔ Remove ➔ 
 - ➔ Yes ➔ 


Moving Widgets

- 1  ➔ Use  to select widget ➔ 
 - ➔ Operation ➔  ➔ Change Layout ➔  ➔ Specify target location ➔ 

Moving Widgets to Front/Back

- 1  ➔ Use  to select widget ➔ 
 - ➔ Operation ➔  ➔ To Front or To Back ➔ 

Updating View

- 1  ➔ Use  to select widget ➔ 
 - ➔ Operation ➔  ➔ Update View ➔ 



Using Widgets

- 1  ➔ Use  to select widget ➔ 
- 2 
 - Widget activates; follow onscreen instructions.

Using Sheets


Paste widgets and Standby shortcuts on each sheet; toggle sheets to use them.

Saving Widgets on Other Sheets

- 1 In Widget list, select widget
 - ➔ 
- 2 Set as StbyShortcut ➔ 








- 3 Select sheet ➔ 



- 4 Specify target location ➔ 

Advanced

-   Logging in to Yahoo!JAPAN
-  Viewing widget-related information
-  Reversing icon selection order with 
-  Slowing pointer speed
-  Editing sheet names
-  Locking sheets (P.10-16 - 10-17)



10 Toggling Sheets

1 [Icon] → [Y] (Long)



- To toggle further, Long Press [Y] or press [Y] repeatedly.
- Sheet name appears at the top, then disappears.
- Save widgets as needed; corresponding icons appear on the current sheet.

Using Locked Sheets

[Icon] → Select [Icon] → [Y] → Enter
Handset Code → [Y]

Deleting Widgets

One Entry

1 In Widget list, select widget



- *S!速報ニュース/S!ともだち状況* cannot be deleted.

2 Delete → [Y] → Yes → [Y]

All Entries

1 In Widget list, [Icon]

- When an item other than *Download* or *S!速報ニュース/S!ともだち状況* is selected, press [Icon] then select *Manage Items* and press [Y].


2 Delete All → [Y] → Enter Handset Code → [Y]

3 Yes → [Y]

- If there is widget saved in Standby, a confirmation appears.

Using S! Quick News & S! Friend's Status Widget

932SH is preloaded with *S!速報ニュース/S!ともだち状況* (S! Quick News & S! Friend's Status widget) that shows S! Quick News and S! Friend's Status information in Standby.



View Settings

Setting View Pattern

1 [Icon] → Use [Y] to select S! Quick News/S! Friend's Status widget → [Icon]

2 Operation → [Y] → Pattern Setting → [Y]

3 Select item → [Y] (✓) → [Y]

Switching View

1 [Icon] → Use [Y] to select S! Quick News/S! Friend's Status widget → [Icon]

2 Operation → [Y] → Switch Pattern → [Y]

- Repeat the above steps to switch the view.

Advanced

- Adding news items
- Changing news scroll speed
- Showing unread news only
- Showing news images
- Assigning members
- Managing members (P.10-17)

Receiving Content Updates (Japanese)

View content updates or breaking news.
Transmission fees apply.

Registering S! Quick News Items

- 1 **Entertainment** **S! Quick News**



S! Quick News Menu

- 2 **S! Quick News List**



S! Quick News List

- 3 **登録はこちら** **Yes**

- Handset connects to the Internet.

- 4 **Select item**

- Follow onscreen instructions.

Registering with S! Loop Items

- [S! Quick News Menu] **S! Loop List** **S!ループにアクセス** **Yes**

- Handset connects to the Internet. Refer to the S! Loop help menu for operational instructions.

Opening Information

- 1 **In S! Quick News List, select item**

- Title list appears.

- 2 **Select title**



- Press to return to title list, or to open next title.

Updating Items Manually

- [S! Quick News List] **Select item** **更新** **一件 or 全件**

Receiving S! Loop Item Updates

- [S! Quick News Menu] **S! Loop List** **Select item** **Select title**

Indicators

Unread Special news	<input type="checkbox"/>	Unread General news
Read Special news	<input type="checkbox"/>	Read General news
Unread News Flash	<input checked="" type="checkbox"/>	Auto update disabled
Read News Flash		

Advanced

- Updating S! Quick News list automatically
- Checking update schedule
- Deleting S! Quick News items
- Resetting S! Quick News List and S! Loop List
- Updating S! Loop items manually
- Updating S! Loop list automatically
- Deleting S! Loop items
- Changing background image
- Accessing source sites
- Disabling image download (P.10-18)



S! Information Channel & Weather Indicator (Japanese)


Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed. Transmission fees apply.

Service Registration & Content Subscription

- 1   **Entertainment** 
 **S! Information Channel/Weather** 




S! Information Channel Menu


- 2 **Registration/Cancel** 
 • Handset connects to the Internet.
 Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

- 1 **While Information window appears, S! Info. Channel** 
 • S! Information Channel page opens. Follow onscreen instructions.
 • S! Information Channel page handling is similar to that of Yahoo! Keitai.









- 2  **Page closes**




Opening Unread Latest Issue
 [S! Information Channel Menu]
What's New 

Opening Back Issues
 [S! Information Channel Menu]
Back Issue   **Select date** 






Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

	Clear skies (day)		Snow
	Clear skies (night)		Thunder showers
	Cloudy		Then
	Rain		Partly/chance of

Example:    Partly cloudy with a chance of rain
 Indicators other than the above also appear for more information.

Manual Update

[S! Information Channel Menu]
Weather Indicator   **Manual Update**   **Yes** 

Advanced

-  ● Hiding Information window for new received info ● Changing Display Size ● Changing scroll unit ● Copying text ● Hiding Weather Indicator in Standby
 ● Canceling Weather Indicator automatic updates ● Hiding Information window for weather updates (And more on P.10-19)



Reading e-Books (Japanese)

Downloading e-Books

1  ➔ **メニューリスト** ➔ 

2 **書籍・コミック・写真集** ➔ 

- Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

Note

- Alternatively, visit SH-web to download e-Books.

e-Book Viewer

Read XPDF books and dictionary files. Some files may not be supported.

1  ➔ **Entertainment** ➔ 



Entertainment Menu

2 **e-Book Viewer** ➔ 

- e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1 In Entertainment menu, **BookSurfing** ➔ 

- BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card

- When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Advanced

-  ● Copying text ● Opening non-932SH e-Books (Library) ● Using Library (P.10-20)




Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.


- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to **Online** beforehand.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.



1 (Long)



2 Yes



3 Yes

4 Phone Book

5 Select entry Select phone number



- Omit number selection step if only one number is saved.

6 Yes

- Registration request is sent to the number.

When Request is Accepted

- An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry

In **4**, Add New Entry Enter phone number

Advanced

- Adding members
- Deleting members
- Moving members
- Renaming Groups
- Rejecting requests
- Updating manually
- Opening notices
- Sending My Details image (And more on P.10-20 - 10-21)





Opening Member Status

- 1 (Long) Select Group



My Status

Member Status

- 2 Select member



When Cancellation Notice Arrives

- Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.


- 1 (Long) 私の状況



Connection Status

My Status Window

- 2 Select Status, e.g., **ごきげん**



Status Template Window

- 3 Select new Status

- 4 Select Availability, e.g., **Answer OK** Select new Availability

- 5 <Add Comment> Enter text

- 6 Update starts

Changing Connection Status

[My Status Window] **Online (or Offline)** Select status

Changing Status Icon/Label

[Status Template Window] Select Status Status Icon or Status Label Select Pictogram or enter text

Changing Availability Settings at Once


In 4, **Answer Status** Select new Answer Status From 5

Editing My Status Name

[My Status Window] Edit Name Edit

Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.



1 Yes → []

- Acceptance notice is sent; the number is registered.


Rejecting

In 1, No → [] → Yes → []

- Rejection notice is sent; the number cannot be registered for 24 hours.
- For **Confirm Later**, Information window opens.

Creating Status Templates

Save custom combinations of Status Icon and Status Label to each template.



1 In Status Template window, [] → New Entry → []

2 Enter name → []

3 <未定> → []



4 Status Icon → [] → Select Pictogram → []

5 Status Label → [] → Enter text → [] → []

6 Repeat 3 - 5 → [] → Saved

Saving to Data Folder

[Status Template Window] [] Select template → [] → Save to DF → [] → Save here → []

Loading Templates via Data Folder

[Status Template Window] [] → Add Template → [] → Select template → []

Renaming Templates

[Status Template Window] [] Select template → [] → Edit Temp. Name → [] → Enter name → []

Advanced

- Resetting templates (P.10-21)



Using S! Circle Talk



Use handset like a walkie-talkie to speak to multiple parties simultaneously.


- A subscription to S! Friend's Status is required.
- Transmission fees apply during S! Circle Talk.


Registering Members

Follow these steps to register a number saved in Phone Book:
















- When registering a member for the first time, a confirmation appears. Choose **Yes** and press , then skip ahead to .



- Omit number selection step if only one number is saved.
- Repeat **4** -  to add members.



Saving as Individuals

- In , **Individual**    - 
- In , **Members List**   **Select member**   
- Omit  when **Individual** is selected in .

Advanced

-   Editing individual members  Editing Groups (P.10-21)




Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:
Set My Status to **Online** first (P.10-9).

1 





2 Select member or Group ➔ 

3  ➔ **Transmission starts**



- S! Circle Talk starts when request is accepted by a receiver.
- Loudspeaker activates automatically.


Direct Entry


Enter phone number ➔  ➔  ➔ **Transmission starts**

S! Circle Talk Operations

Speaking

1 Press and hold  when **Press and Hold**  appears
➔ **You have the floor**



-  **:My Turn** appears when you have the floor.

2 Keep holding  to speak
➔ Release  ➔ **Floor is released**



- Warning tone sounds before time limit.

Incoming Calls during S! Circle Talk


- Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.

Canceling Loudspeaker

During S! Circle Talk, 





- To reactivate, follow these steps:
 ➔ **While message appears,** 

Exiting S! Circle Talk

1  ➔ **Connection ends**


- S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk



-   ➔ **Select most recent S! Circle Talk record** ➔  ➔ **Rejoin Circle Talk** ➔ 
- An error message appears when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

1 While handset is ringing/vibrating,  ➔ **S! Circle Talk starts**

- Alternatively, press .
- S! Circle Talk Operations: left

Advanced

-  Disabling Loudspeaker
-  Exiting S! Circle Talk for incoming calls (P.10-21)



Using Near Chat (Japanese)


Exchange real-time text messages wirelessly with compatible Bluetooth® devices within ten meters. (Available even when handset is out-of-range.) Because this application employs Bluetooth® wireless technology transmission/connection fees do not apply.

Access Restriction

- In the event that this handset may be used by a minor, access to this application may be password restricted by a supervising adult. In this case, Handset Code access must also be managed to prevent the execution of Memory All Clear that may be used to reset the application password.

Sending Near Chat Request


- 1 ➔ **Communication** ➔
➔ **Near chat** ➔



- 2 **Yes** ➔
 - Near Chat S! Application starts.
 - For more, see Near Chat S! Application instructions.

Receiving Near Chat Request

When a Near Chat request arrives, a tone sounds and S! Appli Notification appears.



After a period of inactivity, Information window opens, tone sounds and notification appears.

- 1 **Yes** ➔
 - Near Chat S! Application starts.
 - For more, see Near Chat S! Application instructions.

Rejecting Request

In 1, **No** ➔



Blogging

Save blog details to view or update blogs easily on handset.

Saving Blog Details


Setup for Posting via Mail

Follow these steps to save blog name and address for posting:

- 1 **Communication** **Blog Tool**



- 2 **Add NewEntry**



- 3 **Blog Menu** **Enter name**

- 4 **Blog by send Mail**



Blog Setting Menu (Mail)

- 5 **Blog's Email Address** **Enter mail address**

- 6

Saving Title/Text for Posts

[Blog Setting Menu (Mail)] **Blog's Title or Blog's Text** **Enter title or text**

- Saved title/text is entered automatically when posting.

Setting Image Size for Posting

[Blog Setting Menu (Mail)] **Picture Size** **Select size**

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC Site Browser, or both.

- 1 In Blog Setting menu, **Refer/Send by Yahoo! Keitai or Refer/Send by PC Site Browser**



- 2 **Blog's URL** **Enter URL**

- 3 **Refer Blog's URL** **Enter URL**

- 4

Advanced


- Editing entries ● Deleting entries (P.10-22)



Posting to Blogs

Complete setup for posting via mail/
Internet beforehand.



Posting via Mail

- 1 In Blog Tool window, select entry ➔ 
- 2 **Blog by send Mail** ➔ 
 - S! Mail Composition window opens with address entered.
 - Omit  if no URL is saved for posting.
- 3 Complete message ➔ 


Posting via the Internet

- 1 In Blog Tool window, select entry ➔ 
- 2 **Blog by send Browser** ➔ 
 - Page of URL saved in *Blog's URL* opens.
 - Omit  if no address is saved for posting.
 - If PC Site Browser message appears, follow onscreen prompts.


When URL is Saved for Yahoo! Keitai &
PC Site Browser

After , select browser ➔ 

Opening Blog Page

- 1 In Blog Tool window, select entry ➔ 
 - Page of URL saved in *Refer Blog's URL* opens.
 - If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai &
PC Site Browser

After 1, select browser ➔ 



Mobile Widget

Managing

Opening properties	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Widget Contents ▶ ■ ▶ Select widget ▶ Details ▶ ■ <ul style="list-style-type: none"> ● Select widget other than <i>S!速報ニュース!</i>ともだち状況.
--------------------	--

Widget History


Opening widget notification history	<p>Start Here ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Widget History ▶ ■ ▶ See below</p> <p>Showing All Text</p> <p>Select record ▶ ☰ ▶ View full text ▶ ■</p> <p>Deleting a Record</p> <p>Select record ▶ ☰ ▶ Delete ▶ ■ ▶ Yes ▶ ■</p> <p>Deleting All Records</p> <p>Select record ▶ ☰ ▶ Delete All ▶ ■ ▶ Enter Handset Code ▶ ■ ▶ Yes ▶ ■</p>
-------------------------------------	---

Settings


Canceling automatic updates	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Settings ▶ ■ ▶ Auto Refresh ▶ ■ ▶ <p>Off ▶ ■</p>
Receiving updates automatically while abroad	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Settings ▶ ■ ▶ AutoConnect Abroad ▶ ■ ▶ On ▶ ■
Disabling widget notifications	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Settings ▶ ■ ▶ Notification Setting ▶ Off ▶ ■

Disabling cookies	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Settings ▶ ■ ▶ Cookies ▶ ■ ▶ <p>Disabled ▶ ■</p>
Deleting cookies	<ul style="list-style-type: none"> ■ ▶ Entertainment ▶ ■ ▶ Mobile Widget ▶ ■ ▶ Settings ▶ ■ ▶ Delete Cookies ▶ ■ <p>Yes ▶ ■</p>

Operations in Standby

Logging in to Yahoo!JAPAN	<ul style="list-style-type: none"> ☰ ▶ ☰ ▶ Yahoo!JAPAN log in ▶ ■ <ul style="list-style-type: none"> ● Follow onscreen instructions. ● To log out, select Yahoo!JAPAN log out in the above steps.
Viewing widget-related information	<ul style="list-style-type: none"> ☰ ▶ ☰ ▶ Information ▶ ■
Reversing icon selection order with 	<ul style="list-style-type: none"> ☰ ▶ ☰ ▶ Move Focus(Reverse) ▶ ■ <ul style="list-style-type: none"> ● To cancel, select Move Focus(Order).
Slowing pointer speed	<ul style="list-style-type: none"> ☰ ▶ ☰ ▶ Cursor Speed ▶ ■ ▶ Slow ▶ ■

Sheets

Editing sheet names	<p>Start Here)  ▶ ☰ ▶ Sheet Settings ▶ ■ ▶</p> <p>Change Sheet Name ▶ ■ ▶ See below</p> <p>Renaming</p> <p>Select sheet ▶ ■ ▶ Enter name ▶ ■</p> <p>Resetting All Sheet Names</p> <p>☰ ▶ Yes ▶ ■</p>
---------------------	---



Locking sheets	<p>Start Here Sheet Settings Set Sheet Lock Enter Handset Code </p> <p> See below</p>
	<p>Activating Lock</p> <p>Select sheet On </p>
	<p>Changing Method for Temporary Access</p> <p>Unlock Method No Password </p> <ul style="list-style-type: none"> Press , then select and press to unlock sheet temporarily.
<p>■ S! Quick News & S! Friend's Status Widget (S! Quick News)</p>	
Adding news items	<p> Use to select S! Quick News/S! Friend's Status widget Operation Contents Menu Add News </p> <p> S! Quick News List 登録はこちら Yes Select genre Select item </p> <ul style="list-style-type: none"> Follow onscreen instructions.
Changing news scroll speed	<p> Use to select S! Quick News/S! Friend's Status widget Operation Contents Menu News Display News Speed Select speed </p>
Showing unread news only	<p> Use to select S! Quick News/S! Friend's Status widget Operation Contents Menu News Display Target News Unread Only </p>
Showing news images	<p> Use to select S! Quick News/S! Friend's Status widget Operation Contents Menu News Display Display Image On </p> <ul style="list-style-type: none"> Available when only S! Quick News area is set to appear on the Panel.

■ **S! Quick News & S! Friend's Status Widget (S! Friend's Status)**

Assigning members	<p>When Pattern Setting is Not Friend's Status(List)</p> <p> Use to select member field Operation Contents Menu Assign Member Select category Select entry/member </p>
	<p>When Pattern Setting is Friend's Status(List)</p> <p> Use to select S! Quick News/S! Friend's Status widget Operation Contents Menu Assign Member Select category Select entry/member (Empty) </p>
Managing members	<p>Start Here Use to select member Operation Contents Menu See below</p>
	<p>Deleting Members</p> <p>Delete Yes </p>
	<p>Changing Member Order</p> <p>Move (Up) or (Down) </p>
	<p>Changing Member Icons</p> <p>Change Icon Select Pictogram </p>



S! Quick News

■ Opening/Updating Items

Updating S! Quick News list automatically

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Automatic Update →
 ■ → S! Quick News → ■ → Select item → ■
 → ■ → Select interval or choose On → ■
- If a confirmation appears, press ■.
 - When Special is set to **On**, items are updated every four hours.
 - When General is set to **On**, items are updated once a day.
 - To cancel automatic update, choose **Off** and press ■.
 - Updating items may incur high charges.
 - Only available in Japan.

Checking update schedule

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Check Schedule → ■

Deleting S! Quick News items

- [Start Here] ■ → Entertainment → ■ → S! Quick News →
 ■ → S! Quick News List → ■ →
 Select item → ■ → See below

One Entry

- 一件 → ■ → Yes → ■

All Entries

- 全件 → ■ → Enter Handset Code → ■ → Yes → ■

Resetting S! Quick News List and S! Loop List

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Delete S! Quick News Lists →
 ■ → Enter Handset Code → ■ → Yes → ■
- Not available during automatic updates.

■ S! Loop

Updating S! Loop items manually

- [Start Here] ■ → Entertainment → ■ → S! Quick News →
 ■ → S! Loop List → ■ → See below

One Entry

- Select item → ■ → 更新 → ■ → 一件 → ■

All Entries

- → 更新 → ■ → 全件 → ■

Updating S! Loop list automatically

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Automatic Update →
 ■ → S! Loop → ■ → ■ → On → ■ → ■
- Items are updated about four times a day.
 - Only available in Japan.

Deleting S! Loop items

- [Start Here] ■ → Entertainment → ■ → S! Quick News →
 ■ → S! Loop List → ■ → Select item → ■ → See below

One Entry

- 一件 → ■ → Yes → ■

All Entries

- 全件 → ■ → Enter Handset Code → ■ → Yes → ■

■ Other

Changing background image

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Change Skin → ■ →
 Select pattern → ■

Accessing source sites

- → Entertainment → ■ → S! Quick News →
 ■ → Select list → ■ → Select item → ■ →
 Select title → ■ → Select title → ■ → Yes → ■

Disabling image download

- → Entertainment → ■ → S! Quick News →
 ■ → Settings → ■ → Show Image → ■ →
 Off → ■



S! Information Channel

■ Receiving Information

Hiding Information window for new received info	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Notification</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/>
Requesting re-delivery	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Get Latest Contents</i> → <input type="checkbox"/> → <i>Yes</i> → <input type="checkbox"/>

■ Information Pages

Changing Display Size	On a page, <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Display Size</i> → <input type="checkbox"/> → <i>Select size</i> → <input type="checkbox"/>
Changing scroll unit	On a page, <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Scroll Unit</i> → <input type="checkbox"/> → <i>Select unit</i> → <input type="checkbox"/>
Copying text	On a page, <input type="checkbox"/> → <i>Copy Text</i> → <input type="checkbox"/> → <i>Select first character</i> → <input type="checkbox"/> → <i>Highlight text range</i> → <input type="checkbox"/>
Saving files to Data Folder	On a page, <input type="checkbox"/> → <i>Save Items</i> → <input type="checkbox"/> → <i>Select file</i> → <input type="checkbox"/> → <i>Save</i> → <input type="checkbox"/> → <i>Enter name</i> → <input type="checkbox"/> → <i>Save here</i> → <input type="checkbox"/> <ul style="list-style-type: none"> Some files are saved automatically.
Opening page properties	On a page, <input type="checkbox"/> → <i>Page Information</i> → <input type="checkbox"/>

■ Weather Indicators

Checking weather forecast	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Weather Indicator</i> → <input type="checkbox"/> → <i>Weather</i> → <input type="checkbox"/>
Changing weather forecast page font size	On a page, <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Font Size</i> → <input type="checkbox"/> → <i>Select size</i> → <input type="checkbox"/>
Hiding Weather Indicator in Standby	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Weather Indicator</i> → <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Standby Setting</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/>
Canceling Weather Indicator automatic updates	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Weather Indicator</i> → <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Icon Update</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/>
Hiding Information window for weather updates	<input type="checkbox"/> → <i>Entertainment</i> → <input type="checkbox"/> → <i>S! Information Channel/Weather</i> → <input type="checkbox"/> → <i>Weather Indicator</i> → <input type="checkbox"/> → <i>Settings</i> → <input type="checkbox"/> → <i>Weather Notif.</i> → <input type="checkbox"/> → <i>Off</i> → <input type="checkbox"/>



e-Books	
Copying text	In open page, \Rightarrow 文字列を北' - \Rightarrow \Rightarrow Select first character \Rightarrow \Rightarrow Highlight text range \Rightarrow
Opening non-932SH e-Books (Library)	\Rightarrow Entertainment \Rightarrow \Rightarrow e-Book Viewer \Rightarrow \Rightarrow Select file \Rightarrow <ul style="list-style-type: none"> Some files may not open.
Using Library	\Rightarrow Entertainment \Rightarrow \Rightarrow e-Book Viewer \Rightarrow \Rightarrow See below
	Adding Folders \Rightarrow New Folder \Rightarrow \Rightarrow Enter name \Rightarrow
	Switching Folders \Rightarrow Switch Folders \Rightarrow \Rightarrow Select folder \Rightarrow
	Renaming Folders/Files Select folder/file \Rightarrow \Rightarrow Change Name \Rightarrow \Rightarrow Enter name \Rightarrow
	Moving Files Select file \Rightarrow \Rightarrow Move \Rightarrow \Rightarrow Select folder \Rightarrow \Rightarrow Move here \Rightarrow
	Deleting Folders/Files Select folder/file \Rightarrow \Rightarrow Delete \Rightarrow \Rightarrow Yes \Rightarrow
	Opening File Properties Select file \Rightarrow \Rightarrow Details \Rightarrow

S! Friend's Status

Members/Groups

Adding members	(Long) \Rightarrow Select Group \Rightarrow Add Member \Rightarrow \Rightarrow Select method \Rightarrow \Rightarrow Select entry or enter phone number \Rightarrow \Rightarrow Yes \Rightarrow
Deleting members	(Long) \Rightarrow Select Group \Rightarrow Select member \Rightarrow \Rightarrow Registration Release \Rightarrow \Rightarrow Yes \Rightarrow \Rightarrow Yes \Rightarrow <ul style="list-style-type: none"> Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	(Long) \Rightarrow Select Group \Rightarrow Select member \Rightarrow \Rightarrow Change Group \Rightarrow \Rightarrow Select target Group \Rightarrow
Renaming Groups	(Long) \Rightarrow Select Group \Rightarrow Edit Group Name \Rightarrow \Rightarrow Enter name \Rightarrow
Rejecting requests	(Long) \Rightarrow \Rightarrow Settings \Rightarrow \Rightarrow Request Reply \Rightarrow \Rightarrow See below
	Rejecting Requests from Unsaved Numbers Confirm if Registered \Rightarrow <ul style="list-style-type: none"> Rejection notice is sent to rejected numbers automatically.
	Rejecting All Requests Always Ignore \Rightarrow <ul style="list-style-type: none"> Rejection notice is sent to all requesters automatically.



■ Status/Availability

Saving custom Availability combinations	<p>[⋮] (Long) → [☰] → <i>Settings</i> → [■] → <i>Answer Status</i> → [■] → <i>User Setting</i> → [■] → Select type → [■] → Select Availability → [■] → [✓]</p>
Changing Status Icon Pictogram or Status Label description	<p>[⋮] (Long) → [☰] → <i>Settings</i> → [■] → <i>Status Setting</i> → [■] → [☰] Select template → Select Status → [■] → <i>Status Icon</i> → [■] → Select Pictogram → [■] → <i>Status Label</i> → [■] → Enter text → [■] → [✓]</p>

■ Status Templates

Resetting templates	<p>[Start Here] [⋮] (Long) → <i>私の状況</i> → [■] → Select Status → [■]</p>
	<p>One Template</p> <p>[☰] Select template → [☰] → <i>Reset</i> → [■] → Yes → [■]</p>
	<p>All Templates</p> <p>[☰] → <i>Reset All</i> → [■] → Yes → [■]</p>

■ Member Status & Notices

Updating manually	<p>[⋮] (Long) → [☰] → <i>Settings</i> → [■] → <i>Status Update</i> → [■]</p>
Opening notices	<p>[⋮] (Long) → [☰] → <i>Status Notif. List</i> → [■] → Select notice → [■]</p>

■ My Details

Sending My Details image	<p>[⋮] (Long) → [☰] Select Group → Select member → [☰] → <i>Send Image</i> → [■] → Yes → [■]</p>
--------------------------	--

S! Circle Talk

■ Member List






Editing individual members	<p>[Start Here] [🔴] → Select member → [☰] → See below</p> <p>Replacing Members</p> <p><i>Edit</i> → [■] → [☰] → Select method → [■] → Select entry → [■]</p> <p>Deleting Members</p> <p><i>Delete</i> → [■] → Yes → [■]</p>
	<p>[Start Here] [🔴] → Select Group → [☰] → See below</p> <p>Editing Group Name/Members</p> <p><i>Edit</i> → [■] → Select target → [■] → Edit/enter → [■] → [✓]</p> <p>Deleting Group Members</p> <p><i>Edit</i> → [■] → Select member → [☰] → <i>Delete</i> → [■] → Yes → [■] → [✓]</p> <p>Deleting Groups</p> <p><i>Delete</i> → [■] → Yes → [■]</p>

■ Settings

Disabling Loudspeaker	<p>[🔴] → [☰] → <i>Loudspeaker</i> → [■] → Off → [■]</p>
Exiting S! Circle Talk for incoming calls	<p>[🔴] → [☰] → <i>Incoming Calls</i> → [■] → <i>Voice Calls or Video Calls</i> → [■] → <i>Accept Calls</i> → [■]</p>



Blog Tool

Editing entries	<ul style="list-style-type: none"> ■ → <i>Communication</i> → ■ → <i>Blog Tool</i> → ■ → Select entry →  → <i>Edit</i> → ■ → Select item → ■ → <i>Edit</i> →  →  • For <i>Blog Menu</i>, omit step of pressing  after editing.
Deleting entries	<ul style="list-style-type: none"> ■ → <i>Communication</i> → ■ → <i>Blog Tool</i> → ■ → Select entry →  → <i>Delete</i> → ■ → <i>Yes</i> → ■





S! Friend's Status

? Cannot use S! Friend's Status

- Set IP Service Setting to *On*.

? Handset rejected a registration request automatically

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

? Registration request arrived from a deleted member

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

? Registration request was sent to a member automatically

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

? Cannot create Status Templates

- Three templates may already be added; reset one and retry.

S! Circle Talk

? Cannot use S! Circle Talk

- Set IP Service Setting to *On*.

? S! Circle Talk starts automatically

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Auto Join*.

? Cannot accept S! Circle Talk requests

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Join NG*.

Near Chat

? Cannot receive Near Chat requests

- S! Appli Request may be set to *Off*.

S! Quick News

? Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash or S! Loop List update items overnight.
- USIM Card replacement cancels Automatic Update.