

Mobile Widget	10-2
Customizing Standby Display (Japanese).....	10-2
S! Quick News	10-5
Receiving Content Updates (Japanese)	10-5
S! Information Channel	10-6
S! Information Channel & Weather Indicator (Japanese)	10-6
e-Books	10-7
Reading e-Books (Japanese)	10-7

S! Friend's Status	10-8
Using S! Friend's Status	10-8
S! Circle Talk	10-11
Using S! Circle Talk	10-11
Near Chat	10-13
Using Near Chat (Japanese).....	10-13
Blog Tool	10-14
Blogging	10-14
Additional Functions	10-16
Troubleshooting	10-23

10

Entertainment & Communication



Customizing Standby Display (Japanese)

Paste various widgets (applications) to Standby to access/activate information/functions immediately from Standby.




S! Quick News &
S! Friend's Status Widget

Widgets

Obtaining Widgets

- 1 → **Entertainment** → → **Mobile Widget** →



Mobile Widget Menu

- 2 **Widget Contents** →



Widget List

- 3 **Download** →

• Follow onscreen instructions.

Installing Widgets

• Some widgets may need to be installed manually; follow these steps:

[Widget List] Select widget → → → **Install** → → **Yes** →

Activating Single Widgets

[Widget List] Select widget → → →

Deleting Widgets

- 1 In Widget list, select widget →

• S!速報ニュース/S!ともだち状況 cannot be deleted.

- 2 **Delete** → → **Yes** →

Deleting All Widgets

In Widget list, **Download** → → **Delete All** → → **Enter Handset Code** → → **Yes** →

■ If there is a widget saved in Standby, a confirmation appears; follow onscreen prompt.

Advanced

- Opening properties
- Opening widget notification history
- Canceling automatic updates
- Receiving updates automatically while outside Japan
- Hiding confirmation outside Japan
- Disabling widget notifications
- Disabling cookies
- Deleting cookies (P.10-16)



Saving Widgets to Standby

- 1
- 2 Use to select (OPEN)
➡



- 3 Select widget ➡
- Corresponding icon appears in Standby.

- 4 Use to specify target location ➡

Using Pointer ()

- After 1, Long Press () to activate pointer navigation; select widgets, etc.
- To cancel pointer navigation, Long Press ()

Using Widgets

- 1 ➡ Use to select widget ➡



- 2
- Widget activates; follow onscreen instructions.

Using Sheets

Paste widgets and Standby Shortcuts on each sheet; toggle sheets to use them.

Toggling Sheets

- 1 ➡



- To toggle further, press or .
- Sheet name appears at the top, then disappears.
- Save widgets as needed; corresponding icons appear on the current sheet.

Advanced

- Logging in to Yahoo!JAPAN
- Moving widgets
- Viewing widget-related information (Japanese)
- Slowing pointer speed
- Editing sheet names
- Locking sheets (And more on P.10-16 - 10-17)



Saving Widgets on Other Sheets

- 1 In Widget list, select widget
➡
- 2 Set as StbyShortcut ➡




- 3 Select sheet ➡



- 4 Specify target location ➡

Removing Widgets from Standby

- 1 ➡ Use to select widget ➡
- 2 Operation ➡
- 3 Remove ➡
- 4 Yes ➡



Using S! Quick News & S! Friend's Status Widget

936SH is preloaded with *S!速報ニュース*/S!ともだち状況 (S! Quick News & S! Friend's Status widget) that shows S! Quick News and S! Friend's Status information in Standby.



View Settings

Setting View Pattern

- 1 ➡ Use to select S! Quick News/S! Friend's Status widget ➡
- 2 Settings ➡ ➡ Pattern Setting ➡
- 3 Select item ➡ (✓) ➡

Switching View

- 1 ➡ Use to select S! Quick News/S! Friend's Status widget ➡
- 2 Operation ➡ ➡ Switch Pattern ➡

• Repeat the above steps to switch the view.

Advanced

- Removing widgets at once by sheet
- Adding news items
- Changing news scroll speed
- Showing unread news only
- Showing news images
- Assigning members
- Managing members (P.10-16 - 10-18)



Receiving Content Updates (Japanese)

View content updates or breaking news.
Transmission fees apply.

Registering S! Quick News Items

- 1 ➔ **Entertainment** ➔ ➔ **S! Quick News** ➔



S! Quick News Menu

- 2 **S! Quick News List** ➔



S! Quick News List

- 3 **登録はこちら** ➔ ➔ **Yes** ➔


- Handset connects to the Internet.

- 4 **Select item** ➔ ➔
- Follow onscreen instructions.

Opening Information

- 1 **In S! Quick News List, select item** ➔
- Title list appears.

- 2 **Select title** ➔



- Press to return to title list, or to open next title.

Updating Items Manually

[S! Quick News List] **Select item** ➔

➔ **更新** ➔ ➔ **一件 or 全件** ➔

Indicators

	Unread Special news		Unread General news
	Read Special news		Read General news
	Unread News Flash		Auto update disabled
	Read News Flash		

Advanced

- Updating S! Quick News list automatically
- Checking update schedule
- Deleting S! Quick News items
- Resetting S! Quick News List
- Changing background image
- Accessing source sites
- Disabling image download (P.10-18 - 10-19)




S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed. Transmission fees apply.

Service Registration & Content Subscription

- 1** **Entertainment** **S! Information Channel/Weather**



S! Information Channel Menu

- 2** **Registration/Cancel**
- Handset connects to the Internet. Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

- 1** **While Information window appears, S! Info. Channel**
- S! Information Channel page opens. Follow onscreen instructions.
 - S! Information Channel page handling is similar to that of Yahoo! Keitai.

- 2** **Page closes**

Opening Unread Latest Issue

[S! Information Channel Menu]

What's New

Opening Back Issues

[S! Information Channel Menu] **Back**

Issue **Select date**

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

	Clear skies (day)		Snow
	Clear skies (night)		Thunder showers
	Cloudy		Then
	Rain		Partly/chance of

Example: Partly cloudy with a chance of rain

Indicators other than the above also appear for more information.

Manual Update

[S! Information Channel Menu]

Weather Indicator **Manual**

Update **Yes**

Advanced

- Hiding Information window for new received info
- Changing Display Size
- Changing scroll unit
- Copying text
- Hiding Weather Indicator in Standby
- Canceling Weather Indicator automatic updates
- Hiding Information window for weather updates (And more on **P.10-19 - 10-20**)



Reading e-Books (Japanese)

Downloading e-Books

1  ➔ **メニューリスト** ➔ 

2 **書籍・コミック・写真集** ➔ 

- Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

Note

- Alternatively, go to SH-web Mobile Internet site (**シャープメーカーサイトSH-web** in Bookmarks; see P.5-7) for e-Books.

e-Book Viewer

Read XPDF books and dictionary files. Some files may not be supported.

1  ➔ **Entertainment** ➔ 



Entertainment Menu

2 **e-Book Viewer** ➔ 

- e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1 In Entertainment menu, **BookSurfing** ➔ 

- BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card

- When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Advanced

-  ● Copying text ● Opening non-936SH e-Books (Library) ● Using Library (P.10-20)



Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.

- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to **Online** first.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.



1 (Long)



2 Yes ➔ ●



3 Yes ➔ ●

4 Phone Book ➔ ●

5 Select entry ➔ ● ➔ Select phone number ➔ ●



- Omit number selection step if only one number is saved.

6 Yes ➔ ●

- Registration request is sent to the number.

When Request is Accepted

- An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry

In 4, **Add New Entry** ➔ ● ➔ Enter phone number ➔ ● ➔ 5

Advanced

- Adding members
- Deleting members
- Moving members
- Renaming Groups
- Rejecting requests
- Updating manually
- Opening notices
- Sending My Details image (And more on P.10-21)



Opening Member Status

- 1 (Long) ➡ Select Group



My Status
Member Status

- 2 Select member ➡



When Cancellation Notice Arrives

- Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.


- 1 (Long) ➡ 私の状況 ➡



Connection Status

My Status Window

- 2 Select Status, e.g., ごきげん ➡



Status Template Window

- 3 Select new Status ➡

- 4 Select Availability, e.g., Answer OK ➡ ➡ Select new Availability ➡

- 5 <Add Comment> ➡ ➡ Enter text ➡

- 6 ➡ Update starts

Changing Connection Status

[My Status Window] Online (or Offline) ➡ ➡ Select status ➡

Changing Status Icon/Label

[Status Template Window] Select Status ➡ ➡ Status Icon or Status Label ➡ ➡ Select Pictogram or enter text ➡ ➡

Changing Availability Settings at Once

In 4, Answer Status ➡ ➡ Select new Answer Status ➡ ➡ From 5


Editing My Status Name

[My Status Window] ➡ Edit Name ➡ ➡ Edit ➡



Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.



1 Yes → ●

- Acceptance notice is sent; the number is registered.


Rejecting

In 1, No → ● → Yes → ●

- Rejection notice is sent; the number cannot be registered for 24 hours.
- For **Confirm Later**, Information window opens.

Creating Status Templates


Save custom combinations of Status Icon and Status Label to each template.



1 In Status Template window, New Entry → ●

2 Enter name → ●

3 <未定> → ●



4 Status Icon → ● → Select Pictogram → ●

5 Status Label → ● → Enter text → ● → Y7

6 Repeat 3 - 5 → Y7 → Saved

Saving to Data Folder

[Status Template Window] Select template → Save to DF → Save here →

Loading Templates via Data Folder

[Status Template Window] Add Template → Select template →

Renaming Templates

[Status Template Window] Select template → Edit Temp. Name → Enter name →

Advanced

- Resetting templates (P.10-21)



Using S! Circle Talk

Use handset like a walkie-talkie to speak to multiple parties simultaneously.

- A subscription to S! Friend's Status is required.
- Transmission fees apply during S! Circle Talk.

Registering Members

Follow these steps to register a number saved in Phone Book:

- 1 **Communication** **S! Circle Talk**

- When registering a member for the first time, a confirmation appears. Choose **Yes** and press , then skip ahead to 3.

- 2 **<Add New Entry>**



- 3 **Group** **Group Name:** **Enter name**



- 4 **Select number, e.g., No.1:**

- 5 **Phone Book**

- 6 **Select entry** **Select phone number**



- Omit number selection step if only one number is saved.
- Repeat 4 - 6 to add members.

- 7 **Saved**

Saving as Individuals

- In 3, **Individual** 5 - 5
 Saving from S! Friend's Status Member List
 In 5, **Members List** **Select member** 7
 ■ Omit 7 when **Individual** is selected in 3.

Advanced

- Editing individual members ● Editing Groups (P.10-22)



Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:

(First, set Connection status to **Online** (P.10-9).)

- 1 ➔ **Communication** ➔ ➔ **S! Circle Talk** ➔



- 2 ➔ **Select member or Group** ➔
- 3 ➔ **Transmission starts**
 - S! Circle Talk starts when request is accepted by a receiver.
 - Loudspeaker activates automatically.

Direct Entry

Enter phone number ➔ ➔ **Call**
S! Circle Talk ➔ ➔

S! Circle Talk Operations

Speaking

- 1 ➔ **Press and hold** ➔ **Press and Hold** appears
 ➔ **You have the floor**



- **:My Turn** appears when you have the floor.

- 2 ➔ **Keep holding** ➔ **to speak**
 ➔ **Release** ➔ **Floor is released**
 - Warning tone sounds before time limit.

Incoming Calls during S! Circle Talk

- Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.

Canceling Loudspeaker During S! Circle Talk,

- To reactivate, follow these steps:
 ➔ **While message appears**,

Exiting S! Circle Talk

- 1 ➔ **Connection ends**
 - S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk

- ➔ **Select most recent S! Circle Talk record** ➔ ➔ **Rejoin Circle Talk** ➔
- Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

- 1 ➔ **While handset is ringing/vibrating**, ➔ **S! Circle Talk starts**
 - Alternatively, press .
 - S! Circle Talk Operations: left

Advanced

- Disabling Loudspeaker ● Exiting S! Circle Talk for incoming calls (P.10-22)



Using Near Chat (Japanese)

Exchange real-time text messages wirelessly with compatible Bluetooth® devices within ten meters. (Available even when handset is out-of-range.) Because this application employs Bluetooth® wireless technology transmission/connection fees do not apply.

Access Restriction

- In the event that this handset may be used by a minor, access to this application may be password restricted by a supervising adult. In this case, Handset Code access must also be managed to prevent the execution of Memory All Clear that may be used to reset the application password.

Sending Near Chat Request

- 1** ● ➡ **Communication** ➡ ●
➡ **Near chat** ➡ ●




- 2** **Yes** ➡ ●

- Near Chat S! Application starts.
- A confirmation appears. Read the message and press ☺ (はい) or ☹ (いいえ).
- For more, see Near Chat S! Application instructions.

Receiving Near Chat Request

When a Near Chat request arrives, a tone sounds and S! Appli Notification appears.



After a period of inactivity, Information window opens, tone sounds and notification appears.

- 1** **Yes** ➡ ●

- Near Chat S! Application starts.
- A confirmation appears. Read the message and press ☺ (はい) or ☹ (いいえ).
- For more, see Near Chat S! Application instructions.

Rejecting Request

In **1**, **No** ➡ ●



Blogging


Save blog details to view or update blogs easily on handset.

Saving Blog Details

Setup for Posting via Mail


Follow these steps to save blog name and address for posting:

- 1 **Communication** **Blog Tool**



Blog Tool Window


- 2 **Add New Entry**



Blog Setting Menu

- 3 **Blog Title** **Enter name**

- 4 **Blog by send Mail**



Blog Setting Menu (Mail)

- 5 **Blog's Email Address** **Enter mail address**

- 6

Saving Title/Text for Posts

After 5, **Blog's Title** or **Blog's Text**

Enter title or text 6

- Saved title/text is entered automatically when posting.

Setting Image Size for Posting

After 5, **Picture Size** **Select size**

6

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC Site Browser, or both.

- 1 In Blog Setting menu, **Refer/Send by Yahoo! Keitai** or **Refer/Send by PC Site Browser**



- 2 **Blog's URL** **Enter URL**

- 3 **Refer Blog's URL** **Enter URL**

- 4

Advanced

- Editing entries Deleting entries (P.10-22)



Posting to Blogs

Complete setup for posting via mail/
Internet beforehand.

Posting via Mail

- 1 In Blog Tool window, select entry ➡ ●
- 2 **Blog by send Mail** ➡ ●
 - S! Mail Composition window opens with address entered.
 - Omit 2 if no URL is saved for posting.
- 3 Complete message ➡ 37

Posting via the Internet

- 1 In Blog Tool window, select entry ➡ ●
- 2 **Blog by send Browser** ➡ ●
 - Page of URL saved in *Blog's URL* opens.
 - Omit 2 if no address is saved for posting.
 - If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser

After 2, select browser ➡ ●

Opening Blog Page

- 1 In Blog Tool window, select entry ➡ 37
 - Page of URL saved in *Refer Blog's URL* opens.
 - If PC Site Browser message appears, follow onscreen prompts.

When URL is Saved for Yahoo! Keitai & PC Site Browser

After 1, select browser ➡ ●



Mobile Widget

Managing

Opening properties	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Widget Contents → Select widget → Details Select widget other than <i>S!速報ニュース!ともだち状況</i>.
--------------------	---

Widget History

Opening widget notification history	<p>Start Here → Entertainment → Mobile Widget → Widget History → See below</p> <p>Showing All Text Select record → View full text</p> <p>Deleting a Record Select record → Delete → Yes</p> <p>Deleting All Records Select record → Delete All → Enter Handset Code → Yes</p>
-------------------------------------	--

Settings

Canceling automatic updates	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → Auto Refresh → Off
Receiving updates automatically while outside Japan	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → AutoConnect Abroad → On
Hiding confirmation outside Japan	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → Set Use Abroad → Off

Disabling widget notifications	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → Notification Setting → Off
Disabling cookies	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → Cookies → Disabled
Deleting cookies	<ul style="list-style-type: none"> Entertainment → Mobile Widget → Settings → Delete Cookies → Yes

Operations in Standby

Logging in to Yahoo!JAPAN	<ul style="list-style-type: none"> Use → Yahoo!JAPAN log in Follow onscreen instructions. To log out, select <i>Yahoo!JAPAN log out</i> in the above steps.
Moving widgets	<ul style="list-style-type: none"> Use → to select widget → Change Layout → Specify target location
Moving widgets to front/back	<ul style="list-style-type: none"> Use → to select widget → Operation → To Front or To Back
Updating view	<ul style="list-style-type: none"> Use → to select widget → Operation → Update View
Removing widgets at once by sheet	<p>Start Here → to select widget → Operate from List → Remove → See below</p> <p>All Widgets Remove All → Select sheet → Yes</p> <p>Selected Widgets Select also Remove → Select widget → Complete selection → Yes</p>



Viewing widget-related information (Japanese)	➔ ➔ Information ➔ • Follow onscreen instructions.
Slowing pointer speed	➔ ➔ Settings ➔ ➔ Cursor Speed ➔ ➔ Slow ➔

■ Sheets

Editing sheet names	[Start Here] ➔ ➔ Settings ➔ ➔ Sheet Settings ➔ ➔ Change Sheet Name ➔ ➔ See below
	Renaming Select sheet ➔ ➔ Enter name ➔ Resetting All Sheet Names ➔ Yes ➔
Locking sheets	[Start Here] ➔ ➔ Settings ➔ ➔ Sheet Settings ➔ ➔ Set Sheet Lock ➔ ➔ Enter Handset Code ➔ ➔ See below
	Activating Lock Select sheet ➔ ➔ On ➔ Changing Method for Temporary Access Unlock Method ➔ ➔ No Password ➔ • Press , then select and press to unlock sheet temporarily.

■ S! Quick News & S! Friend's Status Widget (S! Quick News)

Adding news items	➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ Add News ➔ ➔ S! Quick News List ➔ ➔ 登録はこちら ➔ ➔ Yes ➔ • Follow onscreen instructions.
Changing news scroll speed	➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ News Display ➔ ➔ News Speed ➔ ➔ Select speed ➔
Showing unread news only	➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ News Display ➔ ➔ Target News ➔ ➔ Unread Only ➔
Showing news images	➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ News Display ➔ ➔ Display Image ➔ ➔ On ➔ • Available when only S! Quick News area is set to appear on the Panel.



■ S! Quick News & S! Friend's Status Widget (S! Friend's Status)

Assigning members	<p>When Pattern Setting is Not Friend's Status(List) ➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Use to select member field ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ Assign Member ➔ ➔ Select category ➔ ➔ Select entry/member ➔ </p> <p>When Pattern Setting is Friend's Status(List) ➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ Assign Member ➔ ➔ Select category ➔ ➔ Select entry/member ➔ ➔ (Empty) ➔ </p>
Managing members	<p>Start Here ➔ Select S! Quick News/S! Friend's Status widget ➔ ➔ Use to select member field ➔ ➔ Operation ➔ ➔ Contents Menu ➔ ➔ See below</p> <p>Deleting Members Delete ➔ ➔ Yes ➔ </p> <p>Changing Member Order Move ➔ ➔ (Up) or (Down) ➔ </p> <p>Changing Member Icons Change Icon ➔ ➔ Select Pictogram ➔ </p>

■ S! Quick News

■ Opening/Updating Items

Updating S! Quick News list automatically	<p> ➔ Entertainment ➔ ➔ S! Quick News ➔ ➔ Settings ➔ ➔ Automatic Update ➔ ➔ Select item ➔ ➔ Select interval or choose On ➔ </p> <ul style="list-style-type: none"> • If a confirmation appears, press . • When Special is set to On, items are updated every four hours. • When General is set to On, items are updated once a day. • To cancel automatic update, choose Off and press . • Updating items may incur high charges. • Only available in Japan.
Checking update schedule	<p> ➔ Entertainment ➔ ➔ S! Quick News ➔ ➔ Settings ➔ ➔ Check Schedule ➔ </p>
Deleting S! Quick News items	<p>Start Here ➔ ➔ Entertainment ➔ ➔ S! Quick News ➔ ➔ S! Quick News List ➔ ➔ Select item ➔ ➔ See below</p> <p>One Entry 一件 ➔ ➔ Yes ➔ </p> <p>All Entries 全件 ➔ ➔ Enter Handset Code ➔ ➔ Yes ➔ </p>
Resetting S! Quick News List	<p> ➔ Entertainment ➔ ➔ S! Quick News ➔ ➔ Settings ➔ ➔ Delete S! Quick News Lists ➔ ➔ Enter Handset Code ➔ ➔ Yes ➔ </p> <ul style="list-style-type: none"> • Not available during automatic updates.



■ Other

Changing background image	● ➤ <i>Entertainment</i> ➤ ● ➤ <i>S! Quick News</i> ➤ ● ➤ <i>Settings</i> ➤ ● ➤ <i>Change Skin</i> ➤ ● ➤ Select pattern ➤ ●
Accessing source sites	● ➤ <i>Entertainment</i> ➤ ● ➤ <i>S! Quick News</i> ➤ ● ➤ <i>S! Quick News List</i> ➤ ● ➤ Select item ➤ ● ➤ Select title ➤ ● ➤ Select title ➤ ● ➤ Yes ➤ ●
Disabling image download	● ➤ <i>Entertainment</i> ➤ ● ➤ <i>S! Quick News</i> ➤ ● ➤ <i>Settings</i> ➤ ● ➤ <i>Show Image</i> ➤ ● ➤ <i>Off</i> ➤ ●

S! Information Channel

■ Receiving Information

Hiding Information window for new received info	● ➤ <i>Entertainment</i> ➤ ● ➤ <i>S! Information Channel/Weather</i> ➤ ● ➤ <i>Notification</i> ➤ ● ➤ <i>Off</i> ➤ ●
Requesting re-delivery	● ➤ <i>Entertainment</i> ➤ ● ➤ <i>S! Information Channel/Weather</i> ➤ ● ➤ <i>Get Latest Contents</i> ➤ ● ➤ Yes ➤ ●

■ Information Pages

Changing Display Size	On a page, ☐ ➤ <i>Settings</i> ➤ ● ➤ <i>Display Size</i> ➤ ● ➤ Select size ➤ ●
Changing scroll unit	On a page, ☐ ➤ <i>Settings</i> ➤ ● ➤ <i>Scroll Unit</i> ➤ ● ➤ Select unit ➤ ●
Copying text	On a page, ☐ ➤ <i>Copy Text</i> ➤ ● ➤ Select first character ➤ ● ➤ Highlight text range ➤ ●
Saving files to Data Folder	On a page, ☐ ➤ <i>Save Items</i> ➤ ● ➤ Select file ➤ ● ➤ <i>Save</i> ➤ ● ➤ Enter name ➤ ● ➤ <i>Save here</i> ➤ ● • Some files are saved automatically.
Opening page properties	On a page, ☐ ➤ <i>Details</i> ➤ ●



Weather Indicators

Checking weather forecast	● → Entertainment → ● → SI Information Channel/Weather → ● → Weather Indicator → ● → Weather → ●
Changing weather forecast page font size	On a page, ☐ → Settings → ● → Font Size → ● → Select size → ●
Hiding Weather Indicator in Standby	● → Entertainment → ● → SI Information Channel/Weather → ● → Weather Indicator → ● → Settings → ● → Standby Setting → ● → Off → ●
Canceling Weather Indicator automatic updates	● → Entertainment → ● → SI Information Channel/Weather → ● → Weather Indicator → ● → Settings → ● → Icon Update → ● → Off → ●
Hiding Information window for weather updates	● → Entertainment → ● → SI Information Channel/Weather → ● → Weather Indicator → ● → Settings → ● → Weather Notif. → ● → Off → ●

e-Books

Copying text	In open page, ㉞ → 文字列を北' → ● → Select first character → ● → Highlight text range → ●
Opening non-936SH e-Books (Library)	● → Entertainment → ● → e-Book Viewer → ☐ → Select file → ● • Some files may not open.
Using Library	[Start Here] ● → Entertainment → ● → e-Book Viewer → ☐ → See below
	Adding Folders ☐ → New Folder → ● → Enter name → ●
	Switching Folders ☐ → Switch Folders → ● → Select folder → ●
	Renaming Folders/Files Select folder/file → ☐ → Rename → ● → Enter name → ●
	Moving Files Select file → ☐ → Move → ● → Select folder → ● → Move here → ●
	Deleting Folders/Files Select folder/file → ☐ → Delete → ● → Yes → ●
	Opening File Properties Select file → ☐ → Details → ●



S! Friend's Status

■ Members & Groups

Adding members	(Long) → Select Group → Add Member → Select method → Select entry or enter phone number → Yes → Select
Deleting members	(Long) → Select Group → Select member → Registration Release → Yes → Yes → Select <ul style="list-style-type: none"> • Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	(Long) → Select Group → Select member → Change Group → Select target Group → Select
Renaming Groups	(Long) → Select Group → Edit Group Name → Enter name → Select
Rejecting requests	Start Here (Long) → Settings → Status → Request Reply → See below Rejecting Requests from Unsaved Numbers Confirm if Registered → Confirm <ul style="list-style-type: none"> • Rejection notice is sent to rejected numbers automatically. Rejecting All Requests Always Ignore → Always Ignore <ul style="list-style-type: none"> • Rejection notice is sent to all requesters automatically.

■ Status & Availability

Saving custom Availability combinations	(Long) → Settings → Answer Status → User Setting → Select type → Select Availability → Select
Changing Status Icon Pictogram or Status Label description	(Long) → Settings → Status Setting → Select template → Select Status → Status Icon → Select Pictogram → Status Label → Enter text → Select

■ Status Templates

Resetting templates	Start Here (Long) → 私の状況 → Select Status → See below One Template Select template → Reset → Yes → Select All Templates Reset All → Yes → Select
---------------------	---

■ Member Status & Notices

Updating manually	(Long) → Settings → Status Update → Update
Opening notices	(Long) → Status Notif. List → Select notice → Select

■ My Details

Sending My Details image	(Long) → Select Group → Select member → Send Image → Yes → Select <ul style="list-style-type: none"> • Available when your handset number is saved in Phone Book on member's handset.
--------------------------	---



S! Circle Talk

■ Member List

Editing individual members	<p>[Start Here] → Communication → S! Circle Talk → Select member → See below</p> <p>Replacing Members</p> <p>Edit → Select method → Select entry</p> <p>Deleting Members</p> <p>Delete → Yes</p>
	<p>[Start Here] → Communication → S! Circle Talk → Select Group → See below</p> <p>Editing Group Name/Members</p> <p>Edit → Select target → Edit/enter</p> <p>Deleting Group Members</p> <p>Edit → Select member → Delete → Yes</p> <p>Deleting Groups</p> <p>Delete → Yes</p>

■ Settings

Disabling Loudspeaker	Communication → S! Circle Talk → Loudspeaker → Off
Exiting S! Circle Talk for incoming calls	Communication → S! Circle Talk → Incoming Calls → Voice Calls or Video Calls → Accept Calls

Blog Tool

Editing entries	Communication → Blog Tool → Select entry → Edit → Select item → Edit → Blog Title after editing.
Deleting entries	Communication → Blog Tool → Select entry → Delete → Yes





S! Friend's Status

? Cannot use S! Friend's Status

- Set IP Service Setting to *On*.

? Handset rejected a registration request automatically

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

? Registration request arrived from a deleted member

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

? Registration request was sent to a member automatically

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

? Cannot create Status Templates

- Three templates may already be added; reset one and retry.

S! Circle Talk

? Cannot use S! Circle Talk

- Set IP Service Setting to *On*.

? S! Circle Talk starts automatically

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Auto Join*.

? Cannot accept S! Circle Talk requests

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Join NG*.

Near Chat

? Cannot receive Near Chat requests

- S! Appli Request may be set to *Off*.

S! Quick News

? Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.