

|  |             |
|--|-------------|
| <b>S! Quick News</b> .....                                     | <b>12-2</b> |
| Receiving Content Updates<br>(Japanese) .....                  | 12-2        |
| <b>S! Information Channel</b> .....                            | <b>12-3</b> |
| S! Information Channel & Weather<br>Indicator (Japanese) ..... | 12-3        |
| <b>Content Downloads</b> .....                                 | <b>12-4</b> |
| Downloading Content (Japanese)<br>.....                        | 12-4        |
| <b>e-Books</b> .....   | <b>12-5</b> |
| Reading e-Books (Japanese) .....                               | 12-5        |

|                                   |              |
|-----------------------------------|--------------|
| <b>S! Friend's Status</b> .....   | <b>12-6</b>  |
| Using S! Friend's Status .....    | 12-6         |
| <b>S! Circle Talk</b> .....       | <b>12-9</b>  |
| Using S! Circle Talk .....        | 12-9         |
| <b>Near Chat</b> .....            | <b>12-11</b> |
| Using Near Chat (Japanese).....   | 12-11        |
| <b>Blog Tool</b> .....            | <b>12-12</b> |
| Blogging .....                    | 12-12        |
| <b>Additional Functions</b> ..... | <b>12-14</b> |
| <b>Troubleshooting</b> .....      | <b>12-18</b> |

# 12

## Entertainment



## Receiving Content Updates (Japanese)

View content updates or breaking news.  
Packet transmission fees apply (except when downloading via Wi-Fi).

### Registering S! Quick News Items

- 1 → **Entertainment** → → **S! Quick News** →



S! Quick News Menu

- 2 **S! Quick News List** →



S! Quick News List

- 3 **登録はこちら** → → **Yes** →

- Handset connects to the Internet.

- 4 **Select item** →


- Follow onscreen instructions.

### Opening Information

- 1 **In S! Quick News List, select item** →

- Title list appears.

- 2 **Select title** →



- Press to return to title list, or to open next title.

### Updating Items Manually

[S! Quick News List] Select item →

→ **更新** → → **一件** or **全件** →

### Indicators

|  |                     |  |                      |
|--|---------------------|--|----------------------|
|  | Unread Special news |  | Unread General news  |
|  | Read Special news   |  | Read General news    |
|  | Unread News Flash   |  | Auto update disabled |
|  | Read News Flash     |  |                      |

### Advanced

- Updating S! Quick News List automatically
- Checking update schedule
- Deleting S! Quick News items
- Resetting S! Quick News List
- Changing background image
- Accessing source sites
- Disabling image download (P.12-14)




## S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed. Packet transmission fees apply.

### Service Registration & Content Subscription

- 1** **Entertainment** **S! Information Channel/Weather**



S! Information Channel Menu

- 2** **Registration/Cancel**
- Handset connects to the Internet. Follow onscreen instructions.

### New Received Information

Information window opens for new S! Information Channel info delivery.

**1** **While Information window appears, S! Info. Channel**



- S! Information Channel page opens. Follow onscreen instructions.
- S! Information Channel page handling is similar to that of Yahoo! Keitai.

**2**



### Standby returns

#### Opening Unread Latest Issue

[S! Information Channel Menu]

*What's New*

#### Opening Back Issues

[S! Information Channel Menu] *Back Issue*

**Select date**

### Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

#### Manual Update

[S! Information Channel Menu]

*Weather Indicator*

*Update* **Yes**

### Advanced

- Suppressing Information window for new received info Changing Display Size Changing scroll unit Copying text Hiding Weather Indicator in Standby Canceling Weather Indicator automatic updates Suppressing Information window for weather updates (And more on P.12-14 - 12-15)



## Downloading Content (Japanese)

Download media content via Yahoo! Keitai.

### Via S! Contents Store

1 **Entertainment**



Entertainment Menu

2 **S! Contents Store**

- Handset connects to the Internet.  
Follow onscreen instructions.

### Via Free Content Providers

Download free Graphic Mail templates, e-Books, games, etc.

Content downloads are free, however, they require Internet connection incurring packet transmission fees (except when downloading via Wi-Fi).

1 **In Entertainment menu,**  
**Free Contents**



2 **Select provider**

- Handset connects to the Internet.  
Follow onscreen instructions.



# Reading e-Books (Japanese)

## Downloading e-Books

1 ● ➔ **Entertainment** ➔ ●



Entertainment Menu

2 **S! Contents Store** ➔ ●

- Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

### Note

- Alternatively, go to SH-web Mobile Internet site ([携帯電話メーカーサイトSH-web](#)) in Bookmarks; see P.6-9) for e-Books.

### Downloading Free E-Books

In ●, **Free Contents** ➔ ● ➔  
**Tada-Hon** or **Tada-Komi** ➔ ●

- Follow onscreen instructions.

## e-Book Viewer

Read XPDF books and dictionary files. Some files may not be supported.

1 In Entertainment menu, **e-Book Viewer** ➔ ●

- e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

## Digital Media Viewer

Read digital magazines and newspapers. Some files may not be supported.

1 In Entertainment menu, **Digital Media Viewer** ➔ ●

- Digital Media Viewer starts. Refer to the Digital Media Viewer help menu for operational instructions.

## BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1 In Entertainment menu, **BookSurfing** ➔ ●

- BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

### Moving CCF Files via Memory Card

- When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

## Advanced

- ☞ ● Copying text ● Opening non-940SH e-Books (Library) ● Using Library (P.12-15)



## Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.


- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to **Online** first.

### First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.



- 1** **Entertainment** **S! Friend's Status**




- 2** **Yes**



- 3** **Yes**

- 4** **Phone Book**

- 5** **Select entry** **Select phone number**



- Omit number selection step if only one number is saved.

- 6** **Yes**

- Registration request is sent to the number.

### When Request is Accepted

- An acceptance notice arrives; My Status is sent and member's status appears on handset.

### Direct Entry

- In **4**, **Add New Entry** **Enter phone number** **6**

### Advanced

- Adding members
- Deleting members
- Moving members
- Renaming Groups
- Rejecting requests
- Updating manually
- Opening notices
- Sending My Details image (And more on P.12-16 - 12-17)



## Opening Member Status

- 1 → **Entertainment** → → **S! Friend's Status** → → → **Select Group**



My Status

Member Status

- 2 **Select member** →




## When Cancellation Notice Arrives

- Member is deleted from S! Friend's Status member list.

## Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.


- 1 → **Entertainment** → → **S! Friend's Status** → → → **私の状況** →



Connection Status

My Status Window

- 2 **Select Status, e.g., ごきげん** →



Status Template Window

- 3 **Select new Status** →
- 4 **Select Availability, e.g., Answer OK** → → **Select new Availability** →
- 5 **<Add Comment>** → → **Enter text** →
- 6 → **Update starts**

## Changing Connection Status

[My Status Window] **Online (or Offline)** → → **Select status** →

## Changing Status Icon/Label

[Status Template Window] **Select Status** → → **Status Icon or Status Label** → → **Select Pictogram or enter text** → →

**Changing Availability Settings at Once** In 4, **Answer Status** → → **Select new Answer Status** → → **From**


## Editing My Status Name

[My Status Window] → **Edit Name** → → **Edit** →



## Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.



### 1 Yes → ●

- Acceptance notice is sent; the number is registered.

### Rejecting

In 1, No → ● → Yes → ●

- Rejection notice is sent; the number cannot be registered for 24 hours.
- For **ConfirmLater**, Information window opens.

## Creating Status Templates

Save custom combinations of Status Icon and Status Label to each template.




### 1 In Status Template window,

☒ → **New Entry** → ●

### 2 Enter name → ●

### 3 <未定> → ●



### 4 Status Icon → ● → Select Pictogram → ●

### 5 Status Label → ● → Enter text → ● → Y7

### 6 Repeat 3 - 5 → ● → Y7 → Saved

### Saving to Data Folder

[Status Template Window] ☒ Select template → ☒ → **Save to DF** → ●

→ **Save here** → ●

### Loading Templates via Data Folder

[Status Template Window] ☒ → **Add Template** → ● → Select template

→ ●

### Renaming Templates

[Status Template Window] ☒ Select template → ☒ → **Edit Temp. Name**

→ ● → Enter name → ●

## Advanced

- ☒ ● Resetting templates (P.12-16)





## Using S! Circle Talk


Use handset like a walkie-talkie to speak to multiple parties simultaneously.

- A subscription to S! Friend's Status is required.
- Packet transmission fees apply during S! Circle Talk.

### Registering Members

Follow these steps to register a number saved in Phone Book:

- 1 → **Entertainment** → → **S! Circle Talk** →
  - When registering a member for the first time, a confirmation appears. Choose **Yes** and press , then skip ahead to 2.
- 2 **<Add New Entry>** →



- 3 **Group** → → **Group**  
**Name:** → → **Enter name**  
 →



- 4 **Select number, e.g., No.1:**  
 →

- 5 **Phone Book** →

- 6 **Select entry** → → **Select phone number** →



- Omit number selection step if only one number is saved.
- Repeat 4 - 6 to add members.

- 7 → **Saved**

### Saving as Individuals

- In , **Individual** → → -
- In , **Members List** → → **Select member** → →
- Omit when **Individual** is selected in .

### Advanced

- Editing individual members Editing Groups (P.12-17)



## Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:  
 (First, set Connection status to *Online* (P.12-7).)

- 1 ➔ **Entertainment** ➔ ➔ **S! Circle Talk** ➔



- 2 **Select member or Group** ➔

- 3 ➔ **Transmission starts**

- S! Circle Talk starts when request is accepted by a receiver.
- Loudspeaker activates automatically.

### Direct Entry

Enter phone number ➔ ➔ **Call**  
**S! Circle Talk** ➔ ➔

## S! Circle Talk Operations

### Speaking

- 1 **Press and hold** **when**  
**Press and Hold** **appears**  
 ➔ **You have the floor**



- : **My Turn** appears when you have the floor.

- 2 **Keep holding** **to speak**  
 ➔ **Release** ➔ **Floor is released**  
 • Warning tone sounds before time limit.

### Incoming Calls during S! Circle Talk

- Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.

### Canceling Loudspeaker

**During S! Circle Talk,**

- To reactivate, follow these steps:  
 ➔ **While message appears,**

## Exiting S! Circle Talk

- 1 ➔ **Connection ends**  
 • S! Circle Talk ends automatically when there is only one participant left, including yourself.

### Rejoining S! Circle Talk

- ➔ ➔ **Select most recent S! Circle Talk record** ➔ ➔ **Rejoin Circle Talk** ➔
- Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

## Accepting S! Circle Talk Request

- 1 **While handset is ringing/vibrating,** ➔ **S! Circle Talk starts**  
 • Alternatively, press .
- S! Circle Talk Operations: left

## Advanced

- Disabling Loudspeaker Exiting S! Circle Talk for incoming calls (P.12-17)



## Using Near Chat (Japanese)

Exchange real-time text messages wirelessly with compatible Bluetooth® devices within ten meters. (Available even when handset is out-of-range.) Because this application employs Bluetooth® wireless technology transmission/connection fees do not apply.

### Access Restriction



- In the event that this handset may be used by a minor, access to this application may be password restricted by a supervising adult. In this case, Handset Code access must also be managed to prevent the execution of Memory All Clear that may be used to reset the application password.

### Sending Near Chat Request

- 1  ➔ **Entertainment** ➔  ➔ **Near chat** ➔ 




- 2 **Yes** ➔ 

- Near Chat S! Application starts.
- A confirmation appears. Read the message and press  (はい) or  (いいえ).
- For more, see Near Chat S! Application instructions.



### Receiving Near Chat Request

When a Near Chat request arrives, a tone sounds and S! Appli Notification appears.




After a period of inactivity, Information window opens, tone sounds and notification appears.

- 1 **Yes** ➔ 

- Near Chat S! Application starts.
- A confirmation appears. Read the message and press  (はい) or  (いいえ).
- For more, see Near Chat S! Application instructions.

### Rejecting Request

- 1 **In**, **No** ➔ 



## Blogging

Save blog details to view or update blogs easily on handset.

### Saving Blog Details

#### Setup for Posting via Mail

Follow these steps to save blog name and address for posting:

- 1 **Entertainment** → **Blog Tool**



Blog Tool Window


- 2 **Add New Entry**



Blog Setting Menu

- 3 **Blog Title** → **Enter name**

- 4 **Blog by send Mail**



Blog Setting Menu (Mail)

- 5 **Blog's Email Address** → **Enter mail address**

- 6 **CLEAR/BACK** → **Yr**

#### Saving Title/Text for Posts

- After **ESC**, **Blog's Title** or **Blog's Text** → **Enter title or text**
- Saved title/text is entered automatically when posting.


#### Setting Image Size for Posting

- After **ESC**, **Picture Size** → **Select size**

#### Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC sites, or both.

- 1 **In Blog Setting menu, Refer/Send by Yahoo! Keitai or Refer/Send by PC Site/Direct Browser**



- 2 **Blog's URL** → **Enter URL**

- 3 **Refer Blog's URL** → **Enter URL**

- 4 **CLEAR/BACK** → **Yr**




### Advanced

- Editing entries
- Deleting entries (P.12-17)

## Posting to Blogs

Complete setup for posting via mail/  
Internet beforehand.

### Posting via Mail

- 1 In Blog Tool window, select entry ➔ 
- 2 *Blog by send Mail* ➔ 
  - S! Mail Composition window opens with address entered.
  - Omit 2 if no URL is saved for posting.
- 3 Complete message ➔ 


### Posting via the Internet

- 1 In Blog Tool window, select entry ➔ 
- 2 *Blog by send Browser* ➔ 
  - Page of URL saved in *Blog's URL* opens.
  - Omit 2 if no address is saved for posting.
  - If PC Site Browser message appears, follow onscreen prompts.


When URLs for Yahoo! Keitai & PC Sites are Saved

After 2, select browser ➔ 

### Opening Blog Page

- 1 In Blog Tool window, select entry ➔ 
  - Page of URL saved in *Refer Blog's URL* opens.
  - If PC Site Browser message appears, follow onscreen prompts.

When URLs for Yahoo! Keitai & PC Sites are Saved

After 1, select browser ➔ 



## S! Quick News

### Opening/Updating Items

|   |  |
|---|--|
| Updating S! Quick News List automatically | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Automatic Update</i> → <input type="radio"/> → <i>Select item</i> → <input type="radio"/> → <i>Select interval or choose On</i> → <input type="radio"/> </p> <ul style="list-style-type: none"> <li>• If a confirmation appears after completing above, press <input type="radio"/>.</li> <li>• When selecting an item set to <i>Off</i>, a confirmation appears.</li> <li>• When Special is set to <i>On</i>, items are updated every four hours.</li> <li>• When General is set to <i>On</i>, items are updated once a day.</li> <li>• Updating items may incur high packet transmission fees.</li> <li>• Only available in Japan.</li> </ul> |
| Checking update schedule                  | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Check Schedule</i> → <input type="radio"/> </p>   |
| Deleting S! Quick News items              | <p> <input type="radio"/> → <i>Start Here</i> → <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>S! Quick News List</i> → <input type="radio"/> → <i>Select item</i> → <input type="radio"/> → <i>See below</i> </p> <p><b>One Entry</b></p> <p>一件 → <input type="radio"/> → <i>Yes</i> → <input type="radio"/></p> <p><b>All Entries</b></p> <p>全件 → <input type="radio"/> → <i>Enter Handset Code</i> → <input type="radio"/> → <i>Yes</i> → <input type="radio"/></p>   |
| Resetting S! Quick News List              | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Delete S! Quick News Lists</i> → <input type="radio"/> → <i>Enter Handset Code</i> → <input type="radio"/> → <i>Yes</i> → <input type="radio"/> </p> <ul style="list-style-type: none"> <li>• Not available during automatic updates.</li> </ul>  |

### Other

|                           |   |
|---------------------------|---|
| Changing background image | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Change Skin</i> → <input type="radio"/> → <i>Select pattern</i> → <input type="radio"/> </p>   |
| Accessing source sites    | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>S! Quick News List</i> → <input type="radio"/> → <i>Select item</i> → <input type="radio"/> → <i>Select title</i> → <input type="radio"/> → <i>Select linked title</i> → <input type="radio"/> → <i>Yes</i> → <input type="radio"/> </p> |
| Disabling image download  | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Quick News</i> → <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Show Image</i> → <input type="radio"/> → <i>Off</i> → <input type="radio"/> </p>   |

## S! Information Channel

### Receiving Information

|  |   |
|--|---|
| Suppressing Information window for new received info | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Information Channel/Weather</i> → <input type="radio"/> → <i>Notification</i> → <input type="radio"/> → <i>Off</i> → <input type="radio"/> </p>        |
| Requesting re-delivery                               | <p> <input type="radio"/> → <i>Entertainment</i> → <input type="radio"/> → <i>S! Information Channel/Weather</i> → <input type="radio"/> → <i>Get Latest Contents</i> → <input type="radio"/> → <i>Yes</i> → <input type="radio"/> </p> |

### Information Pages

|                       |  |
|-----------------------|--|
| Changing Display Size | <p>             On a page, <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Display Size</i> → <input type="radio"/> → <i>Select size</i> → <input type="radio"/> </p> |
| Changing scroll unit  | <p>             On a page, <input type="radio"/> → <i>Settings</i> → <input type="radio"/> → <i>Scroll Unit</i> → <input type="radio"/> → <i>Select unit</i> → <input type="radio"/> </p>  |



|                             |  |
|-----------------------------|--|
| Copying text                | On a page,  → <i>Copy Text</i> →  →  → Select first character →  → Highlight text range →  →                       |
| Saving files to Data Folder | On a page,  → <i>Save Items</i> →  →  → Select file →  → <i>Save</i> →  → Enter name →  →  → <i>Save here</i> →  → |
| Opening page properties     | On a page,  → <i>Details</i> →  →  |

## Weather Indicators

|  |   |
|--|---|
| Checking weather forecast                          | → <i>Entertainment</i> →  →  → <i>S! Information Channel/Weather</i> →  → <i>Weather Indicator</i> →  →  → <i>Weather</i> →  →  |
| Changing weather forecast page font size           | On a page,  → <i>Settings</i> →  →  → <i>Font Size</i> →  →  → Select size →  →   |
| Hiding Weather Indicator in Standby                | → <i>Entertainment</i> →  →  → <i>S! Information Channel/Weather</i> →  → <i>Weather Indicator</i> →  →  → <i>Settings</i> →  →  → <i>Standby Setting</i> →  →  → <i>Off</i> →  →   |
| Canceling Weather Indicator automatic updates      | → <i>Entertainment</i> →  →  → <i>S! Information Channel/Weather</i> →  → <i>Weather Indicator</i> →  →  → <i>Settings</i> →  →  → <i>Icon Update</i> →  →  →  → <i>Off</i> →  →    |
| Suppressing Information window for weather updates | → <i>Entertainment</i> →  →  → <i>S! Information Channel/Weather</i> →  → <i>Weather Indicator</i> →  →  → <i>Settings</i> →  →  → <i>Weather Notif.</i> →  →  →  → <i>Off</i> →  → |

## e-Books

|                                     |  |
|-------------------------------------|--|
| Copying text                        | In open page,  → <i>文字列を北</i> →  →  → Select first character →  →  → Highlight text range →  →             |
| Opening non-940SH e-Books (Library) | → <i>Entertainment</i> →  →  → <i>e-Book Viewer</i> →  →  → <i>Select file</i> →  →                        |
| Using Library                       | → <i>Start Here</i> →  →  → <i>Entertainment</i> →  →  → <i>e-Book Viewer</i> →  →  → See below            |
|                                     | <b>Adding Folders</b><br>→ <i>New Folder</i> →  →  → Enter name →  →                                       |
|                                     | <b>Switching Folders</b><br>→ <i>Switch Folders</i> →  →  → Select folder →  →                             |
|                                     | <b>Renaming Folders/Files</b><br>Select folder/file →  →  → <i>Rename</i> →  →  → Enter name →  →          |
|                                     | <b>Moving Files</b><br>Select file →  →  → <i>Move</i> →  →  → Select folder →  →  → <i>Move here</i> →  → |
|                                     | <b>Deleting Folders/Files</b><br>Select folder/file →  →  → <i>Delete</i> →  →  →  →  → <i>Yes</i> →  →    |
|                                     | <b>Opening File Properties</b><br>Select file →  →  → <i>Details</i> →  →                                  |



## S! Friend's Status

## ■ Members &amp; Groups

|                    |   |
|--------------------|---|
| Adding members     | <p>● → Entertainment → ● → S! Friend's Status → ● → Select Group → Add Member → ● → Select method → ● → Select entry or enter phone number → ● → Yes → ●</p>  |
| Deleting members   | <p>● → Entertainment → ● → S! Friend's Status → ● → Select Group → Select member → Registration Release → ● → Yes → ● → Yes → ●</p> <p>• Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.</p> |
| Moving members     | <p>● → Entertainment → ● → S! Friend's Status → ● → Select Group → Select member → Change Group → ● → Select target Group → ●</p>   |
| Renaming Groups    | <p>● → Entertainment → ● → S! Friend's Status → ● → Select Group → Edit Group Name → ● → Enter name → ●</p>   |
| Rejecting requests | <p><b>Start Here</b> ● → Entertainment → ● → S! Friend's Status → ● → Settings → ● → Request Reply → ● → See below</p>  |
|                    | <p><b>Rejecting Requests from Unsaved Numbers Confirm if Registered</b> → ●</p> <p>• Rejection notice is sent to rejected numbers automatically.</p>  |
|                    | <p><b>Rejecting All Requests Always Ignore</b> → ●</p> <p>• Rejection notice is sent to all requesters automatically.</p>   |

## ■ Status &amp; Availability

|  |  |
|--|--|
| Saving custom Availability combinations                    | <p>● → Entertainment → ● → S! Friend's Status → ● → Settings → Answer Status → ● → User Setting → ● → Select type → ● → Select Availability → ● → Y</p>  |
| Changing Status Icon Pictogram or Status Label description | <p>● → Entertainment → ● → S! Friend's Status → ● → Settings → Status Setting → ● → Select template → Select Status → ● → Status Icon → ● → Select Pictogram → ● → Status Label → ● → Enter text → ● → Y</p> |

## ■ Status Templates

|                     |  |
|---------------------|--|
| Resetting templates | <p><b>Start Here</b> ● → Entertainment → ● → S! Friend's Status → ● → 私の状況 → ● → Select Status → ● → See below</p> |
|                     | <p><b>One Template</b></p> <p>● → Select template → ● → Reset → ● → Yes → ●</p>                                    |
|                     | <p><b>All Templates</b></p> <p>● → Reset All → ● → Yes → ●</p>   |

## ■ Member Status &amp; Notices

|                   |  |
|-------------------|--|
| Updating manually | <p>● → Entertainment → ● → S! Friend's Status → ● → Settings → ● → Status Update → ●</p>           |
| Opening notices   | <p>● → Entertainment → ● → S! Friend's Status → ● → Status Notif. List → ● → Select notice → ●</p> |





## ■ My Details

|                          |  |
|--------------------------|--|
| Sending My Details image | <ul style="list-style-type: none"> <li>● → Entertainment → ● → S! Friend's Status</li> <li>→ ● → Select Group → Select member →</li> <li>☺ → Send Image → ● → Yes → ●</li> </ul> |
|                          | <ul style="list-style-type: none"> <li>• Available when your handset number is saved in Phone Book on member's handset.</li> </ul>   |

## S! Circle Talk

### ■ Member List

|                            |   |
|----------------------------|---|
| Editing individual members | <ul style="list-style-type: none"> <li><b>Start Here</b> ● → Entertainment → ● → S! Circle Talk → ● → Select member → ☺ → See below</li> </ul>  |
|                            | <p><b>Replacing Members</b></p> <ul style="list-style-type: none"> <li>Edit → ● → Select method → ● → Select entry → ●</li> </ul>               |
|                            | <p><b>Deleting Members</b></p> <ul style="list-style-type: none"> <li>Delete → ● → Yes → ●</li> </ul>   |
| Editing Groups             | <ul style="list-style-type: none"> <li><b>Start Here</b> ● → Entertainment → ● → S! Circle Talk → ● → Select Group → ☺ → See below</li> </ul>   |
|                            | <p><b>Editing Group Name/Members</b></p> <ul style="list-style-type: none"> <li>Edit → ● → Select target → ● → Edit/enter → ● → Yr</li> </ul>   |
|                            | <p><b>Deleting Group Members</b></p> <ul style="list-style-type: none"> <li>Edit → ● → Select member → ☺ → Delete → ● → Yes → ● → Yr</li> </ul> |
|                            | <p><b>Deleting Groups</b></p> <ul style="list-style-type: none"> <li>Delete → ● → Yes → ●</li> </ul>  |

## ■ Settings

|                       |   |
|-----------------------|---|
| Disabling Loudspeaker | <ul style="list-style-type: none"> <li>● → Entertainment → ● → S! Circle Talk → ● → ☺ → Loudspeaker → ● → Off → ●</li> </ul>  |
|                       | <ul style="list-style-type: none"> <li>● → Entertainment → ● → S! Circle Talk → ● → ☺ → Incoming Calls → ● → Voice Calls or Video Calls → ● → Accept Calls → ●</li> </ul> |

## Blog Tool

|                 |  |
|-----------------|--|
| Editing entries | <ul style="list-style-type: none"> <li>● → Entertainment → ● → Blog Tool → ● → Select entry → ☺ → Edit → ● → Select item → ● → Edit → ☺ → Yr</li> <li>• For <b>Blog Title</b>, omit step of pressing ☺ after editing.</li> </ul> |
|                 | <ul style="list-style-type: none"> <li>● → Entertainment → ● → Blog Tool → ● → Select entry → ☺ → Delete → ● → Yes → ●</li> </ul>  |



## S! Friend's Status

### ? Cannot use S! Friend's Status

- Set IP Service Setting to **On**.

### ? Handset rejected a registration request automatically

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

### ? Registration request arrived from a deleted member

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

### ? Registration request was sent to a member automatically

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

### ? Cannot create Status Templates

- Three templates may already be added; reset one and retry.

## S! Circle Talk

### ? Cannot use S! Circle Talk

- Set IP Service Setting to **On**.

### ? S! Circle Talk starts automatically

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to **Auto Join**.

### ? Cannot accept S! Circle Talk requests

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to **Join NG**.

## Near Chat

### ? Cannot receive Near Chat requests

- S! Appli Request may be set to **Off**.

## S! Quick News

### ? Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.

