

S! Quick News	12-2
Receiving Content Updates (Japanese)	12-2
S! Information Channel	12-3
S! Information Channel & Weather Indicator (Japanese)	12-3
Content Downloads	12-4
Downloading Content (Japanese)....	12-4
e-Books	12-5
Reading e-Books (Japanese)	12-5

S! Friend's Status	12-6
Using S! Friend's Status	12-6
S! Circle Talk	12-9
Using S! Circle Talk	12-9
Near Chat	12-11
Using Near Chat (Japanese)	12-11
Blog Tool	12-12
Blogging	12-12
Additional Functions	12-14
Troubleshooting	12-18

12

Entertainment



Receiving Content Updates (Japanese)

View content updates or breaking news.
Packet transmission fees apply (except when downloading via Wi-Fi).

Registering S! Quick News Items

- MENU** ➔ **Entertainment** ➔ **S! Quick News**



S! Quick News Menu

- S! Quick News List**



S! Quick News List

- 登録はこちら** ➔ **Yes**

- Handset connects to the Internet.

- Select item**


- Follow onscreen instructions.

Opening Information

- In S! Quick News List, select item**

- Title list appears.

- Select title**



- Tap **一覧** to return to title list, or **次へ** to open next title.

Updating Items Manually

[S! Quick News List] Highlight item

➔ **メニュー** ➔ **更新** ➔ **一件** or **全件**

Indicators

	Unread Special news		Unread General news
	Read Special news		Read General news
	Unread News Flash		Auto update disabled
	Read News Flash		

Advanced

- Updating S! Quick News List automatically
- Checking update schedule
- Deleting S! Quick News items
- Resetting S! Quick News List
- Setting background image
- Accessing source sites
- Disabling image download (P.12-14)



S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed. Packet transmission fees apply.

Service Registration & Content Subscription

- MENU** → *Entertainment* → *S! Information Channel/Weather*



S! Information Channel Menu

- Registration/Cancel**
 - Handset connects to the Internet. Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

- While Information window appears, S! Info. Channel**
 - S! Information Channel page opens. Follow onscreen instructions.
 - S! Information Channel page handling is similar to that of Yahoo! Keitai.

- END** → Standby returns

Opening Unread Latest Issue

[S! Information Channel Menu]
What's New

Opening Back Issues

[S! Information Channel Menu] *Back Issue* → Select date

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

Manual Update

[S! Information Channel Menu]
Weather Indicator → *Manual Update*
→ Yes

Advanced

- Suppressing Information window for new received info
- Setting Display Size
- Setting scroll unit
- Copying text
- Hiding Weather Indicator in Standby
- Canceling Weather Indicator automatic updates
- Suppressing Information window for weather updates (And more on P.12-14 - 12-15)



Downloading Content (Japanese)

Download media content via Yahoo! Keitai.

Via S! Contents Store

1 MENU ➔ Entertainment



Entertainment Menu

2 S! Contents Store

- Handset connects to the Internet.
Follow onscreen instructions.

Via Free Content Providers

Download free Graphic Mail templates, e-Books, games, etc.

Content downloads are free, however, they require Internet connection incurring packet transmission fees (except when downloading via Wi-Fi).

1 In Entertainment menu, Free Contents



2 Select provider

- Handset connects to the Internet.
Follow onscreen instructions.



Reading e-Books (Japanese)

Downloading e-Books

1 MENU ➔ Entertainment



Entertainment Menu


2 S! Contents Store

- Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

Note

- Alternatively, go to SH-web Mobile Internet site ([シャープ メーカーサイトSH-web](#)) in Bookmarks; see P.6-9) for e-Books.

Downloading Free E-Books

In , **Free Contents** ➔ **Tada-Hon** or **Tada-Komi**

- Follow onscreen instructions.

e-Book Viewer

Read XPDF books and dictionary files. Some files may not be supported.

1 In Entertainment menu, e-Book Viewer

- e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

Digital Media Viewer

Read digital magazines and newspapers. Some files may not be supported.

1 In Entertainment menu, Digital Media Viewer

- Digital Media Viewer starts. Refer to the Digital Media Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.


1 In Entertainment menu, BookSurfing

- BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card

- When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Advanced

-  ● Copying text ● Opening non-941SH e-Books (Library) ● Using Library (P.12-15)



Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.


- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set Connection status to **Online** first.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.



1 MENU → Entertainment → S! Friend's Status




2 Yes



3 Yes

4 Phone Book

5 Select entry → Select phone number



- Omit number selection step if only one number is saved.

6 Yes

- Registration request is sent to the number.

When Request is Accepted

- An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry

In 4, **Add New Entry** → Enter phone number → Done → 6

Advanced

- Adding members
- Deleting members
- Moving members
- Renaming Groups
- Rejecting requests
- Updating manually
- Opening notices
- Sending My Details image (And more on P.12-16 - 12-17)



Opening Member Status

- 1 **MENU** ➔ **Entertainment** ➔ **S! Friend's Status** ➔ **Select Group**



- To select Group, tap ◀ or ▶.

- 2 **Select member**



When Cancellation Notice Arrives

- Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.

- 1 **MENU** ➔ **Entertainment** ➔ **S! Friend's Status** ➔ **私の状況**



My Status Window

- 2 **Select Status, e.g., ごきげん**



Status Template Window

- 3 **Select new Status**
- 4 **Select Availability, e.g., Answer OK** ➔ **Select new Availability**
- 5 **<Add Comment>** ➔ **Enter text** ➔ **Done**
- 6 **Update** ➔ **Update starts**

Changing Connection Status

[My Status Window] **Online** (or **Offline**) ➔ **Select status**

Changing Status Icon/Label

[Status Template Window] **Highlight Status** ➔ **Edit** ➔ **Status Icon** or **Status Label** ➔ **Select Pictogram** or **enter text** ➔ **Save**

Setting Availability Settings at Once

In 4, **Answer Status** ➔ **Select new Answer Status** ➔ **From**


Editing My Status Name

[My Status Window] **Options** ➔ **Edit Name** ➔ **Edit** ➔ **Done**



Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.



1 Yes

- Acceptance notice is sent; the number is registered.


Rejecting

In 1, **No** ➔ **Yes**

- Rejection notice is sent; the number cannot be registered for 24 hours.
- For **ConfirmLater**, Information window opens.

Creating Status Templates


Save custom combinations of Status Icon and Status Label to each template.



1 In Status Template window, **Options** ➔ **New Entry**

2 Enter name ➔ **Done**

3 <未定>



4 **Status Icon** ➔ **Select Pictogram**

5 **Status Label** ➔ Enter text ➔ **Done** ➔ **OK**

6 Repeat 3 - 5 ➔ **Save** ➔ **Saved**

Saving to Data Folder

[Status Template Window] Highlight tab (template) ➔ **Options** ➔ **Save to DF** ➔ **Save here**

Loading Templates via Data Folder

[Status Template Window] **Options** ➔ **Add Template** ➔ Select template

Renaming Templates

[Status Template Window] Highlight tab (template) ➔ **Options** ➔ **Edit Temp. Name** ➔ Enter name ➔ **Done**

Advanced

- Resetting templates (P.12-16)



Using S! Circle Talk


Use handset like a walkie-talkie to speak to multiple parties simultaneously.

- A subscription to S! Friend's Status is required.
- Packet transmission fees apply during S! Circle Talk.


Registering Members

Follow these steps to register a number saved in Phone Book:

- 1 MENU** → **Entertainment** → **S! Circle Talk**
 - When registering a member for the first time, a confirmation appears. Tap **Yes**, then skip ahead to 3.
- 2 <Add New Entry>**



- 3 Group** → **Group Name:** → **Enter name** → **Done**



- 4 Select number, e.g., No.1:**
- 5 Phone Book**
- 6 Select entry** → **Select phone number**



- Omit number selection step if only one number is saved.
- Repeat 4 - 6 to add members.

- 7 Save** → **Saved**

Saving as Individuals

- In 3, **Individual** → 5 - 6
- Saving from S! Friend's Status Member List
- In 5, **Members List** → **Select member** → 7
- Omit 7 when **Individual** is selected in 5.

Advanced

- Editing individual members
- Editing Groups (P.12-17)



Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:
 (First, set Connection status to *Online* (P.12-7).)

- 1 **MENU** ➔ **Entertainment** ➔ **S! Circle Talk**



- 2 **Select member or Group**
- 3 **Call** ➔ **Transmission starts**
 - S! Circle Talk starts when request is accepted by a receiver.
 - Loudspeaker activates automatically.

Direct Entry

Enter phone number ➔ **Call** ➔ **Call S! Circle Talk** ➔ **Call**

S! Circle Talk Operations

Speaking

- 1 **Press and hold** **when Press and Hold** **appears** ➔ **You have the floor**



- **My Turn** appears when you have the floor.
- 2 **Keep holding** **to speak** ➔ **Release** ➔ **Floor is released**
 - Warning tone sounds before time limit.

Incoming Calls during S! Circle Talk

- Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.

Canceling Loudspeaker

During S! Circle Talk,

- To reactivate, follow these steps:
 - ➔ **While message appears, OK**

Exiting S! Circle Talk

- 1 **END** ➔ **Connection ends**
 - S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk

- ➔ **Highlight most recent S! Circle Talk record** ➔ **Options** ➔ **Rejoin Circle Talk**
 - Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

- 1 **While handset is ringing/vibrating, Answer** ➔ **S! Circle Talk starts**
 - Alternatively, press .
 - S! Circle Talk Operations: left

Advanced

- Disabling Loudspeaker
- Exiting S! Circle Talk for incoming calls (P.12-17)



Using Near Chat (Japanese)

Exchange real-time text messages wirelessly with compatible Bluetooth® devices within ten meters. (Available even when handset is out-of-range.) Because this application employs Bluetooth® wireless technology transmission/connection fees do not apply.

Access Restriction

- In the event that this handset may be used by a minor, access to this application may be password restricted by a supervising adult. In this case, Handset Code access must also be managed to prevent the execution of Memory All Clear that may be used to reset the application password.

Sending Near Chat Request

- 1 **MENU** ➔ **Entertainment** ➔ **Near chat**



- 2 **Yes**

- Near Chat S! Application starts.
- A confirmation appears. Read the message and tap はい or いいえ.
- For more, see Near Chat S! Application instructions.

Receiving Near Chat Request

When a Near Chat request arrives, a tone sounds and S! Appli Notification appears.



After a period of inactivity, Information window opens, tone sounds and notification appears.

- 1 **Yes**

- Near Chat S! Application starts.
- A confirmation appears. Read the message and tap はい or いいえ.
- For more, see Near Chat S! Application instructions.

Rejecting Request

In 1, No



Blogging

Save blog details to view or update blogs easily on handset.

Saving Blog Details

Setup for Posting via Mail


Follow these steps to save blog name and address for posting:

- 1 MENU** → *Entertainment* → *Blog Tool*



Blog Tool Window

- 2 Add New Entry**



Blog Setting Menu

- 3 Blog Title** → Enter name → *Done*

- 4 Blog by send Mail**



Blog Setting Menu (Mail)

- 5 Blog's Email Address** → Enter mail address → *Done*

- 6 CLEAR/BACK** → *Assign*

Saving Title/Text for Posts

After **⊖**, *Blog's Title* or *Blog's Text* → Enter title or text → *Done* → **⊖**

- Saved title/text is entered automatically when posting.

Setting Image Size for Posting

After **⊖**, *Picture Size* → Select size → **⊖**

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC sites, or both.

- 1 In Blog Setting menu, Blog Title** → Enter name → *Done*

- 2 Refer/Send by Yahoo! Keitai or Refer/Send by PC Site/ Direct Browser**



- 3 Blog's URL** → Enter URL → *Done*

- 4 Refer Blog's URL** → Enter URL → *Done*

- 5 CLEAR/BACK** → *Assign*



Advanced

- Editing entries
- Deleting entries (P.12-17)

Posting to Blogs

Complete setup for posting via mail/
Internet beforehand.

Posting via Mail

- 1 In Blog Tool window, select entry
- 2 **Blog by send Mail**
 - S! Mail Composition window opens with address entered.
 - Omit 2 if no URL is saved for posting.
- 3 Complete message ➔ **Send**

Posting via the Internet

- 1 In Blog Tool window, select entry
- 2 **Blog by send Browser**
 - Page of URL saved in *Blog's URL* opens.
 - Omit 2 if no address is saved for posting.
 - If PC Site Browser message appears, follow onscreen prompts.

When URLs for Yahoo! Keitai & PC Sites are Saved

After 2, select browser

Opening Blog Page

- 1 In Blog Tool window, highlight entry ➔ **Read**
 - Page of URL saved in *Refer Blog's URL* opens.
 - If PC Site Browser message appears, follow onscreen prompts.

When URLs for Yahoo! Keitai & PC Sites are Saved

After 1, select browser



S! Quick News

Opening/Updating Items

Updating S! Quick News List automatically	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>Settings</i> ➔ <i>Automatic Update</i> ➔ Select item ➔ Select interval or <i>On</i></p> <ul style="list-style-type: none"> • If a confirmation appears after completing above, tap OK. • When selecting an item set to Off, a confirmation appears. • When Special is set to On, items are updated every four hours. • When General is set to On, items are updated once a day. • Updating items may incur high packet transmission fees. • Only available in Japan.
Checking update schedule	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>Settings</i> ➔ <i>Check Schedule</i></p>
Deleting S! Quick News items	<p><small>(Start Here)</small> MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>S! Quick News List</i> ➔ Highlight item ➔ <i>削除</i> ➔ See below</p> <p>One Entry 一件 ➔ Yes</p> <hr/> <p>All Entries 全件 ➔ Enter Handset Code ➔ OK ➔ Yes</p>
Resetting S! Quick News List	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>Settings</i> ➔ <i>Delete S! Quick News Lists</i> ➔ Enter Handset Code ➔ OK ➔ Yes</p> <ul style="list-style-type: none"> • Not available during automatic updates.

Other

Setting background image	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>Settings</i> ➔ <i>Change Skin</i> ➔ Select pattern</p>
Accessing source sites	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>S! Quick News List</i> ➔ Select item ➔ Select title ➔ Select linked title ➔ Yes</p>
Disabling image download	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Quick News</i> ➔ <i>Settings</i> ➔ <i>Show Image</i> ➔ Off</p>

S! Information Channel

Receiving Information

Supressing Information window for new received info	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Information Channel/Weather</i> ➔ <i>Notification</i> ➔ Off</p>
Requesting re-delivery	<p>MENU ➔ <i>Entertainment</i> ➔ <i>S! Information Channel/Weather</i> ➔ <i>Get Latest Contents</i> ➔ Yes</p>

Information Pages

Setting Display Size	<p>On a page, <i>Options</i> ➔ <i>Settings</i> ➔ <i>Display Size</i> ➔ Select size</p>
Setting scroll unit	<p>On a page, <i>Options</i> ➔ <i>Settings</i> ➔ <i>Scroll Unit</i> ➔ Select unit</p>



Copying text	On a page, <i>Options</i> → <i>Copy Text</i> → Highlight first character → <i>Start</i> → Highlight text range → <i>End</i>
Saving files to Data Folder	On a page, <i>Options</i> → <i>Save Items</i> → Select file → <i>Save</i> → Enter name → <i>Done</i> → <i>Save here</i> • Some files are saved automatically.
Opening page properties	On a page, <i>Options</i> → <i>Details</i>

Weather Indicators

Checking weather forecast	<i>MENU</i> → <i>Entertainment</i> → <i>S! Information Channel/Weather</i> → <i>Weather Indicator</i> → <i>Weather</i>
Setting weather forecast page font size	On a page, <i>Options</i> → <i>Settings</i> → <i>Font Size</i> → Select size
Hiding Weather Indicator in Standby	<i>MENU</i> → <i>Entertainment</i> → <i>S! Information Channel/Weather</i> → <i>Weather Indicator</i> → <i>Settings</i> → <i>Standby Setting</i> → <i>Off</i>
Canceling Weather Indicator automatic updates	<i>MENU</i> → <i>Entertainment</i> → <i>S! Information Channel/Weather</i> → <i>Weather Indicator</i> → <i>Settings</i> → <i>Icon Update</i> → <i>Off</i>
Suppressing Information window for weather updates	<i>MENU</i> → <i>Entertainment</i> → <i>S! Information Channel/Weather</i> → <i>Weather Indicator</i> → <i>Settings</i> → <i>Weather Notif.</i> → <i>Off</i>

e-Books

Copying text	In open page, <i>メニュー</i> → <i>文字列を北</i> → Highlight first character → <i>選択</i> → Highlight text range → <i>選択</i>
Opening non-941SH e-Books (Library)	<i>MENU</i> → <i>Entertainment</i> → Highlight <i>e-Book Viewer</i> → <i>Library</i> → Select file • Some files may not open.
Using Library	<small>(Start Here)</small> <i>MENU</i> → <i>Entertainment</i> → Highlight <i>e-Book Viewer</i> → <i>Library</i> → See below
	Adding Folders <i>Options</i> → <i>New Folder</i> → Enter name → <i>Done</i>
	Switching Folders <i>Options</i> → <i>Switch Folders</i> → Select folder
	Renaming Folders/Files Highlight folder/file → <i>Options</i> → <i>Rename</i> → Enter name → <i>Done</i>
	Moving Files Highlight file → <i>Options</i> → <i>Move</i> → Select folder → <i>Move here</i>
	Deleting Folders/Files Highlight folder/file → <i>Options</i> → <i>Delete</i> → <i>Yes</i>
Opening File Properties Highlight file → <i>Options</i> → <i>Details</i>	



S! Friend's Status

■ Members & Groups

Adding members	<small>[Start Here]</small> MENU → Entertainment → S! Friend's Status → Select Group → Options → Add Member → See below
	From Phone Book Phone Book → Select entry → Yes
	Direct Entry Add New Entry → Enter phone number → Done → Yes
Deleting members	MENU → Entertainment → S! Friend's Status → Select Group → Highlight member → Options → Registration Release → Yes → Yes • Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	MENU → Entertainment → S! Friend's Status → Select Group → Highlight member → Options → Change Group → Select target Group
Renaming Groups	MENU → Entertainment → S! Friend's Status → Select Group → Options → Edit Group Name → Enter name → Done

Rejecting requests	<small>[Start Here]</small> MENU → Entertainment → S! Friend's Status → Options → Settings → Request Reply → See below
	Rejecting Requests from Unsaved Numbers Confirm if Registered • Rejection notice is sent to rejected numbers automatically.
	Rejecting All Requests Always Ignore • Rejection notice is sent to all requesters automatically.

■ Status & Availability

Saving custom Availability combinations	MENU → Entertainment → S! Friend's Status → Options → Settings → Answer Status → User Setting → Select type → Select Availability → Save
Changing Status Icon Pictogram or Status Label description	MENU → Entertainment → S! Friend's Status → Options → Settings → Status Setting → Highlight tab (template) → Select Status → Status Icon → Select Pictogram → Status Label → Enter text → Done → Save

■ Status Templates

Resetting templates	<small>[Start Here]</small> MENU → Entertainment → S! Friend's Status → 私の状況 → Select Status, e.g., ごきげん → See below
	One Template Highlight tab (template) → Options → Reset → Yes
	All Templates Options → Reset All → Yes



Member Status & Notices

Updating manually	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Friend's Status</i> ➤ <i>Options</i> ➤ <i>Settings</i> ➤ <i>Status Update</i>
Opening notices	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Friend's Status</i> ➤ <i>Options</i> ➤ <i>Status Notif. List</i> ➤ Select notice

My Details

Sending My Details image	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Friend's Status</i> ➤ <i>Select Group</i> ➤ <i>Highlight member</i> ➤ <i>Options</i> ➤ <i>Send Image</i> ➤ <i>Yes</i> • Available when your handset number is saved in Phone Book on member's handset.
--------------------------	---

S! Circle Talk

Member List

Editing individual members	<small>(Start Here)</small> <i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Circle Talk</i> ➤ <i>Highlight member</i> ➤ <i>Options</i> ➤ <i>See below</i>
	<i>Replacing Members</i> <i>Edit</i> ➤ <i>Change</i> ➤ <i>Select method</i> ➤ <i>Select entry</i>
	<i>Deleting Members</i> <i>Delete</i> ➤ <i>Yes</i>

Editing Groups	<small>(Start Here)</small> <i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Circle Talk</i> ➤ <i>Highlight Group</i> ➤ <i>Options</i> ➤ <i>See below</i>
	<i>Editing Group Name/Members</i> <i>Edit</i> ➤ <i>Select target</i> ➤ <i>Edit/enter</i> ➤ <i>Save</i>
	<i>Deleting Group Members</i> <i>Edit</i> ➤ <i>Highlight member</i> ➤ <i>Options</i> ➤ <i>Delete</i> ➤ <i>Yes</i> ➤ <i>Save</i>
	<i>Deleting Groups</i> <i>Delete</i> ➤ <i>Yes</i>

Settings

Disabling Loudspeaker	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Circle Talk</i> ➤ <i>Options</i> ➤ <i>Loudspeaker</i> ➤ <i>Off</i>
Exiting S! Circle Talk for incoming calls	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>S! Circle Talk</i> ➤ <i>Options</i> ➤ <i>Incoming Calls</i> ➤ <i>Voice Calls</i> or <i>Video Calls</i> ➤ <i>Accept Calls</i>

Blog Tool

Editing entries	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>Blog Tool</i> ➤ <i>Highlight entry</i> ➤ <i>Options</i> ➤ <i>Edit</i> ➤ <i>Select item</i> ➤ <i>Edit</i> ➤ <i>CLEAR/BACK</i> ➤ <i>Assign</i> • For <i>Blog Title</i> , omit step of tapping <i>CLEAR/BACK</i> after editing.
Deleting entries	<i>MENU</i> ➤ <i>Entertainment</i> ➤ <i>Blog Tool</i> ➤ <i>Highlight entry</i> ➤ <i>Options</i> ➤ <i>Delete</i> ➤ <i>Yes</i>



S! Friend's Status

? Cannot use S! Friend's Status

- Set IP Service Setting to **On**.

? Handset rejected a registration request automatically

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

? Registration request arrived from a deleted member

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

? Registration request was sent to a member automatically

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

? Cannot create Status Templates

- Three templates may already be added; reset one and retry.

S! Circle Talk

? Cannot use S! Circle Talk

- Set IP Service Setting to **On**.

? S! Circle Talk starts automatically

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to **Auto Join**.

? Cannot accept S! Circle Talk requests

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to **Join NG**.

Near Chat

? Cannot receive Near Chat requests

- S! Appli Request may be set to **Off**.

S! Quick News

? Cannot receive content updates

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.

