5

**Yahoo! Keitai &
PC Site Browser**

Service Basics

Access the Mobile Internet via Yahoo! Keitai, or view PC Internet sites via PC Site Browser.
- Service requires a separate contract; retrieve Network Information to use these services.
- For more about Yahoo! Keitai, see SoftBank Mobile Website (**P.15-22**).

Transmission/Information Fees
Some page content may automatically activate Internet connection incurring transmission fees. Information fees may also apply.

Security
Electronic certificates are saved on handset to support SSL (encryption protocol for Internet transmissions of important/sensitive information).

Secure Pages
- A confirmation appears before entering and exiting secure pages.
- When a security notice appears, subscribers must decide for themselves whether or not to open the page. Opening secure pages constitutes agreement to the terms of usage. SoftBank, VeriSign Japan, Cybertrust, Entrust Japan, GlobalSign, RSA Security and SECOM Trust Systems cannot be held liable for any damages associated with the use of SSL.

Advanced

Using Yahoo! Keitai

Opening Main Menu

Internet pages may not open depending on connection/Server status, etc.

1 ⓨ ➡ **Connection starts**

```
📶⬛          15:05
YAHOO!      📧 Yahoo!
   JAPAN
                        ⎯⎯ Cursor
            [検索]
■Yahoo! JAPAN
路線 天気 ニュース
音楽 メール スポーツ
株価 オークション ゲーム
```
Internet Page

● Yahoo! Keitai Main Menu appears.
● To disconnect, press ⓨ.

2 **Highlight menu item** ➡ ●
● Corresponding page opens.
● Repeat 2 to open additional links.

3 📞 ➡ *Yes* ➡ ● ➡ **Page closes**

Returning to Previous Pages
 **[Internet Page]** ⓨ ➡ **Previous page opens**
■ Follow these steps to return to the initial page:
  [Internet Page] ⊞ ➡ *Forward* ➡ ●
Returning to Yahoo! Keitai Main Menu
  [Internet Page] ⊞ ➡ *Yahoo! Keitai* ➡ ●
User Authentication
  Enter user ID or password ➡ ● ➡ ⓨ
Playing Media Streams (Streaming)
  [Internet Page] Select file ➡ ●
■ Downloaded content cannot be saved.
■ Packet transmission fees apply even while stream is paused.

Using History

1 ● ➡ *Yahoo! Keitai* ➡ ● ➡ *History* ➡ ●

```
   History    🔽
🔍 スポーツ情報
🌐 ニュース
```

2 **Select record** ➡ ● ➡ **Connection starts**
● Corresponding page opens.

3 📞 ➡ *Yes* ➡ ● ➡ **Page closes**

Entering URLs Directly

1 ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Enter URL* ➡ ●

```
   Enter URL
.a              7/1024
⬛ttp://
```

2 **Enter URL** ➡ ● ➡ **Connection starts**
● Corresponding page opens.

3 📞 ➡ *Yes* ➡ ● ➡ **Page closes**

Advanced

🔧 ●Switching browsers ●Using previously entered URLs ●Deleting History records ●Opening History properties ●Sorting History records ●Sending History records via mail (**P.5-9**)

●Customizing streaming settings ●Streaming from Media Player (**P.5-12**)

Using PC Site Browser

Open PC sites from Yahoo! JAPAN (preset home page).

- Internet pages may not open depending on connection/Server status, etc.
- Browsing PC sites may incur higher charges depending on subscribed price plan.

1 ● ➡ *Yahoo! Keitai* ➡ ● ➡ *PC Site Browser* ➡ ●

```
15:05
PC Site Browser
⌂ Homepage
▦ Bookmarks
▥ Saved Pages
▤ Enter URL
▦ History
▨ RSS Feed
☆ Yahoo! Keitai
```

2 *Homepage* ➡ ● ➡ **Connection starts**

Internet Page ── Pointer

- Yahoo! JAPAN Home opens.
- When a message appears, follow onscreen prompts.
- To disconnect, press [Y].

3 **Highlight menu item ➡ ●**
- Corresponding page opens.
- Repeat 3 to open additional links.

4 ☎ ➡ *Yes* ➡ ● ➡ **Page closes**

Returning to Previous Pages
[Internet Page] [Y] ➡ **Previous page opens**
■ Follow these steps to return to the initial page:
[Internet Page] ⊠ ➡ *Forward* ➡ ●
Returning to Yahoo! JAPAN Home
[Internet Page] ⊠ ➡ *Homepage* ➡ ●
User Authentication
Enter user ID or password ➡ ● ➡ [Y]
Using History
In 2, *History* ➡ ● ➡ Select record ➡ ●
Entering URLs Directly
In 2, *Enter URL* ➡ ● ➡ Enter URL ➡ ●
Hiding Softkeys
[Internet Page] ⊠ ➡ *Convenient Func.* ➡ ● ➡ *Softkey Area* ➡ ● ➡ *Off* ➡ ●
Browsing in Wideview
[Internet Page] (マナー)
■ Use Multi Selector according to page orientation.

Advanced

🔄 ●Switching browsers ●Using previously entered URLs ●Deleting History records ●Opening History properties ●Sorting History records ●Sending History records via mail (**P.5-9**)
●Hiding navigation map for continuous scroll ●Changing scroll unit ●Hiding PC Site Browser messages (**P.5-12**)

Basic Operations

Page Browsing

Scrolling Pages

If page content continues beyond view, use 💠 to scroll pages.
Long Press 💠 to scroll continuously.

ニュース(総合)
(トピック1)
アメリカで行われた世界腕相撲大会で、日本の石橋さんが見事に優勝。日本人の優勝は、一昨年の木村さんに次いで二人目の快挙。
→関連記事
(トピック2)
台風17号による河川の氾濫で、付近の住宅20棟が床下浸水の被害。

(トピック2)
台風17号による河川の氾濫で、付近の住宅20棟が床下浸水の被害。
→関連記事
(トピック3)
大ヒット映画に出演したあの有名俳優が電撃結婚！　お相手は20代の一般女性。挙式は来年春の予定。

Switching Frames

On framed pages, Long Press 🔳 to select other frames.

猫画像
その1
その2
その3
【猫その1】

Frames

When pointer navigation is active, point to a frame and press ● to select it.

Viewing Single Frame
Select frame ➡ 🅿 ➡ *Convenient Func.* ➡ ● ➡ *Frame In* ➡ ●
■ To return, press 戻る.

Tabbed Browsing

Open another page in a new tab and switch between tabs.

■ **Opening a New Tab**

1. **On a page, select menu item ➡ 🅿 ➡ *Tab Menu* ➡ ●**

2. ***Open in New Tab* ➡ ●**

映画情報　ニュース(総合)
ニュース(総合)
(トピック1)
アメリカで行われた世界腕

Tab

■ **Switching Tabs**

1. **✳ (Long) ➡ 🔘 Select tab ➡ ●**
   - When pointer navigation is active, point to a tab and press ● to open it.

Closing Tabs
✳ (Long) ➡ 🔘 Select tab ➡ ● ➡ 🅿 ➡ *Tab Menu* ➡ ● ➡ *Close Tab* or *Close All Others* ➡ ●

5

Yahoo! Keitai & PC Site Browser

Advanced

🔧 ●Looking up copied words in dictionaries ●Using Web Search ●Searching current page ●Jumping to page top/bottom ●Saving files to Data Folder ●Changing Font Size ●Zooming specific areas ●Disabling automatic image display/sound playback ●Changing scroll unit (And more on **P.5-10 - 5-12**)

Selecting Text

Activate pointer navigation to enable text selection (Drag Mode). Select text to copy or look up words in dictionaries.

- Text may not be selectable or linked page may open depending on the site or page.
- Follow these steps to use a dictionary:

1. **On a page, point to first character ➡ ● (Long)**
   - Drag Mode is activated.

2. **Highlight text range**

   ```
   1:05
   ニュース(総合)
   (トピックス1)
   アメリカで行われた世界腕
   相撲大会で、日本の石
   橋さんが見事に優勝。
   日本人の優勝は、一昨
   年の木村さんに次いで
   二人目の快挙。
   ```

3. **●**
   - Text range remains unchanged even when pointer is moved.

4. **(辞書) ➡ Select dictionary ➡ ●**
   - Dictionary opens with text inserted.

5. **Search ➡ ● ➡ Select word, etc. ➡ ●**

Starting Over
After ③, point to first character ➡ ●
➡ From ②

Additional Page Operations

Enter text or select/execute items.

```
1:05
お名前          ──── Text Entry Field
性別
◉男   ○女       ──── Buttons
お住まい
未入力
北海道          ──── Menu List
青森県
送 信           ──── Command Button
```

Text Entry

1. **On a page, select text entry field ➡ ●**

2. **Enter text ➡ ●**
   - Internet page returns.

Using Entered Text (Input Memory)
[Internet page] Select text entry field ➡
● ➡ ⊡ ➡ *Insert/Font Size* ➡ ● ➡
Input Memory ➡ ● ➡ Select text ➡ ●

Pull-down Menu Item Selection

1. **On a page, select menu list field ➡ ●**

2. **Select item ➡ ●**

When Multiple Selection is Supported
- Select items as needed and press 戻る.

Page Item Indicators

■ **Selection Items**
Buttons ○ or boxes □ appear.

1. **On a page, select button or box ➡ ●**

   ```
   性別
   ◉男   ○女
   ```

   - ○/□ changes to ◉/☑.

■ **Execution Items**
Execute the assigned command.

1. **On a page, select command ➡ ●**

Using Bookmarks & Saved Pages

Bookmarks

Bookmark sites for quick access.

Saving Bookmarks

1 **On a page, 🖂 ➡ *Bookmarks*
   ➡ ● ➡ *Save* ➡ ●**
   ● *Save* appears only for savable pages.

2 **Enter/edit title ➡ ●**

3 ***Save* ➡ ●**

Opening Bookmarks

1 **● ➡ *Yahoo! Keitai* ➡ ● ➡
   Bookmarks ➡ ●**

   ```
   📶         15:05
   Bookmarks
   ⓖシャープメーカーサイト…
   ⓖS-1バトル
   ```

2 **Select title ➡ ●**
   ● Corresponding page opens.

Switching Bookmark Type
   After ①, 🖂 ➡ *Change List* ➡ ● ➡
   Select type ➡ ●
Opening Bookmarks Online
   [Internet Page] 🖂 ➡ *Bookmarks* ➡
   ● ➡ *Open List* ➡ ● ➡ Select title
   ➡ ●

Saved Pages

Save page content; handset opens saved pages without connecting to the Internet.

Saving Pages

1 **On a page, 🖂 ➡ *Saved
   Pages* ➡ ● ➡ *Save* ➡ ●**
   ● *Save* appears only for savable pages.

2 **Enter/edit title ➡ ●**

Opening Saved Pages

1 **● ➡ *Yahoo! Keitai* ➡ ● ➡
   Saved Pages ➡ ●**

   ```
   📶         15:05
   Saved Pages
   Yahoo!ケータイ
   YAHOO!   Yahoo!
              検索
   Yahoo! JAPAN
   路線 天気 ニュース
   ```

2 **Select page ➡ ●**
   ● Corresponding page opens.

Opening Saved Pages Online
   [Internet Page] 🖂 ➡ *Saved Pages* ➡
   ● ➡ *Open List* ➡ ● ➡ Select page
   ➡ ●

5

Yahoo! Keitai & PC Site Browser

Advanced

🖑 ●Deleting titles ●Editing titles ●Changing title order ●Sorting titles into folders ●Deleting pages ●Editing page titles ●Changing page order (And more on **P.5-12** - **5-13**)

Updating Blogs & News

Register RSS-compatible sites; view content updates without opening source sites. Transmission fees apply.

Subscribing to RSS Feeds

👑 appears for RSS-compatible sites.

📡☐☐☐   🗓📢15:05 — RSS Indicator

Available for PC Site Browser.

1. On a compatible page, ◸ ➡ *Register In RSS Feed* ➡ ●

2. Select feed ➡ ● (□/☑) ➡ Complete selection ➡ ⓨ

3. *Save* ➡ ●
   ● Choose *Yes* to update immediately or *No* and press ●.

Via RSS Icons

Use RSS icons to subscribe to RSS feeds from sites that are not RSS-compatible. Available for PC Site Browser.

1. On a page, select icon ➡ ●

2. *Yes* ➡ ● ➡ *Save* ➡ ●

Checking Updates

Follow these steps to update all feeds:

1. ● ➡ *Yahoo! Keitai* ➡ ●

2. *PC Site Browser* ➡ ● ➡ *RSS Feed* ➡ ●

📡☐☐☐   15:05
RSS Feed
🆕Reload All
🗞今日のニュー…
🗞○○の日記

RSS Feed List

3. *Reload All* ➡ ● ➡ ●

4. *Yes* or *No* ➡ ●

5. Select feed ➡ ●

📡☐☐☐   15:05
Items
今日のニュース
🗞明日の天気
🗞今日のエンタ…

Title List

6. Select title ➡ ●
   ● Information appears.

Updating Single RSS Feeds
[RSS Feed List] Select feed ➡ ◸ ➡ *Reload* ➡ ● ➡ ● ➡ *Yes* or *No* ➡ ●
Accessing Source Sites
[Title List] Select title ➡ ● ➡ Select linked title ➡ ● ➡ *Yes* ➡ ● ➡ ● ➡ *Yes* or *No* ➡ ●

Advanced

🕰 ●Disabling feed updates ●Sorting feeds into folders ●Deleting feeds ●Sorting feeds ●Opening feed properties ●Exchanging feeds with other devices ●Sending feeds via mail (**P.5-14**)

Connecting/Browsing

■ General

Switching browsers	On a page, 🔎 ➡ *Convenient Func.* ➡ ● ➡ *Change to PC Br.* or *Switch Browser* ➡ ● ➡ *This Page* or *Linked Page* ➡ ● ➡ ● ➡ *Yes* or *No* ➡ ●
Using previously entered URLs	Start Here ● ➡ *Yahoo! Keitai* ➡ ● ➡ See below **Yahoo! Keitai** *Enter URL* ➡ ● ➡ 🔎 ➡ *URL Entry Log* ➡ ● ➡ Select URL ➡ ● ➡ ● **PC Site Browser** *PC Site Browser* ➡ ● ➡ *Enter URL* ➡ ● ➡ 🔎 ➡ *URL Entry Log* ➡ ● ➡ Select URL ➡ ● ➡ ●

■ History

Deleting History records	Start Here ● ➡ *Yahoo! Keitai* ➡ ● ➡ *History* ➡ ● ➡ 🔎 ➡ *Change to PC Br.* or *Switch Browser* ➡ ● ➡ See below **One Record** Select record ➡ 🔎 ➡ *Delete* ➡ ● ➡ *Yes* ➡ ● **All Records** 🔎 ➡ *Delete All* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Opening History properties	● ➡ *Yahoo! Keitai* ➡ ● ➡ *History* ➡ ● ➡ Select record ➡ 🔎 ➡ *Details* ➡ ●
Sorting History records	● ➡ *Yahoo! Keitai* ➡ ● ➡ *History* ➡ ● ➡ 🔎 ➡ *Sort* ➡ ● ➡ *By Domain* or *By Date* ➡ ●

Sending History records via mail	● ➡ *Yahoo! Keitai* ➡ ● ➡ *History* ➡ ● ➡ Select record ➡ 🔎 ➡ *Send URL* ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ Complete message ➡ 🖂 ● S! Mail Composition window opens automatically depending on character count.

■ Memory Operation

For PC Site Browser, perform the following sequence instead of *Settings* ➡ ●.

PC Site Browser ➡ ● ➡ *PC Site Browser Settings* ➡ ●

Clearing cache (temporarily saved information)	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Memory* Op. ➡ ● ➡ *Delete Cache* ➡ ● ➡ *Yes* ➡ ●
Clearing cookies	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Memory* Op. ➡ ● ➡ *Delete Cookies* ➡ ● ➡ *Yes* ➡ ●
Clearing authentication information	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Memory* Op. ➡ ● ➡ *Delete Auth Info* ➡ ● ➡ *Yes* ➡ ●

Page Operations

■ Yahoo! Keitai & PC Site Browser

Using linked info	**Dialing Numbers** **On a page, highlight number ▶ ● ▶ *Call* or *Video Call* ▶ ●** **Sending Messages** **On a page, highlight number or mail address ▶ ● ▶ *Create Message* ▶ ● ▶ *S! Mail* or *SMS* ▶ ● ▶ Complete message ▶ ⊠** ● For mail addresses, omit mail type selection step.
Copying text	**On a page, ⊞ ▶ *Copy Text* ▶ ● ▶ Select first character ▶ ● ▶ Highlight text range ▶ ●**
Looking up copied words in dictionaries	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Copy & Search Dict.* ▶ ● ▶ Select first character ▶ ● ▶ Highlight text range ▶ ● ▶ Select dictionary ▶ ● ▶ *Search* ▶ ● ▶ Select word, etc. ▶ ●**
Using Web Search	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Web Search* ▶ ● ▶ Enter search text ▶ ●**
Searching current page	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Search* ▶ ● ▶ Enter search text ▶ ●** ● Press ● to jump to next search result, if any.
Jumping to page top/bottom	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Jump In Page* ▶ ● ▶ *Page Top* or *Page Bottom* ▶ ●**
Opening page properties	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Details* ▶ ● ▶ Select item ▶ ●**

Sending URLs via mail	**On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Send URL* ▶ ● ▶ *S! Mail* or *SMS* ▶ ● ▶ Complete message ▶ ⊠** ● S! Mail Composition window opens automatically depending on character count.
Handling Flash® files	**Start Here On a page, ⊞ ▶ *Convenient Func.* ▶ ● ▶ *Flash®Menu* ▶ ● ▶ See below** **Pausing/Playing** *Pause*, *Resume* or *Replay* ▶ ● **Selecting Image Quality** *Quality* ▶ ● ▶ Select option ▶ ●
Saving files to Data Folder	**Start Here On a page, ⊞ ▶ *Save Items* ▶ ● ▶ See below** **Files on Page** Select file ▶ ● ▶ *Save* ▶ ● ▶ Enter name ▶ ● ▶ *Save here* ▶ ● ● Some files are saved automatically. ● Confirm signal is strong, battery is adequately charged and that there is enough free memory beforehand. **Background Images** *Save BG. Image* ▶ ● ▶ *Save* ▶ ● ▶ Enter name ▶ ● ▶ *Save here* ▶ ●
Updating page content	**On a page, ⊞ ▶ *Reload* ▶ ●** ● To update content in Saved Pages, open a page and follow the steps above.

Changing encoding to read garbled text	On a page, ⊠ ➡ *Settings* ➡ ● ➡ *Char-code* ➡ ● ➡ Select option ➡ ●
Opening function shortcuts	On a page, ⊠ ➡ *Help* ➡ ●

■ **Yahoo! Keitai**

Changing Font Size	On a page, 3̄ (Long) to enlarge or 1̄ (Long) to reduce

■ **PC Site Browser**

Switching view	On a page, ⊠ ➡ *Small Screen* or *PC Screen* ➡ ●
Zooming on pages (Zoom Factor)	On a page, 3̄ (Long) to enlarge or 1̄ (Long) to reduce
Jumping to specific locations	On a page, 5̄ (Long) ➡ Quick Movement map appears ➡ Select location ➡ ●
Zooming specific areas	On a page, point to area ➡ 7̄ (Long) ● Pointed area is enlarged while 7̄ is pressed.

Internet Page Settings

■ **Yahoo! Keitai & PC Site Browser**
For PC Site Browser, perform the following sequence instead of *Settings* ➡ ●.
PC Site Browser ➡ ● ➡ *PC Site Browser Settings* ➡ ●

Disabling automatic image display/sound playback	Start Here ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Downloads* ➡ ● ➡ See below
	Image Display *Images* ➡ ● ➡ *Do not Show* ➡ ●
	Sound Playback *Sounds* ➡ ● ➡ *Do not Play* ➡ ●
Changing Font Size	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Font Size* ➡ ● ➡ Select size ➡ ●
Using pointer navigation	Start Here ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Cursor Settings* ➡ ● ➡ See below
	Activating *Cursor Mode Settings* ➡ ● ➡ *Normal Mode* ➡ ●
	Changing Pointer Speed *Speed Settings* ➡ ● ➡ Select speed ➡ ●
Using Memory Card as primary download storage	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Download to* ➡ ● ➡ *Prefer Card* ➡ ● ● Some files may be saved to handset regardless of this setting.

5

Yahoo! Keitai & PC Site Browser

5-11

■ **Yahoo! Keitai**

Changing scroll unit	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Scroll Unit* ➡ ● ➡ **Select unit** ➡ ●

■ **PC Site Browser**

Hiding navigation map for continuous scroll	● ➡ *Yahoo! Keitai* ➡ ● ➡ *PC Site Browser* ➡ ● ➡ *PC Site Browser Settings* ➡ ● ➡ *Scroll Settings* ➡ ● ➡ *Page Navigation* ➡ ● ➡ *Off* ➡ ●
Changing scroll unit	● ➡ *Yahoo! Keitai* ➡ ● ➡ *PC Site Browser* ➡ ● ➡ *PC Site Browser Settings* ➡ ● ➡ *Scroll Settings* ➡ ● ➡ *Scroll Unit* ➡ ● ➡ **Select unit** ➡ ●
Hiding PC Site Browser messages	● ➡ *Yahoo! Keitai* ➡ ● ➡ *PC Site Browser* ➡ ● ➡ *PC Site Browser Settings* ➡ ● ➡ *Warning Message* ➡ ● ➡ *PC Site Browser* or *Yahoo! Keitai* ➡ ● ➡ *Off* ➡ ●

Streaming

Customizing streaming settings	**Start Here** While streaming, ⊡ ➡ *Settings* ➡ ● ➡ See below
	Changing Playback Size *Display Size* ➡ ● ➡ **Select size** ➡ ● • Playback size may not change depending on file/stream.
	Setting Backlight Status *Backlight* ➡ ● ➡ **Select option** ➡ ● • Selecting *Norm. Settings* applies Display Backlight setting.
	Adjusting Sound Effects *Sound Effects* ➡ ● ➡ **Select effect** ➡ ●

Streaming from Media Player	**Start Here** ● ➡ *Media Player* ➡ ● ➡ *Streaming* ➡ ● ➡ See below
	Resuming from Stopped Point *Last Played* ➡ ●
	Using Bookmarks *Bookmarks* ➡ ● ➡ **Select title** ➡ ●
	Using History *History* ➡ ● ➡ **Select record** ➡ ●

Bookmarks

Deleting titles	**Start Here** ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ See below
	One Title **Select title** ➡ ⊡ ➡ *Delete* ➡ ● ➡ *Yes* ➡ ●
	All Titles ⊡ ➡ *Delete All* ➡ ● ➡ **Enter Handset Code** ➡ ● ➡ *Yes* ➡ ●
Editing titles	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ **Select title** ➡ ⊡ ➡ *Edit* ➡ ● ➡ *Title:* ➡ ● ➡ **Enter title** ➡ ● ➡ ⊡
Editing bookmarked URLs	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ **Select title** ➡ ⊡ ➡ *Edit* ➡ ● ➡ *URL:* ➡ ● ➡ **Edit** ➡ ● ➡ ⊡

Sending bookmarked URLs via mail	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ Select title ➡ 🖂 ➡ *Send* ➡ ● ➡ *As Message* ➡ ● ➡ *S! Mail* or *SMS* ➡ ● ➡ Complete message ➡ 🖂 • S! Mail Composition window opens automatically depending on character count.
Changing title order	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ Select title ➡ 🖂 ➡ *Change Order* ➡ ● ➡ Select target location ➡ ●
Opening title properties	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ Select title ➡ 🖂 ➡ *Details* ➡ ●
Sorting titles into folders	**Start Here** ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Bookmarks* ➡ ● ➡ See below **Creating Folders** 🖂 ➡ *Create Folder* ➡ ● ➡ Enter name ➡ ● **Moving to Folders** Select title ➡ 🖂 ➡ *Move* ➡ ● ➡ Select folder ➡ ● ➡ *Move* ➡ ● **Moving from Folders** Select folder ➡ ● ➡ Select title ➡ 🖂 ➡ *Move* ➡ ● ➡ *Move* ➡ ● **Renaming Folders** Select folder ➡ 🖂 ➡ *Rename* ➡ ● ➡ Enter name ➡ ● **Deleting All Titles within a Folder** Select folder ➡ ● ➡ 🖂 ➡ *Delete All* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ● **Deleting Folders** Select folder ➡ 🖂 ➡ *Delete* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

Saved Pages

Deleting pages	**Start Here** ● ➡ *Yahoo! Keitai* ➡ ● ➡ *Saved Pages* ➡ ● ➡ See below **One Page** Select page ➡ 🖂 ➡ *Delete* ➡ ● ➡ *Yes* ➡ ● **All Pages** 🖂 ➡ *Delete All* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Editing page titles	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Saved Pages* ➡ ● ➡ Select page ➡ 🖂 ➡ *Rename* ➡ ● ➡ Enter title ➡ ●
Changing page order	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Saved Pages* ➡ ● ➡ Select page ➡ 🖂 ➡ *Change Order* ➡ ● ➡ Select target location ➡ ●
Opening page properties	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Saved Pages* ➡ ● ➡ Select page ➡ 🖂 ➡ *Details* ➡ ●
Switching page list view	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Saved Pages* ➡ ● ➡ Select page ➡ 🖂 ➡ *List View* or *Preview View* ➡ ●

RSS Feeds

Disabling feed updates	● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → Select feed → ⊡ → *Manage RSS Feed* → ● → *Restrict Update* → ●
Sorting feeds into folders	**Start Here** ● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → See below **Creating Folders** ⊡ → *Manage RSS Feed* → ● → *Create Folder* → ● → Enter name → ● **Moving to Folders** Select feed → ⊡ → *Manage RSS Feed* → ● → *Move* → ● → Select folder → ● → *Move* → ● **Renaming Folders** Select folder → ⊡ → *Manage RSS Feed* → ● → *Rename* → ● → Enter name → ● **Deleting Folders** Select folder → ⊡ → *Delete* → ● → Enter Handset Code → ● → *Yes* → ●
Deleting feeds	**Start Here** ● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → See below **One Entry** Select feed → ⊡ → *Delete* → ● → *Yes* → ● **All Entries** ⊡ → *Manage RSS Feed* → ● → *Delete All* → ● → Enter Handset Code → ● → *Yes* → ● ● Alternatively, perform *Delete RSS Feed List* in Memory Op. (PC Site Browser Settings) to delete all feeds.
Sorting feeds	● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → ⊡ → *Manage RSS Feed* → ● → *Sort* → ● → Select option → ●
Opening feed properties	● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → Select feed → ⊡ → *Manage RSS Feed* → ● → *Details* → ●
Exchanging feeds with other devices	**Start Here** ● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → *Manage RSS Feed* → ● → See below **Exporting All Feeds** *Export All* → ● → Select location → ● **Importing (Adding Feeds)** *Import* → ● → Select file → ● → *As New Items* → ● → *Yes* or *No* → ● → *Yes* or *No* → ● **Importing (Overwriting Existing Feeds)** *Import* → ● → Select file → ● → *Delete All* → ● → Enter Handset Code → ● → *Yes* → ● → *Yes* or *No* → ● → *Yes* or *No* → ●
Sending feeds via mail	● → *Yahoo! Keitai* → ● → *PC Site Browser* → ● → *RSS Feed* → ● → Select feed → ⊡ → *Manage RSS Feed* → ● → *As Message* → ● → Complete message → Y

Security Settings

For PC Site Browser, perform the following sequence instead of *Settings* ➡ ●.

PC Site Browser ➡ ● ➡ *PC Site Browser Settings* ➡ ●

Disabling manufacture number auto send for authentication	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Manufacture No.* ➡ ● ➡ *Off* ➡ ●
Disabling referer information delivery to the Server	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Send Referer* ➡ ● ➡ *Not Send* ➡ ●
Enabling/disabling cookies	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Cookies* ➡ ● ➡ Select option ➡ ●
Selecting script execution option	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Script Settings* ➡ ● ➡ Select option ➡ ●
Hiding confirmations before entering/ exiting secure pages	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Secure Prompt* ➡ ● ➡ *Do not Show* ➡ ●
Opening electronic certificates saved on handset	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Root Certificates* ➡ ● ➡ Select certificate ➡ ●
Changing validity of entered user ID/ password	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Keep Auth Info* ➡ ● ➡ Select option ➡ ● • *Per Browsing* retains entered user ID/password during browsing sessions. *On* retains such authentication information even after turning handset off. • Authentication information may not be retained depending on the site.
Enabling/disabling Ajax (for asynchronous communication)	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Security Settings* ➡ ● ➡ *Restrict Ajax* ➡ ● ➡ Select option ➡ ●

Resetting

For PC Site Browser, perform the following sequence instead of *Settings* ➡ ●.

PC Site Browser ➡ ● ➡ *PC Site Browser Settings* ➡ ●

Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.)	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Init. Browser* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Restoring default handset settings	● ➡ *Yahoo! Keitai* ➡ ● ➡ *Settings* ➡ ● ➡ *Reset Settings* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●

5

Connecting/Browsing

What is the bar at Display bottom?

- This is a data progress bar; the number beside it indicates transmitted (green) or received (red) data.

Page Operations

Internet page does not open completely

- Portions of page content may not appear in tabbed browsing; close other tabs.

Text overlaps

- The site may be designed for browsing on PCs; try *Tiny* font size.
- Text may overlap when Zoom Factor is used; adjust scale.

Cannot access other functions while browsing the Internet

- When switching between Yahoo! Keitai and PC Site Browser (⊡ appears), additional function activation is disabled; close either browser and retry.