| Calendar & Tasks               | 9-2  |
|--------------------------------|------|
| Calendar                       | 9-   |
| Tasks                          |      |
| Alarms                         | 9-   |
| Using Alarms                   |      |
| Wakeup TV                      | 9-9  |
| Using Wakeup TV                | 9-9  |
| Relaxation Time                | 9-1  |
| Playing Animation with Music & |      |
| Illumination                   | 9-1  |
| Calculator                     | 9-1  |
| Using Calculator               |      |
| Expenses Memo                  | 9-1  |
| Adding Expenses                |      |
| Osaifu-Keitai®                 | 9-1  |
| Osaifu-Keitai® (Japanese)      | 9-1  |
| Locking IC Card                | 9-1  |
| Simulated Call                 | 9-18 |
| Faking Incoming Calls          | 9-1  |
| Stopwatch                      | 9-19 |
| Using Stopwatch                | 9-19 |
| Countdown Timer                | 9-20 |
| Using Countdown Timer          | 9-2  |
| World Clock                    | 9-2  |
| Opening World Clock            | 9-2  |

| Hour Minder             |      |
|-------------------------|------|
| Using Hour Minder       | 9-22 |
| Pedometer               |      |
| Using Pedometer         | 9-23 |
| Document Viewer         | 9-25 |
| Opening PC Documents    | 9-25 |
| Notepad                 | 9-26 |
| Saving Text             |      |
| ASCII Art               | 9-27 |
| Using ASCII Art         | 9-27 |
| Voice Recorder          | 9-28 |
| Recording/Playing Voice |      |
| Scan Barcode            | 9-29 |
| Scanning Barcodes       | 9-29 |
| Create QR Code          | 9-30 |
| Creating QR Codes       |      |
| Scan Card               | 9-31 |
| Scanning Business Cards | 9-31 |
| Scan Text               | 9-32 |
| Scanning Text           |      |
| Kanji Grabber           | 9-33 |
| Using Kanji Grabber     | 9-33 |
| Additional Functions    | 9-34 |
| Troubleshooting         | 9-46 |

# 9

# **Handy Extras**



# Calendar

#### **Opening Calendar**

① → Tools → ② → In PIM/ Lifestyle menu, Calendar → ③



Calendar Window

# Toggling View

Press 🕏 to toggle Calendar window:



Month View



v 3Month View



6Month View



Week View

#### Key Assignments

#### All Views

| Open Previous Page | ¥ muev<br>+7 |
|--------------------|--------------|
| Open Next Page     | # 0,         |
| Open Help          | 0 50E        |

#### ■ Month/3Month View

| Select Date        | <b>•</b> |
|--------------------|----------|
| Go to Current Date | 5 .*     |


#### 6Month View

| Go to Current Month | 5 % |
|---------------------|-----|
| Select Month        | ••• |

#### Week View

| Select Date       | - ⊙      |
|-------------------|----------|
| Select Time Block | <b>③</b> |





#### Saving Schedules


Follow these steps to save subject, start/ end date/time. Alarm and schedule details: (Enter Subject or Description to save entry.)

In Calendar window, select date **→** (•)



<Add New Entry> ▶ ●

Enter subject **→** ●



Enter start date/time 

◆ ●



- End: 

   Enter end date/time 

  ◆
- Alarm: **→**
- Alarm Time: 

  ◆ Select time **→ (•) → (•)**
- Description: 

  ◆ Enter schedule details **→** •
- Saved

All-Day Schedule In (4), (∞) **→** (From (3) **Custom Alarm Time** In ∅, Alarm Time: ♦ ⑥ ♦ Other ♦ ● **Enter date/time ●** ● **> >** From 3

#### At Alarm Time

Alarm activates; sounds/vibrates by related settings.



#### Stopping Alarm to Return to Standby

 While Alarm sounds/vibrates, press or .

#### Stopping Alarm to Open Schedule

• While Alarm sounds/vibrates, press a key other than , or .

#### When Another Function is Active

 Alarm may not activate until handset returns to Standby.

#### Incoming Calls

 Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.







Schedule List





Opening Task List
In ⊘, select task → ⊚ → Go to
Tasks → ●

Accessing Secret Entries
[Calendar Window] ⊚ → Unlock
Temporarily → ● → Enter Handset

## Opening Related Message

Open schedule-related messages saved from Messaging message list.

- In schedule list, select schedule ▶ ●
- - Related message opens.
  - To return to schedule window, press

Deleting Message from Schedule

After ①, ⑥ → Related Mail: → ⑥ →

Yes → ⑥ → ∞

#### **Deleting Schedules**

- One Entry
- Delete → → This
  Appointment → → Yes
  → ●
- All Entries of the Day
- In Calendar window, select date ⇒ ⊠
- Delete → → All This Day
  → → Yes → ●

#### **Advanced**

Code 


◆



## Tasks

#### **Saving Tasks**


Follow these steps to save subject, due date/time, Alarm and task details: (Enter Subject or Description to save entry.)











Enter due date/time → ●



🧻 Alarm: 🖈 💿




- Description: 

   ● Enter task details ●
- Saved 

  Saved









Alarm activates; sounds/vibrates by related settings.



#### Stopping Alarm to Return to Standby

While Alarm sounds/vibrates, press ①,
 or .

#### Stopping Alarm to Open Task

 While Alarm sounds/vibrates, press a key other than , or ...


#### When Another Function is Active

 Alarm may not activate until handset returns to Standby.

#### **Incoming Calls**

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

#### **Opening Tasks**





Task List

- Use to open completed or uncompleted task list.
- 🤰 Select task 🕈 💿



# 👔 🔂 🖈 Standby returns

#### **Accessing Secret Entries**

#### **Deleting Tasks**

- One Entry
  - \rceil In task list, select task 🖈 🖾
- Delete → ●
- 🛐 This Task 🕈 🂿 🕈 Yes 🕈 💿
- All Completed Tasks
- 🚹 In task list, 🖾
- Delete → ●
- All Comp. Tasks → → Yes → ●

# **Using Alarms**

#### **Setting Alarm**

Follow these steps to set Alarm to sound at a specific time on a specific day of the week: (Set Snooze--Alarm repeats at set interval--Alarm Volume and Duration.)






Alarm List

2 --:-- → ● → Enter hour (24-hour format) → Enter minutes → ●







🔼 Selected Days 🖈 💿




- Select day → (□/☑) → Complete selection → ♡
- Snooze: ▶ ●
- Select interval **→**
  - For custom intervals, select Other.

















In ⊕, ⊚ → Check All or Uncheck All

Excluding Holidays
In ⑤, select day ♦ ⑥ (□/☑) ♦
Complete selection ♦ Except
Holidays ♦ ⑥ ♦ ※ ♦ From ⑤





#### **At Alarm Time**

Alarm activates; sounds/vibrates by related settings.



#### Stopping Alarm

• Press a kev.

#### When Another Function is Active

 Alarm may not activate until handset returns to Standby.

#### **Incoming Calls**

· Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

#### When Snooze is Set

Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.

## **Canceling Snooze**

While Snoozing, ● **Yes → O** 

• Snooze is automatically canceled after a period of time.

#### Canceling Alarm

In Alarm list, select entry ▶



Switch Off **→** ●


· Reactivate entry to use the same settinas.

#### Reactivating Entry

In ②, Switch On ▶ ●

#### **Deleting Alarm**

One Entry



Reset Alarm **⇒** ●

Yes **▶** (•)

All Entries

In Alarm list, select entry ▶ 🖾

Enter Handset Code **→ ●** Yes → (•)



# Using Wakeup TV

#### **Setting Wakeup TV**

Follow these steps to activate TV at a specific time on a specific day of the week:

- Complete TV Area Setup beforehand.
- TV may not activate in poor signal conditions.
- **→** *Tools* **→ →** In PIM/ Lifestyle menu, Wakeup TV




Wakeup TV List






Wakeup TV Menu







- Select day **→ (**□/**(**□/**(**) **→** Complete selection **→** (>>)
- Channel: **▶** ●
- Select channel **→** 
  - (y) **▶** Saved
    - For more settings, repeat ② ③.
- Wakeup TV setting ends

**Activating TV Once or Daily** In ②, Once or Every Day (All) → • **⇒** From **⑤** Selecting/Canceling All Days In ⑤, ☑ → Check All or Uncheck All **▶ (0**) **Excluding Holidays** In  $\bigcirc$ , select day  $\Rightarrow$   $\bigcirc$   $(\square/\square)$ Complete selection **→** *Except* **Canceling Alarm** Alarm activates at Wakeup TV time. To

cancel Alarm, follow these steps:

[Wakeup TV Menu] Alarm On/Off: ▶

**Adjusting Alarm Volume** [Wakeup TV Menu] Alarm Volume: >

Adjust level 
 From 
 From 



Handy Extras

- While Alarm sounds/vibrates, press a key.
- When Another Function is Active
- TV may not activate depending on the function.

After TV is On for a Period of Time

- In Wakeup TV list, select entry ▶
- Wakeup TV Off 

   Reactivate entry to use the same settings.

In ②, Wakeup TV On → ●

Reactivating Entry

## **Deleting Wakeup TV**

- One Entry
  In Wakeup TV list, select entry ▶ 🖾
- 🗩 Reset Alarm 🕈 💿
- ? Yes **→** •
- All Entries
- In Wakeup TV list, select entry ▶
- Clear All → ●
- Enter Handset Code → ●

  → Yes → ●

# **Playing Animation with Music & Illumination**

Play preset animations or downloaded Flash® files with music and illumination. Set playback time, volume and illumination pattern as needed.

- → Tools → In PIM/ Lifestyle menu, Relaxation Time → ●
- Select type →
  - Animation appears.
  - For *Flash*®, select a file and press •.
  - Key LEDs do not illuminate for soundless Flash® files.

## Setting Relaxation Time

Follow these steps to set playback time, volume and Key Illumination pattern:

- ① ◆ Tools ◆ ② ◆ In PIM/ Lifestyle menu, Relaxation Time ◆ ③
- Settings → ●




- R Playback Time → ●
- Select time →
  - For custom playback time, select Other.
- S Volume → ●
- 🕞 Adjust level 🕈 💿





- Key Pattern → ●
- Select pattern → • •
- Standby returns






# **Using Calculator**

● → Tools → ● → In PIM/ Lifestyle menu, Calculator




Calculator Window







**♦** Calculator ends



#### **Memory Calculation**

- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset is powered off.

#### **Incoming Calls**

 Calculations are not affected. End the call to return to Calculator.

#### **Using % Function**

Use ® to find definite percentage of a known value.

Example: Calculate 30% of 800,000

Enter 800,000 → x → 30 → %

**240,000** appears.





# Adding Expenses

#### **Entering Expenses**









Saved

Saving under Custom Category In ⓒ, Other → ● ⇒ Enter name → ●

#### **Checking Entries**

Lifestyle menu, Expenses Memo **→** •



Totals **→** (●)



Expenses Memo List

Standby returns

Saving Entries to Notepad [Expenses Memo List] 

→ Save to Notepad **→** ●

All expense details are saved as a single entry.

#### **Deleting Entries**

- One Entry
- In Expenses Memo list, select entry **→** (□)
- Delete Item **→** •
- Yes **▶** (•)
- **All Entries**
- In Expenses Memo list, ₪
- Enter Handset Code **→** (•)

# Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 936SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

#### **Basics**

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

#### Starting Lifestyle-Appli

● **Tools →** In PIM/Lifestyle menu. *Osaifu-Keitai* → ● Lifestvle-Appli 

◆ ● Select application **→** •

#### Lifestyle-Appli Precautions


- Contact Osaifu-Keitai<sup>®</sup> service providers for Lifestyle-Appli registration and usage details
- Keep service passwords/customer service contact information, etc. in a separate place.

## Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment

- Lifestyle-Appli activation is not necessary.
- Transactions are possible even when handset power is off (if battery is adequately charged).
- Calls/Internet transmissions do not affect. transactions





Place this part over reader/writer

Align handset parallel to reader/writer.

#### Important Osaifu-Keitai® Usage Note

 SoftBank Mobile is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

#### When Placed Over Sensor

- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.



# **Locking IC Card**

#### **IC Card Lock**

Restrict access to/prevent unauthorized use of Osaifu-Keitai® on handset.


- **Tools** • In PIM/ Lifestyle menu, *Osaifu-Keitai* 
  - Osaifu-Keitai


    Lifestyle-Appli

    Cl Card Settings




- Canceling IC Card Lock
  In ②, IC Card Lock → ③ → Off → ④
  → Enter Handset Code → ④





IC Card Settings Menu





Disable Osaifu-Keitai® remotely by mail or phone.

|      | Send mail to activate<br>Remote Lock                |
|------|---|
|      | Call from a specified phone to activate Remote Lock |
| Lock | to activate Remote Lock                             |

#### Mail Remote Lock

Preparation on Handset









Mail Remote Lock **→** ●




Mail Remote Lock Menu

- Remote Lock PW **→**
- Enter password **→** ●
- On **▶ (1) (27)**

**Canceling Mail Remote Lock** In ⑤, Switch On/Off ♦ ⑥ ♦ Off ♦ (a) **(**27)

■ Activating Remote Lock via Mail If handset cannot receive mail IC Card Lock is not set.



• After handset receives message, IC Card Lock is set and notice is sent as a reply.

- Call Remote Lock
- Preparation on Handset
- ① ◆ *Tools* ◆ ① ◆ In PIM/ Lifestyle menu, *Osaifu-Keitai* ◆ ②
- IC Card Settings → ●
- Remote Lock → ► Enter Handset Code → ●



Call Remote Lock → ●



Call Remote Lock Menu

Phone No. to Lck 1 or Phone No. to Lck 2 ▶ ●



- Phone Book → Select entry → ● → Select phone number → ●
  - Select Phone Number to enter directly.
- Switch On/Off → ●
  On → □

Enabling Activation via Public Phone
In ⊕, Set Public Phone ▶ ● ▶ On
▶ ● ▶ From ②

Canceling Call Remote Lock
In ⊕, Switch On/Off ▶ ● ▶ Off ▶

**●** ★ 😕

- Activating Remote Lock via Phone
  If handset cannot receive calls IC Card
  Lock is not set
- Using one of the specified phones, call handset

   Send Caller ID.
  - Handset receives call 
    End the call
    - The call is recorded as a Missed Call.
- Within three minutes, repeat

  O ② twice



 After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

#### If Series is Interrupted by Another Call

 Missed Call count is reset. Start over from the beginning. Handset rings to emulate an incoming call.

- Save name and phone number to show as Caller ID.
- Ringer may be muted by handset settings.
   To override Silent setting, see P.9-40.

#### **Setting Simulated Call**

● → Tools → ● In PIM/ Lifestyle menu, Simulated Call → ●



Simulated Call Menu







- Name: → Enter name
  → ●
- Phone Number: → →
  Enter phone number → ●

  → ②
- Assign Tone → Select tone/file → ●

When Name and Phone Number are Unset

• Handset rings with Caller ID "Withheld."

Canceling Simulated Call
[Simulated Call Menu] Switch On/Off

**Setting Wait Time** 

[Simulated Call Menu] Receive Timing

→ • • Select time • • • □

#### **Using Simulated Call**

Available with handset open.



# (Long)

- Handset rings and incoming Voice Call window opens.
- Ringtone stops after a period of time.
- In incoming Voice Call window, press
  - Voice Call window opens. (Softkeys are dummies.)
- Simulated Call ends

# When Receive Timing is Not Immediately ● Press ③ or during wait time to

- cancel Simulated Call activation.Simulated Call activation is canceled by
- Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.

# **Using Stopwatch**

Stopwatch stops when battery runs low.





Stopwatch Window





Press to resume.



 Records are deleted when Stopwatch ends. Recording Lap Times
While Stopwatch is running, 
Saving Records to Notepad
After ⓒ, ◎ ➤ Save to Notepad ➤ ●
Resetting Records
After ⓒ, ※ ➤ From ❷
Incoming Calls
• Stopwatch is not affected by incoming calls. End the call to return.





Timer Entry Window

Enter minutes → Enter seconds → ●



Countdown Timer Window

• Press ( to change time.

- - Press to stop/resume countdown.
- Set time elapses ⇒ Tone sounds



Using Timer Records

After ①, ◎ → Select record → ● →

• → From Θ

Resetting Countdown Timer Stop countdown and © Incoming Calls

 Countdown is not affected by incoming calls. End the call to return. When Set Time Elapses

Tone sounds.



#### Stopping Tone Instantly

 Press or a Side Key. (Tone stops automatically after a period of time.)

When Timer Time Elapsed during a Call

Tone sounds after the call.

Handy Extras

9-20

# **Opening World Clock**

① → Tools → ⊙ → ⊙
Clocks/Gauges → World
Clock → ⊙



Select area → ●

Advancing One Hour (Daylight Saving)
[Set Time Zone Window] 

■ To cancel, press 

Adding Custom Time Zone

[Set Time Zone Window] <sup>(a)</sup> → Enter city name → (a) → + or - (b) → Enter time difference → (a)

#### Opening World Clock in Standby

- Standby Display ▶ ●



- Clock/Calendar → ●
- World Clock (L), etc. → •
- Standby returns 

  Standby returns





Set Time Zone Window



# **Using Hour Minder**

#### **Setting Hour Minder**

Follow these steps to activate the hourly time signal at selected hours:






Hour Minder Menu















Changing Hour Minder Duration
In ②, Advanced → ● Duration:

 → ● Select time
 → ∞ →

 From
 □

■ For custom Duration, select *Other*. Selecting/Canceling All Hours

In ②, ⊚ → Check All or Uncheck All

# At Hour Minder Time

Hour Minder activates; sounds/vibrates by related settings.



#### Stopping Tone Instantly

• Press a key.


When Another Function is Active

- Hour Minder does not activate.
   Incoming Calls
- Active Hour Minder stops for incoming calls.

#### Canceling Hour Minder







# Using Pedometer

#### **Getting Started**


- Count based on a pace of approximately 100 steps per minute over even terrain.
- Accuracy may be affected by course, terrain, walking style, etc.
- Avoid holding the handset; use a body worn case or a strap, or place handset inside a pocket or bag.
- Avoid sudden/erratic movements.
- Steps are not counted in the following cases:
  - While handset is off
  - For the first few steps
  - While handset vibrates
- Handset use may affect accuracy.
- Use Pedometer only as a rough guide.

#### **Adjusting Counter Sensitivity**

- **Tools → O Clocks/** Gauges → Pedometer → • • → Select option●
- Select *Low* when steps seem overcounted: select High when they seem undercounted

#### Saving Body Information

Weight and pace entry required to view full Pedometer data.





Pedometer Menu

- Settings **→ ● →** Body Info.
- Enter Handset Code **→**



Body Info Menu

- Height 

  ◆ Enter height
- Weight 

  ◆ 

  Enter weight **→**
- $Pace \Rightarrow \bigcirc \Rightarrow Yes \text{ or } No \Rightarrow \bigcirc$ • Choose Yes to enter pace automatically based on height.
- **Editing Body Information** 
  - ▶ Enter value 
     ◆ 

     ◆ 
     □ ■ For *Pace*, automatic calculation
- confirmation appears (when height is entered).

#### **Activating Pedometer**

- In Pedometer menu, Switch

**Canceling Pedometer** In  $\bigcirc$ , Off  $\Rightarrow$   $\bigcirc$ 



#### **Pedometer Indicator**

When Pedometer is active, today's step count appears in Standby.



#### **Viewing Step Count Records**

In Pedometer menu, Today's Walking **→** ●







Steps Window

- Press ( r) to toggle daily/weekly view.
- Press ∑ to open previous day/ week, or # at to open next day/week.

Select time/date 

◆ 

●

Hourly/daily step counts appear.

Standby returns

Resetting Today's Step Count In ②, ☑ → Reset Day's Data → ① Yes → ●

Resetting Log

→ ( ) → Yes → ( )

■ Todav's data is also reset.

#### **Setting Targets**

Information window opens, etc. when target is achieved for these items:



- In Pedometer menu, Settings → ● Target → ●
- Target Settings **→** ●
- Select item **→ ● →** Enter value/time 

  ◆
  - Other target settings may consequently change.

#### **Editing Targets**

[Pedometer Menu] Settings → • • → Select item ⇒ (□) ⇒ Enter value/ time **→** •

#### When Target is Achieved

 A tone sounds and Information window opens. (Select Goal Achievement and press ( ) to open Pedometer Calendar.) Follow these steps to mute achievement tone:

[Pedometer Menu] Settings → • • ● Off ● ●

#### About Exercise (Ex)

 Ex and MET indicate amount and intensity of physical activity, respectively. Ex for walking is calculated by multiplying 3 METs by walking duration (hour).

#### **Advanced**



Handy Extras

🤔 Changing Pedometer indicator Ousing Pedometer Calendar Ochecking accumulated data Resetting accumulated data Customizing achievement notice (P.9-40 - 9-41)

# **Opening PC Documents**

Supported File Formats:

PDF (.pdf) Microsoft® Excel® (.xls) Microsoft® Word (.doc) Microsoft® PowerPoint® (.ppt)

- Some files may not appear correctly.
- Download files via the Internet.
- When transferring files from PCs, save to corresponding Memory Card folder (P.15-24).





Select file **→** •

Zooming In/Out with Loupe (Magnifier) In open file, <sup>®</sup> (Long) → Specify portion **⇒** <sup>(2)</sup> **→** Zoom Out or Zoom In **▶** ●

| Key Assignments                |                           |
|--------------------------------|---------------------------|
| View Whole Page                | •                         |
| Scroll                         | <b>:</b>                  |
| View Upper Left                | 1 *                       |
| Toggle Full Screen View On/Off | 2 m                       |
| View Upper Right               | 3 000                     |
| Zoom Out                       | 4 th                      |
| Continuous Zoom Out            | 4 tong) (Long) (Long)     |
| View Center                    | 5 %                       |
| Zoom In                        | 6 IZ /                    |
| Continuous Zoom In             | 6 (Long)                  |
| View Lower Left                | 7 *                       |
| Jump to Page                   | 8 * TUV                   |
| View Lower Right               | 9 8002                    |
| Open Help                      | #d 0                      |
| Next Page                      | # %                       |
| Previous Page                  | ¥ #±±                     |
| Fit Width                      | ٩                         |
| Rotate 90 Degrees              | \(\frac{\frac{1}{2}}{2}\) |



#### **New Notepad Entry**





Notepad List





Enter text → ●



# Sorting Entries Temporarily [Notepad List] (2)

#### **Opening Notepad**




CLIST returns

#### **Deleting Entries**

#### One Entry

In Notepad list, select entry

⇒ □




#### Selected Entries

In Notepad list, select entry →

Setting/Manage →

O





# Unchecking All In ⊚, Uncheck All → ●

#### All Entries

In Notepad list, select entry →

Setting/Manage → ●



#### Advanced



Handy Extras


© Editing Notepad Searching text within all entries Inserting Notepad text into message text Sending entries via S! Mail Creating text files
Importing text files
Checking memory status
Opening properties (P.9-41)

# **Using ASCII Art**

#### **Inserting ASCII Art**

In message text entry window, ⊕ → Call ASCII Art







#### Previewing ASCII Art In ⊘, select entry ⇒ ⊚


■ Press to insert ASCII Art.

#### **Editing Entries**





**ASCII Art List** 





#### **Deleting Entries**

- In ASCII Art list, select entry


  → □ → Delete → ●
- Yes → ●



# **Recording/Playing Voice**

#### Recording

- Recording stops if battery runs low while recording.
- Record conversations during calls via Record Caller Voice.





Recording Window







 For Extended Voice, recording is saved automatically.





#### **Playback**

In recording window, 

Ring Songs Tones 

●





# Playback Operations

| Adjust Volume | <b>③</b> |
|---------------|----------|
| Pause/Resume  | •        |
| Stop          | SLEAN EE |



# **Scanning Barcodes**

Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.









# 🔰 Scan Barcode 🕈 💿

**Display** 





Scan Window

- Use Focus Adjustment Bar as a guide (better focus in darker blue).
- If focus is poor, press 🐑 to switch to Shutter mode.



#### Scan starts

- If recognition takes time, slowly adjust the distance between handset and barcode.
- Press 🐨 to stop scan.

# Tone sounds **→** Scan results appear



#### **Split Data**


- After scanning, confirmation appears.
   Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

# Starting Over



## Key Assignments in Scan Window

| Toggle Focus Mode      | 3 3   |
|------------------------|-------|
| Switch to Photo Camera | 7 *   |
| Focus Lock             | Û     |
| Mobile Light On/Off    | # 0,7 |
| Adjust Brightness      | ••    |
| Open Help              | O se  |





# **Creating QR Codes**

Create QR Codes from these items on handset:



Large items are divided into multiple QR Codes.

#### **Procedure**

Follow these steps to create QR Codes from Data Folder files:

● → Tools → ● → ⊕
Doc./Rec. → Barcode/Scan
→ ●



Create QR Code → ●





- Select folder 

  Select file or entry 

  Select
  - QR Code is created.



 QR Code is saved to Data Folder (Pictures).

# From Phone Book Entries In ⊚, Phone Book → ● Select

entry **▶ (•) ♦ (-)** 

From My Details In ⊗, My Details → ● □ → □

From Entered Text

In 6, Text Input  $\Rightarrow$  6  $\Rightarrow$  Enter text  $\Rightarrow$  6  $\Rightarrow$  5

Switching Storage Media

In  $\bigcirc$ ,  $\bigcirc$   $\Rightarrow$  Save to  $\Rightarrow$   $\bigcirc$   $\Rightarrow$  Phone or Memory Card  $\Rightarrow$   $\bigcirc$   $\Rightarrow$   $\bigcirc$ 

Attaching to S! Mail

In ⑤, ᠍ → Send As Message → ⑥

→ Complete message → 😇

#### **Incoming Calls**

 QR Code creation is not affected by incoming calls. End the call to return.



# **Scanning Business Cards**

Scan business cards and save names, addresses, etc. to Phone Book.

- English business cards may not be scanned correctly.
- Some cards may not be scanned.











Scan Window

- 40
  - Press (y) to stop scan.
- 🕞 ⊙ ➡ Scan results appear



- - New Phone Book entry is saved.

# If Text Exceeds Phone Book Entry Item Character Limit

 Confirmation appears. Follow these steps to delete overage:

Yes **▶** •

**Switching Storage Media** 

After ⑤, ◎ → Save to → ⑥ →
Select storage media → ⑥ → ⑥

Saving Scanned Image as Phone Book Picture

After  $\bigcirc$ ,  $\bigcirc$   $\Rightarrow$  Add Image  $\Rightarrow$   $\bigcirc$   $\Rightarrow$  On  $\Rightarrow$   $\bigcirc$ 

Starting Over

After  $\bigcirc$ ,  $\bigcirc$   $\Rightarrow$  Yes  $\Rightarrow$   $\bigcirc$   $\Rightarrow$  From  $\bigcirc$ 

# Key Assignments in Scan Window

| Toggle Focus Mode      | 3 3   |
|------------------------|-------|
| Switch to Photo Camera | 7 *   |
| Focus Lock             | C.    |
| Mobile Light On/Off    | # 27  |
| Adjust Brightness      | •     |
| Open Help              | O 20# |



# **Scanning Text**

Scan text and save it to Notepad, etc. Available Modes:

|      | Capture text in full screen and scan a selected line |
|------|--|
| Line | Capture a few lines of text and scan a selected line |


- To toggle mode, press 💬 in scan window.
- Some text cannot be scanned







- To change mode, press 😉 in scan window.
- Frame text in center of Display



Scan Window

- Scan starts
   Press ഈ to stop scan.
- Select line ▶ ▶ Scan results appear





🍞 🖻 Þ Notepad 🕈 💿

Correcting Text Type

After ⑤, ⑥ ♦ Change Mode ♦ ⑥
♦ Select type ♦ ⑥ ♦ From ⑥

Editing Scanned Text

After ⑤, ⑥ ♦ Select/Edit ♦ ⑥ ♦

Select character ♦ Select alternative from list or edit directly ♦ From ⑥

Starting Over

In ⑥, ⑥ ♦ Yes ♦ ⑥ ♦ From ⑥

Key Assignments in Scan Window

| Toggle Focus Mode      | 3 3  |
|------------------------|------|
| Switch to Photo Camera | 7 *  |
| Focus Lock             | ÷.   |
| Mobile Light On/Off    | T ov |
| Adjust Brightness      | ••   |
| Open Help              | Ø# 0 |



# Using Kanji Grabber

Scan a word of up to ten kanji and look it up in dictionaries.

Some text cannot be scanned.







Frame kanji in Loupe



Scan Window

- Scan results (k
  - Scan results (kanji) appear.
- 6
- Select dictionary 

  ◆ ◆

  Search 

  ◆
- Select word, etc. 

  ◆ ●

   Definition/translation window of
  - Definition/translation window opens.

Starting Over In ⑤, ఄ Þ From ⑧ Key Assignments in Scan Window

| Toggle 2x Magnification On/Off | ¥7)  |
|--------------------------------|------|
| Toggle Focus Mode              | 3 3  |
| Switch to Photo Camera         | 7 *  |
| Focus Lock                     | C.   |
| Mobile Light On/Off            | # av |
| Adjust Brightness              | •    |
| Open Help                      | 0 se |





| Calendar                             |  |
|--------------------------------------|--|
| ■ View Settings                      |  |
| Changing default view                | Tools  In PIM/Lifestyle menu, Calendar  Calendar Settings  Calendar Settings  Calendar Settings  Select type  Select type  |
| Jumping to specified date            | ● → Tools → ● → In PIM/Lifestyle menu,  Calendar → ● → ⑧ → Enter date → ●  |
| Changing date color                  | Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below   |
|                                      | By Days of the Week  |
|                                      | By Date Select date → 4. → Select color → ●  Not available in 6Month View.   |
|                                      | Resetting "By Date" Colors  ③  |
| Selecting task view option           | Tools  In PIM/Lifestyle menu, Calendar  Calend |
| Adding stamps<br>(Month/3Month View) | ● * Tools * ● * In PIM/Lifestyle menu,  Calendar * ● * Select date * ② * Select  stamp * ●   |
| Hiding schedules                     | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Calendar</li> <li>Select date</li> <li>Select entry</li> <li>Secret:</li> <li>On</li> <li>On</li> </ul>  |

|                                 | Start Here  |
|---------------------------------|---|
| Saving additional holidays      | Adding Holidays <empty> ● ● Enter name ● ● Enter date ● ● Select frequency ● ● ♥ ⊙</empty>  |
|                                 | Editing Added Holidays  Select holiday © Date: Name:  Enter name ODAte: DATE: |
| Removing/<br>restoring holidays | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Calendar</li> <li>Set Holiday</li> <li>Select holiday</li> <li>(□/√)</li> </ul>   |

# ■ Saving/Editing Schedules

| Setting Category/<br>Location | Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → ● See below  |  |
|-------------------------------|--|--|
|                               | Category  Category:   Select Category  Select Category   |  |
|                               | Location  Location:  |  |
| Creating Categories           | Start Here   |  |
|                               | Renaming Categories Select Category  |  |
|                               | Changing Icons Select Category   |  |
|                               | Resetting  ③ → Reset Settings → ● → Enter Handset  Code → ● → Yes → ●  |  |
| Saving repetitive schedules   | ● Tools ● In PIM/Lifestyle menu,  Calendar ● Select date ● Select  entry ● ● ● Repeat: ● Select  frequency ● Enter repeat time ● ● ♡  • Repeat time is not available for Every Year. |  |
|                               |  |  |

| Saving S! Friend's<br>Status information   | Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → ● → S! Friend's Status: → ● → Link Setting: → ● → Linked → ● → See below |
|--|--|
|  | Availability  Answer Status:   |
|  | Comment  Comment:  |
| Editing entries                            | ● Tools ● In PIM/Lifestyle menu,  Calendar ● Select date ● Select  entry ● ● Select item ● Edit in  the same manner as saving schedules ●   y                                  |
| Changing Alarm<br>tone/video &<br>duration | Start Here ● → Tools → ● → In PIM/Lifestyle menu, Calendar → ● → Select date → ● → Select entry → ● → Alarm: → ● → See below   |
|  | Alarm Tone/Video  Assign Tone/Video:   Select folder  Select tone/file  Select start point if required.  |
|  | Duration  Duration:   ◆ ● Select time   ◆ ● ◆ ♥ ◆ ♥  |
| Changing Alarm volume                      | ● Tools ● In PIM/Lifestyle menu, Calendar ● □ Alarm Settings ● Alarm Volume: ● Adjust level ●  |
| Selecting Vibration option                 | ● Tools ● In PIM/Lifestyle menu,  Calendar ● □ Alarm Settings ●  Vibration: ■ Select option ■  |



|                | → Tools →                             |
|----------------|---------------------------------------|
| Sounding Alarm | Calendar → ● → □ → Alarm Settings → ● |
| tone even in   | ⇒ For Manner Mode: ⇒ ● ⇒ Ring ⇒ ●     |
| Manner mode    | Yes • •                               |

| ■ Managing Schedules                                  |   |
|---|---|
| Searching entries                                     | Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below  |
|   | By Part of Subject  |
|   | By Category  Select Category   ●  |
| Checking memory status                                | ● * Tools * ● * In PIM/Lifestyle menu,  Calendar * ● * Select date * □ * Memory  Status * ●   |
| Deleting all entries                                  | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Calendar</li> <li>Salendar</li> <li>Salendar</li> <li>Delete</li> <li>All</li> <li>Appointments</li> <li>Enter Handset Code</li> <li>Yes</li> </ul> |
| Deleting entries by<br>specifying week<br>(Week View) | Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below  |
|   | Within One Week Select date ⇒ ② ⇒ Delete ⇒ ● → All This Week ⇒ ● → Yes ⇒ ●  |
|   | Up to the End of Previous Week Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ Up to Last Week ⇒ ● ≯ Yes ⇒ ●   |

| Deleting entries by specifying month (Month/3Month View) | Start Here ● → Tools → ● In PIM/Lifestyle menu, Calendar → ● → See below                            |
|--|---|
|  | Within One Month Select date → ② → Delete → ● → All This Month → ● → Yes → ●                        |
|  | Up to the End of Previous Month Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ Up to Last Month ⇒ ● → Yes ⇒ ●       |
| Deleting entries in<br>six months<br>(6Month View)       | ● * Tools * ● In PIM/Lifestyle menu, Calendar * ● * ⑤ * Delete * ● * All This 6Months * ● * Yes * ● |

# Tasks

# Task List

| <br>Tools  In PIM/Lifestyle menu,  Tools  Tools                   |
|---|
| Tasks → ● → Select task → □ → Edit → ● → Secret: → ● → On → ● → ♡ |

# ■ Saving/Editing Tasks

| Editing tasks    | ● Tools ● In PIM/Lifestyle menu,  Tasks ● Select task ● □ Edit ● ●  Select item ● Edit in the same  manner as saving tasks ● □ |
|------------------|--|
| Setting priority | ● Tools ● In PIM/Lifestyle menu,  Tasks ● Select task ● Edit ● Priority: ● Select priority ● ©                                 |



|   | Start Here ● → Tools → ● ▶ In PIM/Lifestyle menu, Tasks → ● → Select task → □ → Edit → ● → Alarm: → ● → See below     |
|---|---|
| Changing Alarm tone/<br>video & duration      | Alarm Tone/Video  Assign Tone/Video:  |
|   | Duration  Duration: ♦ ● ♦ Select time ♦ ● ♦ ♥ ♦ ♥   |
| Changing Alarm volume                         | ● * Tools * ● * In PIM/Lifestyle menu,  Tasks * ● * ③ * Alarm Settings * ● *  Alarm Volume: * ● * Adjust level * ●    |
| Selecting Vibration option                    | ● * Tools * ● In PIM/Lifestyle menu,  Tasks * ● * ③ * Alarm Settings * ● *  Vibration: * ● * Select option * ●        |
| Sounding Alarm<br>tone even in<br>Manner mode | ● * Tools * ● * In PIM/Lifestyle menu, Tasks * ● * ◎ * Alarm Settings * ● * For Manner Mode: * ● * Ring * ● * Yes * ● |

| ■ Managing Tasks   |  |
|--------------------|--|
|                    | Start Here   |
| Searching tasks    | By Part of Subject   |
|                    | By Subject → ● → Enter text → ●  |
|                    | By Due Date  |
|                    | By Due Date ⇒ ● ⇒ Enter date ⇒ ●   |
| Sorting tasks by   | ● → Tools → ● In PIM/Lifestyle menu,   |
| priority           | Tasks → ● → 🖾 → Sort → ● → Priority → ●  |
| Checking memory    | ● → Tools → ● In PIM/Lifestyle menu,   |
| status             | Tasks → ● → 🖾 → Memory Status → ●  |
| Deleting all tasks | Tools • • In PIM/Lifestyle menu,  Tasks • • • Delete • • All Tasks  • Enter Handset Code • • Yes • • |

# Alarms

| Editing entries                               | ● Tools ● In PIM/Lifestyle menu,  Alarms ● Select entry ● Select item ● Edit in the same manner as saving entries ● ♡  |
|---|--|
| Saving entry name                             | ● Tools ● In PIM/Lifestyle menu,  Alarms ● Select entry ● Subject:  ● Enter name ● © ♡   |
|   | Start Here   |
| Changing Alarm tone/video                     | Using Preset Tone or Data Folder File  Select folder → ● ⇒ Select tone/file ⇒ ⊕ ⇒ ⊗  • Select start point if required.   |
|   | Using Customized Screen Tone/Video  Customized Screen  |
| Setting handset to vibrate at Alarm Time      | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Alarms</li> <li>Select entry</li> <li>Vibration:</li> <li>On or Link to Sound</li> <li>Select Link to Sound</li> <li>Select Link to Sound</li> <li>Select Link to Sound</li> </ul> |
| Sounding Alarm<br>tone even in<br>Manner mode | ● Tools • ● In PIM/Lifestyle menu,  Alarms • ● Settings • ● For Manner  Mode • ● Ring • ● Yes • ●  |
| Activating Alarm based on World Clock time    | ● ▼ Tools ▼ ● ▼ In PIM/Lifestyle menu,  Alarms ▼ ● ▼ Settings ▼ ● ▼ Link to  World Clk ▼ ● ♥ On ▼ ●  |

# Wakeup TV

| Editing entries                               | ● * Tools * ● In PIM/Lifestyle menu,  Wakeup TV * ● Select entry * ● *  Select item * ● Edit in the same manner as saving entries * • |
|---|---|
|   | Start Here  |
| Changing Alarm tone/video                     | Using Preset Tone or Data Folder File Select folder → ● → Select tone/file → ● → • Select start point if required.                    |
|   | Using Customized Screen Tone/Video  Customized Screen   |
| Sounding Alarm<br>tone even in<br>Manner mode | ● * Tools * ● * In PIM/Lifestyle menu,  Wakeup TV * ● * For Manner Mode * ● *  Ring * ● * Yes * ●                                     |

# Calculator

| Copying calculation results                    | While result appears, ⊜ → Copy → ●  |
|--|---|
| Changing exchange rate for currency conversion | Tools  In PIM/Lifestyle menu, Calculator  Money Converter  Exchange Rate  Domestic or Foreign  Enter rate   |
| Converting currencies                          | ● Tools ● In PIM/Lifestyle menu,  Calculator ● Enter amount of money  ■ Money Converter ● To Domestic  or To Foreign ●   • Set Exchange Rate first. |



#### **Expenses Memo Changing Category** Expenses Memo > • Totals > • > of saved entry Expenses Memo > • Totals > • > Changing amount Edit ⇒ ● Renaming Categories ⇒ Select Category ⇒ ● ⇒ Enter name ⇒ ●

Osaifu-Keitai®

Balance Info list

| Enabling to view e-money balances                   | ● Tools ● In PIM/Lifestyle menu, Osaifu-Keitai ● IC Card Settings ● ● Balance Info ● Enter Handset Code ● ● <empty> ● Stappli or Lifestyle-Appli ● Select application ● ●  For use with compatible Lifestyle-Applications.  • Start Lifestyle-Appli once before adding it to Balance Info list.</empty> |
|---|---|
|   |   |
| Moving applications<br>up/down Balance<br>Info list | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Osaifu-Keitai</li> <li>IC Card Settings</li> <li>Balance Info</li> <li>Enter Handset Code</li> <li>Select application</li> <li>Move</li> <li>Select target location</li> </ul>  |

Select application ⇒ □ → Delete ⇒ ●

| Customizing<br>handset response<br>to reader/writer<br>commands | ● Tools ● In PIM/Lifestyle menu, Osaifu-Keitai ● IC Card Settings ● Interface Settings ● Enter Handset Code ● Select item ● Off ●  |
|---|--|
| Opening IC Card properties                                      | ● * Tools * • • In PIM/Lifestyle menu, Osaifu-Keitai * • * IC Card Settings * • * IC Card Status * •   |
|   | Start Here ● → Tools → ● → In PIM/Lifestyle menu, Osaifu-Keitai → ● → IC Card Settings → ● → Remote Lock → ● → Enter Handset Code → ● → Mail Remote Lock → ● → Notice Settings → ● Send Notice → ● → See below |
| Changing IC Card<br>Lock notice recipient                       | Changing Recipient  To Set Recipient  Select method  Select/lenter number/address  Signature  Omit step of pressing Signature  Book as setting method.   |
|   | Disabling Notice Off   |
| Changing required<br>Missed Call count<br>for Call Remote Lock  | ● Tools ● In PIM/Lifestyle menu,  Osaifu-Keitai ● IC Card Settings ●  Remote Lock ● Enter Handset Code  • Call Remote Lock ● Count for Lock • Enter Missed Call count ● ©                                      |
| Restoring default<br>Osaifu-Keitai <sup>®</sup><br>settings     | <ul> <li>Tools</li> <li>In PIM/Lifestyle menu,</li> <li>Osaifu-Keitai</li> <li>IC Card Settings</li> <li>Set to Default</li> <li>Enter Handset Code</li> <li>Yes</li> </ul>                                    |



| Starting via<br>Simulated Call menu | Tools In PIM/Lifestyle menu, Simulated Call  Page 1 Simulated Call Sarts immediately regardless of Receive Timing setting.  Settings remain even after starting Simulated Call during setup. |
|-------------------------------------|--|
| Clearing caller information         | ● * Tools * ● * In PIM/Lifestyle menu,<br>Simulated Call * ● * Set Caller * ● * ◎<br>* Yes * ● * ② * ②   |
| Overriding Silent volume setting    | ● Tools ● In PIM/Lifestyle menu, Simulated Call ● For Silent Mode ●  Pring ● Yes ● ♥   Ring ● Yes ● ♥  |

| Hour | Minder |
|------|--------|
|------|--------|

| Changing Hour<br>Minder tone/video                   | ● Tools ● ⇔ ⇔ Clocks/Gauges Hour Minder ● Advanced ● Assign Tone/Video: ● Select folder ● Select toneffile ● ⊗ ⊗ ⊗ ⊗  |
|--|---|
| Setting handset to<br>vibrate at Hour<br>Minder Time | ● Tools ● ⇔ Clocks/Gauges Hour Minder ● Advanced ● ♥ Vibration: ● ♥ On or Link to Sound ● ● Select Link to Sound to allow compatible SMAF files to control vibration. |

| Sounding Hour<br>Minder tone even<br>in Manner mode    | ● ▼ Tools ▼ ● ▼ ○ Clocks/Gauges ▼ Hour Minder ▼ ● ➤ Advanced ▼ ● ▼ For Manner Mode: ▼ ● ▼ Ring ▼ ● ▼ Yes ▼ ● ▼ ○ ▼ |
|--|--|
| Activating Hour<br>Minder based on<br>World Clock time | ● Tools • ● ⇔ Clocks/Gauges → Hour Minder • ● Advanced • ● Link to World Clk: • ● On • ● ⇔ ⊙ • ⊙                   |

# Pedometer

| i edofficter                    |   |
|---------------------------------|---|
| Changing<br>Pedometer indicator | Settings  Standby Display  Settings  Pedometer  Select item  Select i |
| Using Pedometer<br>Calendar     | ● Tools ● ● ○ Clocks/Gauges ● Pedometer ● ● Pedometer Calendar ● ● Select date ● ● Degree of achievement appears. • Press ※ or ### to view previous or next month.  |
| Checking accumulated data       | ● Tools ● ● ○ Clocks/Gauges → Pedometer ● ● Accumulated Data ● ○ Change in body information is reflected in the data.   |
| Resetting accumulated data      | ● * Tools * ● * • ○ Clocks/Gauges * Pedometer * ● * Accumulated Data * ● * Code * ● * Yes * ● Enter Handset Code * ● * Yes * ● Averages are also reset.   |

| Customizing achievement notice | Start Here $\Rightarrow$ Tools $\Rightarrow$ $\Rightarrow$ Clocks/Gauges $\Rightarrow$ Pedometer $\Rightarrow$ Settings $\Rightarrow$ Target $\Rightarrow$ $\Rightarrow$ Goal Announce $\Rightarrow$ $\Rightarrow$ On $\Rightarrow$ See below |
|--------------------------------|---|
|                                | Changing Tone  Goal Sound   |
|                                | Changing Tone Volume  Goal Volume   |
|                                | Selecting Vibration Option  Vibration   |
|                                | Changing Duration  Duration   Select time   For custom Duration, select Other and press   .   |

| N   |   | 10 |   | _ | a |
|-----|---|----|---|---|---|
| IV. | U | te | μ | a | u |

| Editing Notepad                          | Start Here  |
|--|---|
|  | Editing Text  Edit Text   ● Edit   • Edit   |
|  | Changing Category  Change Category   Select Category  ●   |
| Searching text within all entries        | ● * Tools * • • • • Doc./Rec. * Notepad  • • Select entry * • • Search * • •   Enter text * •   |
| Inserting Notepad text into message text | ● Tools ● Doc./Rec. Notepad  ● Select entry ● Send ● As  Message Text ● SI Mail or SMS ●  Complete message   SI Mail Composition window opens automatically depending on character count. |

| Sending entries via<br>S! Mail | ● * Tools * ● * * Doc./Rec. * Notepad  • • Select entry * ○ * Send * • *  Via Message * • Complete message * *  |
|--------------------------------|---|
| Creating text files            | <ul> <li>Tools</li> <li>Select entry</li> <li>Select Text File</li> <li>Save here</li> <li>Tools</li> <li>Setting/Manage</li> <li>Enter name</li> </ul> |
| Importing text files           | Tools • Doc./Rec. Notepad • Select entry • Select file • Select file • Select file • O  |
| Checking memory status         | ● Tools ● ● ⊙ Doc./Rec. → Notepad  ● ● Select entry ● ⊜ → Setting/Manage  ● ● Memory Status ● ●   |
| Opening properties             | ● → Tools → ● → Operation → Notepad  → ● → Select entry → □ → Details → ●   |

# Voice Recorder

|                                 | ● → Tools → ● → ⊙ Doc./Rec. → Voice   |
|---------------------------------|---|
|                                 | Recorder ⇒ ● ⇒ 🖾 ⇒ Record Time ⇒ ● ⇒  |
| Saving longer                   | Extended Voice ⇒ ● ⇒ Recording  |
| recordings                      | starts  |
|                                 | Insert Memory Card to record in Extended Voice  |
|                                 | mode. (Recording is saved automatically.)   |
|                                 | Tools  T |
| Sending Voice files via S! Mail | Recorder ⇒ ● ⇒ ● Recording starts ⇒ ●   |
|                                 | Recording ends ⇒ Save and Send ⇒ ●  |
|                                 | Complete message  |
|                                 |   |
|                                 | Available in <i>For Message</i> mode.   |



|                   | Tools      O      Tools      O      Doc./Rec.      Voice             |
|-------------------|--|
|                   | Recorder ⇒ ● ⇒ 🖾 ⇒ Save Recording to ⇒                               |
| Switching storage | Recorder → • • □ → Save Recording to → • Select option → •           |
| media             | <ul> <li>Available in For Message mode.</li> </ul>                   |
|                   | <ul> <li>Set to Ask Each Time to select media after every</li> </ul> |
|                   | recording.   |

# Scan Barcode

| Scanning during text entry   | Start Here   In a text entry window, (a) ⇒ Scan ⇒ (b) ⇒ Scan Code ⇒ (b) ⇒ Frame barcode in center of Display ⇒ (b) ⇒ See below   |
|------------------------------|--|
|                              | Pasting All Scan Results   |
|                              | Pasting a Part of Scan Results  ② → Select first character → ● → Highlight text range → ●  |
| Scanning continuously        | ● Tools ● ODC./Rec. Barcode/ Scan ● Scan Barcode ● ● □ □ Continuous Scan ● On ● Frame barcode in center of Display ● Choose Yes to continue scanning or No and press ● to view scan results. |
| Reading saved barcode images | ● ▼ Tools ▼ ● ♥ ⊙ Doc./Rec. ▼ Barcode/ Scan ▼ ● ▼ Open Barcode ▼ ● Select file ▼ ●   |
| Saving scan results          | ● * Tools * ● * ◆ Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * ⑤ * Save * ●   |

| Saving to Notepad                   | ● * Tools * ● * ⊙ Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * ⑤ * Notepad * ●  |
|-------------------------------------|--|
| Saving linked info<br>to Phone Book | ● Tools ● ● Doc./Rec. ■ Barcode/ Scan ● Scan Barcode ● ■ Frame barcode in center of Display ● ● Select number or mail address ■ ◎ ■ Save to Ph.Book ● ● As New Entry ● ● Complete other fields ● ② ● To add to an existing entry, select As New Detail. ● When MEMORY: appears in scan results, press ● to enter the items underlined with a dotted line automatically in Phone Book entry window. |
| Opening saved scan results          | ● Tools ● ● Onc./Rec. ■ Barcode/ Scan ● Scanned Results ● ● Select file ● ●  • Select a file and press ⊕ to rename files, open properties or delete files. • Some files may not open.  |
|                                     | Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → See below  Dialing Numbers Select phone number → ● → ③   |
| Using linked info                   | Sending Messages Select mail address → ● Complete message → ⊕  • When MAILTO: appears in scan results, press ● to enter the items underlined with a dotted line automatically in Composition window.  Accessing Internet Sites Select URL → ●  |



| Using images as<br>Wallpaper        | Tools  |
|-------------------------------------|--|
| Saving images & melodies            | ● Tools ● ● ⊙ Doc./Rec. Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select file ● ③ ▼ To Data Folder ● ●   |
| Opening or playing files            | ● Tools ● ● ⊖ Doc./Rec. ■ Barcode/ Scan ● ● Scan Barcode ● ● Frame barcode in center of Display ● ● Select file ● ●  |
| Using images for<br>System Graphics | ● Tools ● → Doc./Rec. Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select image ● As System ● Select item ● Specify image area ● ● • Some images may be usable without specifying image area. |

| Pasting to<br>message text | Start Here ● → Tools → ● → ⊙ Doc./Rec. →  Barcode/Scan → ● → Scan Barcode → ● →  Frame barcode in center of Display → ● → □  → Send Message → ● → See below                                     |
|----------------------------|---|
|                            | All Text  |
|                            | Selected Text  ③ Select first character → ● Highlight text range → ● S! Mail or SMS → ● ★  Complete message → ○  • S! Mail Composition window opens automatically depending on character count. |
| Copying text               | Start Here ● → Tools → ● → ⊙ Doc./Rec. →  Barcode/Scan → ● → Scan Barcode → ● →  Frame barcode in center of Display → ● →  See below  |
|                            | Text  ② → Copy → ● → Select first character → ●  → Highlight text range → ●   |
|                            | Number, Address or URL  Select number, mail address or URL  ©  Copy Telephone, Copy Address or Copy URL  ©  ©   |


# Scan Card

| Saving to Notepad       | ● * Tools * ● * ⊖ Doc./Rec. * Barcode/ Scan * ● * Scan Card * ● * Frame card in center of Display * ● * ● * ③ *  Notepad * ● |
|-------------------------|--|
| Pasting to message text | Start Here   |
|                         | All Text   |
|                         | Selected Text  (a)   |
| Copying text            | Start Here   |
|                         | Text  ② → Copy → ● → Select first character → ●  → Highlight text range → ●  |

# Scan Text

| Scanning and pasting during text    | In a text entry window, ⊚ ⇒ Scan ⇒ ● ⇒ Scan Text ⇒ ● Frame text in center of  |
|-------------------------------------|---|
| entry                               | Display   |
| Scanning more text                  | ● Tools ● ODOC/Rec. Barcode/ Scan ● Scan Text ● Frame text in center of Display ● Select line ● ● ② Continue Part to enter additional text or • Select Continue Part to enter additional text or  |
|                                     | Scan More to enter text after a line break.   |
| Saving scan results                 | ● Tools • ● Doc./Rec. Barcode/ Scan • Scan Text • ● Frame text in center of Display • Select line • ●  • Save • ●   |
| Saving linked info<br>to Phone Book | ● Tools ● Doc./Rec. Barcode/ Scan ● Scan Text ● Frame text in center of Display ● Select line ● ● Select number or mail address ● Save to Ph.Book ● As New Entry ● Complete other fields ● ● To add to an existing entry, select As New Detail. |
| Opening saved scan results          | ● * Tools * ● * • Doc./Rec. * Barcode/ Scan * ● * Scanned Results * ● * Select file * ●  • Select a file and press ⑤ to rename files, open properties or delete files. • Some files may not open.   |

| Using linked info       | Start Here ● → Tools → ● → ② Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → See below  Dialing Numbers Select phone number → ● △ Sending Messages Select mail address → ● Complete message → ②  Accessing Internet Sites  |
|-------------------------|---|
| Pasting to message text | Select URL $\blacktriangleright$ $\bullet$ Start Here $\bullet$ $\rightarrow$ Tools $\blacktriangleright$ $\bullet$ $\rightarrow$ Doc./Rec. $\blacktriangleright$ Barcode/Scan $\blacktriangleright$ $\bullet$ $\rightarrow$ Scan Text $\blacktriangleright$ $\bullet$ $\rightarrow$ Frame text in center of Display $\blacktriangleright$ $\bullet$ $\rightarrow$ Select line $\blacktriangleright$ $\bullet$ $\rightarrow$ $\bullet$ $\rightarrow$ $\bullet$ $\rightarrow$ Send Message $\rightarrow$ $\bullet$ See below |
|                         | All Text  (a) ⇒ S! Mail or SMS ⇒ (b) ⇒ Complete message ⇒ (c)  (b) S! Mail Composition window opens automatically depending on character count.   |
|                         | Selected Text  ③ Select first character → ● Highlight text range → ● S! Mail or SMS → ●  Complete message → Θ  • S! Mail Composition window opens automatically depending on character count.   |





#### Osaifu-Keitai®



#### Cannot use Osaifu-Keitai® (S! FeliCa)

• Battery may be low. Charge battery or install a charged battery.



#### Recognition via reader/writer takes time

• Check logo area. Foreign articles can block/hamper recognition.



#### Call Remote Lock does not activate even after specified number of Missed Calls

- . Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
- When Call Forwarding is active, Missed Calls may not be recorded.

#### Wakeup TV



#### TV does not activate with specified channel

• If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

#### Voice Recorder



#### Cannot record properly

• If incompatible microphone is connected, recording may fail.



# Noise/skipping occurs

 Avoid shocks to handset while recording; may cause noise or skipping.



#### Recording takes time to start

• Recording window may take longer to open as more Voice files are saved on Memory Card.

#### Scanning Barcode/Card/Text



# Cannot read barcodes properly

- · Scan may fail if barcode is dirty or unclear.
- · Scan may fail if barcode is scanned under inadequate light.
- · Scan may fail if multiple barcodes are captured at one time.



#### Cannot read barcodes during text entry

· Scanning is not available during calls or when mobile camera is active.



#### Cannot read barcode images in **Data Folder automatically**

· When scan fails, follow onscreen instructions and select next barcode image manually.



#### Cannot scan business cards properly

- Scan fails if business card is printed in light-colored text on a dark background, handwritten or printed in casual/decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.



#### Cannot scan text properly

- · Scanning over 35 characters at one time may yield poor results.
- Adjust to frame text in []. Letters at the ends may be distorted.

